




Power Planer

170 mm (6 - 3/4")

MODEL 1806B



I N S T R U C T I O N M A N U A L

⚠ WARNING:

For your personal safety, READ and UNDERSTAND before using.
SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

SPECIFICATIONS

Model	1806B
Planing width	170 mm (6-3/4")
Planing depth	2 mm (1/16")
No load speed (RPM)	15,000/min.
Overall length	529 mm (20-3/4")
Net weight	8.8 kg (19.3 lbs)

- Manufacturer reserves the right to change specifications without notice.
- Specifications may differ from country to country.

GENERAL SAFETY RULES

USA002-2

(For All Tools)

⚠ WARNING:
Read and understand all instructions. Failure to follow all instructions listed below, may result in electric shock, fire and/or serious personal injury.

SAVE THESE INSTRUCTIONS

Work Area

1. **Keep your work area clean and well lit.** Cluttered benches and dark areas invite accidents.
2. **Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.** Power tools create sparks which may ignite the dust or fumes.
3. **Keep bystanders, children, and visitors away while operating a power tool.** Distractions can cause you to lose control.

Electrical Safety

4. **Double insulated tools are equipped with a polarized plug (one blade is wider than the other.) This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install a polarized outlet. Do not change the plug in any way.** Double insulation  eliminates the need for the three wire grounded power cord and grounded power supply system.

-
5. **Avoid body contact with grounded surfaces such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electric shock if your body is grounded.
 6. **Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.
 7. **Do not abuse the cord. Never use the cord to carry the tools or pull the plug from an outlet. Keep cord away from heat, oil, sharp edges or moving parts. Replace damaged cords immediately.** Damaged cords increase the risk of electric shock.
 8. **When operating a power tool outside, use an outdoor extension cord marked “W-A” or “W”.** These cords are rated for outdoor use and reduce the risk of electric shock.

Personal Safety

9. **Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use tool while tired or under the influence of drugs, alcohol, or medication.** A moment of inattention while operating power tools may result in serious personal injury.
10. **Dress properly. Do not wear loose clothing or jewelry. Contain long hair. Keep your hair, clothing, and gloves away from moving parts.** Loose clothes, jewelry, or long hair can be caught in moving parts.
11. **Avoid accidental starting. Be sure switch is off before plugging in.** Carrying tools with your finger on the switch or plugging in tools that have the switch on invites accidents.
12. **Remove adjusting keys or wrenches before turning the tool on.** A wrench or a key that is left attached to a rotating part of the tool may result in personal injury.
13. **Do not overreach. Keep proper footing and balance at all times.** Proper footing and balance enables better control of the tool in unexpected situations.
14. **Use safety equipment. Always wear eye protection.** Dust mask, non-skid safety shoes, hard hat, or hearing protection must be used for appropriate conditions. Ordinary eye or sun glasses are NOT eye protection.

Tool Use and Care

15. **Use clamps or other practical way to secure and support the workpiece to a stable platform.** Holding the work by hand or against your body is unstable and may lead to loss of control.
16. **Do not force tool. Use the correct tool for your application.** The correct tool will do the job better and safer at the rate for which it is designed.
17. **Do not use tool if switch does not turn it on or off.** Any tool that cannot be controlled with the switch is dangerous and must be repaired.
18. **Disconnect the plug from the power source before making any adjustments, changing accessories, or storing the tool.** Such preventive safety measures reduce the risk of starting the tool accidentally.
19. **Store idle tools out of reach of children and other untrained persons.** Tools are dangerous in the hands of untrained users.
20. **Maintain tools with care. Keep cutting tools sharp and clean.** Properly maintained tools with sharp cutting edges are less likely to bind and are easier to control.
21. **Check for misalignment or binding of moving parts, breakage of parts, and any other condition that may affect the tools operation. If damaged, have the tool serviced before using.** Many accidents are caused by poorly maintained tools.
22. **Use only accessories that are recommended by the manufacturer for your model.** Accessories that may be suitable for one tool, may become hazardous when used on another tool.

SERVICE

23. Tool service must be performed only by qualified repair personnel. Service or maintenance performed by unqualified personnel could result in a risk of injury.

24. When servicing a tool, use only identical replacement parts. Follow instructions in the Maintenance section of this manual. Use of unauthorized parts or failure to follow Maintenance instructions may create a risk of electric shock or injury.

USE PROPER EXTENSION CORD: Make sure your extension cord is in good condition. When using an extension cord, be sure to use one heavy enough to carry the current your product will draw. An undersized cord will cause a drop in line voltage resulting in loss of power and overheating. Table 1 shows the correct size to use depending on cord length and nameplate ampere rating. If in doubt, use the next heavier gage. The smaller the gage number, the heavier the cord.

Table 1: Minimum gage for cord

Ampere Rating		Volts	Total length of cord in feet			
		120 V	25 ft.	50 ft.	100 ft.	150 ft.
More Than	Not More Than	AWG				
0	6		18	16	16	14
6	10		18	16	14	12
10	12		16	16	14	12
12	16		14	12	Not Recommended	

SPECIFIC SAFETY RULES

USB042-2

DO NOT let comfort or familiarity with product (gained from repeated use) replace strict adherence to planer safety rules. If you use this tool unsafely or incorrectly, you can suffer serious personal injury.

1. Rags, cloth, cord, string and the like should never be left around the work area.

2. Avoid cutting nails. Inspect for and remove all nails from the workpiece before operation.

3. Use only sharp blades. Handle the blades very carefully.

4. Be sure the blade installation bolts are securely tightened before operation.

5. Hold the tool firmly with both hands.
6. Keep hands away from rotating parts.

7. Before using the tool on an actual workpiece, let it run for a while. Watch for vibration or wobbling that could indicate poor installation or a poorly balanced blade.

8. Make sure the blade is not contacting the workpiece before the switch is turned on.

9. Wait until the blade attains full speed before cutting.

-
- 10. Keep at least 200 mm (8") away from the tool at all times.
 - 11. Always switch off and wait for the blades to come to a complete stop before any adjusting.
 - 12. Never stick your finger into the chip chute. Chute may jam when cutting damp wood. Clean out chips with a stick.
 - 13. Do not leave the tool running. Operate the tool only when hand-held.
 - 14. When leaving the planer, switch off and set it with the front base up on a wooden block, so that the blades do not contact anything.
 - 15. Always change both blades or covers on the drum, otherwise the resulting imbalance will cause vibration and shorten tool life.
 - 16. Wait for complete run-down before putting the tool aside.
 - 17. Use only Makita blades specified in this manual.
 - 18. Some material contains chemicals which may be toxic. Take caution to prevent dust inhalation and skin contact. Follow material supplier safety data.

SAVE THESE INSTRUCTIONS

 **WARNING:**
MISUSE or failure to follow the safety rules stated in this instruction manual may cause serious personal injury.

SYMBOLS

USD201-2

The followings show the symbols used for tool.


- | | |
|--|---|
| V volts | n₀ no load speed |
| A amperes |  Class II Construction |
| Hz hertz | .../min revolutions or reciprocation per minute |
|  alternating current | |

FUNCTIONAL DESCRIPTION

⚠ CAUTION:

- Always be sure that the tool is switched off and unplugged before adjusting or checking function on the tool.

002563




1. Knob

Adjusting depth of cut

Depth of cut may be adjusted by simply turning the knob on the front of the tool.

002552



1. Lock button
2. Switch trigger

Switch action

⚠ CAUTION:

- Before plugging in the tool, always check to see that the switch trigger actuates properly and returns to the “OFF” position when released.
- Switch can be locked in “ON” position for ease of operator comfort during extended use. Apply caution when locking tool in “ON” position and maintain firm grasp on tool.

To start the tool, simply pull the switch trigger. Release the switch trigger to stop.

For continuous operation, pull the switch trigger and then push in the lock button.

To stop the tool from the locked position, pull the switch trigger fully, then release it.

ASSEMBLY

CAUTION:

- Always be sure that the tool is switched off and unplugged before carrying out any work on the tool.

Removing or installing planer blades

CAUTION:

- Tighten the blade installation bolts carefully when attaching the blades to the tool. A loose installation bolt can be dangerous. Always check to see they are tightened securely.
- Handle the blades very carefully. Use gloves or rags to protect your fingers or hands when removing or installing the blades.
- Use only the Makita wrench provided to remove or install the blades. Failure to do so may result in overtightening or insufficient tightening of the installation bolts. This could cause an injury.

To remove the blades on the drum, unscrew the five installation bolts with the hex wrench. The drum cover comes off together with the blades.

To install the blades, first clean out all chips or foreign matter adhering to the drum or blades. Use blades of the same dimensions and weight, or drum oscillation/vibration will result, causing poor planing action and, eventually, tool breakdown.


There are two adjusting screws for each blade. When installing the blade, the notch in the blade should fit over the head of the adjusting screw. Then fit on the drum cover and secure all the installation bolts only finger-tight.

Turn the drum until the blade edge is right in the middle between the front and rear bases.

Place the triangular rule flat on the rear base and run it out over and across the blade edge. Turn the two adjusting screws to adjust the blade protrusion. The blade setting should be made so that the protrusion will be uniform all the way across. Thus the triangular rule should be flush with the entire width of the blade edge. After adjusting both blades, tighten all the installation bolts evenly and alternately with the wrench.


After tightening the bolts, secure the adjusting screws fully.

002560




1. Hex wrench
2. Bolt

002561



1. Adjusting screw
2. Planer blade
3. Notch in the blade
4. Drum cover
5. Drum

002562



1. Triangular rule
2. Screwdriver

For the correct planer blade setting


Your planing surface will end up rough and uneven, unless the blade is set properly and securely. The blade must be mounted so that the cutting edge is absolutely level, that is, parallel to the surface of the rear base.

Below are some examples of proper and improper settings.

EN0004-1

- (A) Front base (Movable shoe)
(B) Rear base (Stationary shoe)

Correct setting




Although this side view cannot show it, the edges of the blades run perfectly parallel to the rear base surface.

Nicks in surface




Cause: One or both blades fails to have edge parallel to rear base line.

Gouging at start



Cause: One or both blade edges fails to protrude enough in relation to rear base line.

Gouging at end




Cause: One or both blade edges protrudes too far in relation to rear base line.

OPERATION

002578

Planing operation



1. End
2. Start

First, rest the tool front base flat upon the workpiece surface without the blades making any contact. Switch on and wait until the blades attain full speed. Then move the tool gently forward. Apply pressure on the front of tool at the start of planing, and at the back at the end of planing. Planing will be easier if you incline the workpiece in stationary fashion, so that you can plane somewhat downhill.

The speed and depth of cut determine the kind of finish. The power planer keeps cutting at a speed that will not result in jamming by chips. For rough cutting, the depth of cut can be increased, while for a good finish you should reduce the depth of cut and advance the tool more slowly.


MAINTENANCE

CAUTION:


- Always be sure that the tool is switched off and unplugged before attempting to perform inspection or maintenance.

Sharpening the planer blades

Always keep your blades sharp for the best performance possible. Use the sharpening holder to remove nicks and produce a fine edge.




1. Sharpening holder




- 1. Wing nut
- 2. Blade (A)
- 3. Blade (B)
- 4. Side (D)
- 5. Side (C)

First, loosen the two wing nuts on the holder and insert the blades (A) and (B), so that they contact the sides (C) and (D). Then tighten the wing nuts.



Immerse the dressing stone in water for 2 or 3 minutes before sharpening. Hold the holder so that the blades both contact the dressing stone for simultaneous sharpening at the same angle.

001145




1. Limit mark

Replacing carbon brushes

Remove and check the carbon brushes regularly. Replace when they wear down to the limit mark. Keep the carbon brushes clean and free to slip in the holders. Both carbon brushes should be replaced at the same time. Use only identical carbon brushes.


002595



1. Chip cover
2. Screwdriver

Use a screwdriver to remove the chip cover.

002596



1. Brush holder cap
2. Screwdriver

Use a screwdriver to remove the brush holder caps. Take out the worn carbon brushes, insert the new ones and secure the brush holder caps.

To maintain product SAFETY and RELIABILITY, repairs, any other maintenance or adjustment should be performed by Makita Authorized or Factory Service Centers, always using Makita replacement parts.

ACCESSORIES

CAUTION:

- These accessories or attachments are recommended for use with your Makita tool specified in this manual. The use of any other accessories or attachments might present a risk of injury to persons. Only use accessory or attachment for its stated purpose.

If you need any assistance for more details regarding these accessories, ask your local Makita service center.

- High-speed steel Planer blade
- Sharpening holder assembly
- Edge fence (Guide rule) set
- Dressing stone
- Triangular rule
- Hex wrench
- Wooden carrying case



Memo

Lined area for writing the memo.

Cut



First-Class
Postage
Required

Post Office will
not deliver
without proper
postage.

Makita U.S.A., Inc.
14930 Northam Street
La Mirada, CA 90638-5753



Fold

MAIL THIS PORTION

Your answers to the following questions are appreciated.

1. This product was purchased from:

- ☐ Home Center
- ☐ Hardware/Lumber Store
- ☐ Tool Distributor
- ☐ Industrial Supply
- ☐ Construction Supply
- ☐ Other ()

3. How did you learn about this product:

- ☐ Magazine
- ☐ From Dealer
- ☐ Newspaper
- ☐ Store Display
- ☐ Catalog
- ☐ Radio
- ☐ Exhibition
- ☐ From Friend
- ☐ Previous Usage
- ☐ Other ()

2. Use of the product is intended for:

- ☐ Construction Trade
- ☐ Industrial Maintenance
- ☐ Home Maintenance
- ☐ Hobby
- ☐ Other ()

4. Most favored points are:

- ☐ Design
- ☐ Features
- ☐ Size
- ☐ Price
- ☐ Makita Brand
- ☐ Repair Service
- ☐ Durability
- ☐ Power
- ☐ Other ()

5. Any comments:

DATE PURCHASED												MODEL NO.																			
MONTH				DAY				YEAR				SERIAL NO.																			
INTL.												LAST NAME / COMPANY NAME												STATUS				SEX			
																								Married Single				M F			
STREET ADDRESS																															
CITY																															
STATE				ZIP CODE								PHONE				AREA CODE															
AGE:				Under 19				20-29				30-39				40-49				50-60				Over 60							

BE SURE TO COMPLETE THE CUSTOMER'S PORTION OF THIS FORM AND RETAIN FOR YOUR RECORDS.

Please return this portion by facsimile or mail.

Facsimile No: (714) 522-8133

FACTORY SERVICE CENTERS

1-800-4-MAKITA

RETAIN THIS PORTION FOR YOUR RECORDS

ALABAMA 2365 Pelham Parkway Pelham, AL 35124 (205) 620-1791	COLORADO 11839 E. 51st Ave. Denver, CO 80239-2709 (303) 371-2850	KENTUCKY 1215 S. Hurstbourne Parkway Louisville, KY 40222 (502) 326-3740	NEW MEXICO 5805 Menaul Blvd. NE Albuquerque, NM 87110 (505) 881-4619	PUERTO RICO 200 Guayama St. Hato Rey, PR 00917 (787) 250-8776
ARIZONA 3707 E. Broadway Rd., Ste. 6 Phoenix, AZ 85040 (602) 224-2850	CONNECTICUT 508 Spring St. Windsor Locks, CT 06096 (860) 292-6405	LOUISIANA 5626 Jefferson Hwy. Harahan, LA 70123 (504) 733-4138	NEW YORK 4917 Genesee Street Cheektowaga, NY 14225 (716) 685-9503	TENNESSEE 4655 Nolensville Rd. Nashville, TN 37211 (615) 331-9922
ARKANSAS Shackelford Shopping Center 240 South Shackelford Rd., Ste. C Little Rock, AR 72211 (501) 224-5733	FLORIDA 620 Douglas Ave, Suite 1302 Altamonte Springs, FL 32714 (407) 774-6000	MARYLAND 7541 - 45 Ritchie Highway Glen Burnie, MD 21061 (410) 590-0160	131-35 31st Ave. Flushing, NY 11354 (718) 886-0971	TEXAS 12801 Stemmons Fwy Ste. 809 Farmers Branch, TX 75234 (972) 243-1150
CALIFORNIA 41850 Christy St. Fremont, CA 94538-5107 (510) 657-9881	750 East Sample Road Pompano Beach, FL 33064 (954) 781-6333	MASSACHUSETTS 232 Providence Hwy. Westwood, MA 02090 (617) 461-9754	NORTH CAROLINA 3501-G S. Tryon St. Charlotte, NC 28217 (704) 527-0611	12701 Directors Dr. Stafford, TX 77477-3701 (281) 955-8665
1421 N. Clovis Ave., Ste. 112 Fresno, CA 93727 (559) 252-5166	Thompson Center Waters 5501 W. Waters Ave., Ste. 406 Tampa, FL 33634 (813) 886-8292	MICHIGAN 37454 Ann Arbor Trail Livonia, MI 48150 (313) 432-1012	OHIO 6253 E. Main St. Columbus, OH 43213 (614) 860-0222	3453 IH-35 North, Ste. 101 San Antonio, TX 78219 (210) 228-0676
14930 Northam St. La Mirada, CA 90638-5753 (714) 522-9086	GEORGIA 4680 River Green Parkway Duluth, GA 30096-2566 (770) 476-8911	MINNESOTA 6427 Penn Ave. South Richfield, MN 55423 (612) 869-5199	6379 Pearl Road Parma Heights, OH 44130 (440) 843-7555	UTAH 145 E. 1300 S., Ste. 101 Salt Lake City, UT 84115 (801) 359-3410
1970 Fulton Avenue Sacramento, CA 95825 (916) 482-5197	HAWAII 4510 Salt Lake Blvd., Suite A7 Honolulu, HI 96818 (808) 847-0038	MISSOURI 9876 Watson Road St. Louis, MO 63126-2221 (314) 909-9889	1617 E. Kemper Rd. Sharonville, OH 45246 (513) 771-0788	VIRGINIA 5760 Northampton Blvd., Ste. 102 Virginia Beach, VA 23455 (757) 460-0280
1440 South "E" Street San Bernardino, CA 92408 (909) 885-1289	ILLINOIS 1450 Feehanville Dr. Mt. Prospect, IL 60056-6011 (847) 297-3100	NEBRASKA 4129 S. 84th St. Omaha, NE 68127 (402) 597-2925	OKLAHOMA 552 E. Memorial Road Oklahoma City, OK 73114 (405) 752-2655	WASHINGTON 22220 84th Ave. So., Bldg. A Kent, WA 98032 (253) 395-8055
7674 Clairemont Mesa Blvd. San Diego, CA 92111 (858) 278-4471	INDIANA 8403 Michigan Road, Unit 1 Indianapolis, IN 46268 (317) 334-9980	NEVADA 3375 S. Decatur Blvd. Suite 22 - 24 Las Vegas, NV 89102 (702) 368-4277	OREGON 828 18th Avenue., N.W. Portland, OR 97209 (503) 222-1823	WISCONSIN Lincoln Plaza Shopping Ctr. 2245 S. 108th St. West Allis, WI 53227 (414) 541-4776
1565 Winchester B. Campbell, CA 95008-0501 (408) 379-0377	KANSAS 8819 W. 95th St. Overland Park, KS 66212 (913) 642-1111	NEW JERSEY 251 Herrod Blvd. Dayton, NJ 08810-1539 (609) 655-1212	PENNSYLVANIA Springwater Plaza 364 Wilmington W. Chester Pike Glen Mills, PA 19342 (610) 459-4122	
16735 Satcoy St., Ste. 105 Van Nuys, CA 91406 (818) 782-2440			6200 Babcock Blvd Pittsburgh, PA 15237 (412) 366-6363	

CUSTOMER'S RECORD

When you need service: Send complete tool (prepaid) to one of the Makita Factory Service Centers listed, or to an Authorized Makita Service Center. Be sure to attach a letter to the outside of the carton detailing the problem with your tool.	Date Purchased
	Dealer's Name & Address
	Model No.
	Serial No.

WARNING

Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:

- lead from lead-based paints,
- crystalline silica from bricks and cement and other masonry products, and
- arsenic and chromium from chemically-treated lumber.

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: work in a well ventilated area, and work with approved safety equipment, such as those dust masks that are specially designed to filter out microscopic particles.

MAKITA LIMITED ONE YEAR WARRANTY

Warranty Policy

Every Makita tool is thoroughly inspected and tested before leaving the factory. It is warranted to be free of defects from workmanship and materials for the period of ONE YEAR from the date of original purchase. Should any trouble develop during this one-year period, return the COMPLETE tool, freight prepaid, to one of Makita's Factory or Authorized Service Centers. If inspection shows the trouble is caused by defective workmanship or material, Makita will repair (or at our option, replace) without charge.

This Warranty does not apply where:

- repairs have been made or attempted by others:
- repairs are required because of normal wear and tear:
- the tool has been abused, misused or improperly maintained:
- alterations have been made to the tool.

IN NO EVENT SHALL MAKITA BE LIABLE FOR ANY INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES FROM THE SALE OR USE OF THE PRODUCT. THIS DISCLAIMER APPLIES BOTH DURING AND AFTER THE TERM OF THIS WARRANTY.

MAKITA DISCLAIMS LIABILITY FOR ANY IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES OF "MERCHANTABILITY" AND "FITNESS FOR A SPECIFIC PURPOSE," AFTER THE ONE-YEAR TERM OF THIS WARRANTY.

This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

Makita Corporation
3-11-8, Sumiyoshi-cho,
Anjo, Aichi 446-8502 Japan