

Table of Contents – Tank 2.4

- Key Functions..... 3**
- Getting Started 4**
 - Installing the SIM Card, SD Card and Battery..... 4
- Menu Guide..... 6**
 - Messaging..... 6
 - Contacts 6
 - BLU Club..... 6
 - Settings..... 7
 - Call History..... 7
 - Multimedia..... 8
 - Organizer 8
 - Calculator..... 9

Phone Overview



- ✚ **Dimensions:** (H x W x D): 121.2 x 50.2 x 13.25mm
- ✚ **Camera:** VGA
- ✚ **Cable:** Micro USB
- ✚ **Battery:** Lithium-Ion
- ✚ **Rated Capacity:** 1900 mAh
- ✚ **Continuous Standby Duration:** (Relates to network status)
- ✚ Please refer to their labels for other data related to the battery and the charger

Key Functions

◆ **Dial key**

Press to place a call by entering a number or by selecting a contact from the phonebook; or press it to receive an incoming call; or press it in standby state to show the latest call records

◆ **End & Power On/Off key**

Press it to end a call being dialed or end an ongoing call; or press it to exit the menu and return to the standby state; or hold it for two or three seconds to power on or off the mobile phone.

◆ **Left and right soft key**

The bottom line on the screen displays the functions of the Left and Right soft key which display menu and submenu options.

◆ **Direction key**

Press to scroll the options when browsing a function list. In edit state, press direction keys to navigate.

◆ **OK/Selection key**

Press to confirm selection.

◆ **Number and Letters**

Press number keys 1 through 9 to input numbers and characters. Press letter keys A through Z to input letters and characters. For added convenience, you may also press the * to select symbols. You may also press the # key to change between different input methods.

Getting Started


Installing the SIM Card, SD Card and Battery

A SIM card carries useful information, including your mobile phone number, PIN (Personal Identification Number), PUK (PIN Unlocking Key), IMSI (International Mobile Subscriber Identity), network information, phonebook data, and short messaging data.


Installation

- ◆ Hold the End Key and power off the mobile phone if the phone is powered on.
- ◆ Pull the back cover and remove it.
- ◆ Pull the battery outward and remove the battery.
- ◆ Insert the SIM card into the SIM card slot ensuring that the card is properly aligned.
- ◆ The SD card is a mobile storage card that the phone may utilize to store different files. Please insert the SD card into the SD card slot for additional storage capacity.
- ◆ Insert the battery and press the battery down until it locks into place.

SIM Slot



SD Slot



Phone Lock Code

The phone lock code is a security measure that may be set to prevent your mobile phone from unauthorized use. The initial phone lock code is set to 1122 and may be changed by the user. Once the lock code is set, it will need to be inputted when powering on the mobile phone.

PIN

The PIN (Personal identification number 4 to 8 digits) code prevents your SIM card from unauthorized use. Once a PIN lock is enabled, you will need to input the PIN any time the phone is powered on. The SIM card will lock if the PIN code is inputted incorrectly three consecutive times.

To Unlock:

- Input the correct PUK to unlock the SIM card.
- Input the new PIN and press the Selection key.
- Input the new PIN again to verify and then press the Selection key.
- If the input PUK is correct, the SIM card will be unlocked and the PIN will be reset.

Note: *The SIM card will be locked if you input wrong PIN code for three times. To unlock the SIM card, you need to input the PUK. The PUK code can be obtained from the network operator.*

PUK Code

The PUK code (Personal Unlocking Number) is a security feature that locks the phone in the event of unauthorized use and will be needed in the event of the PIN code being entered incorrectly. Please contact your service provider for the PUK code. If code is entered incorrectly ten successive times, the SIM card will not be able to be used again. Please contact your service provider for a new card.

Menu Guide

Messaging

Through this feature you can create, read, or send a new message.

- ◆ **Write Message:** Access this menu to create a text message.
- ◆ **Inbox:** Received messages are listed in this location.
- ◆ **Drafts:** Drafts messages are listed in this location.
- ◆ **Outbox:** The messages which failed delivery or are temporarily stored in the Outbox.
- ◆ **Sent Messages:** Sent messages are listed in this location.
- ◆ **Broadcast Messages:** This network service enables you to receive a variety of text messages such as broadcast messages about weather forecast or road conditions. At the present time, few networks provide this service. Please consult your network operator.
- ◆ **SMS Templates:** Ten text templates can be used to create a new message.
- ◆ **Message Settings:** This function enables default settings for SMS.

Contacts

The phonebook feature allows you to store, browse, edit, and delete 200 phone numbers in the phone. Numbers can also be stored in the SIM card and the storage capacity varies depending on the SIM card.

BLU Club

- ◆ **Blu Store:** You can enter Blu store through this function.
- ◆ **Blu Club:** This function enables you to view the internet and set the default features about the network. You can log on Blu Chat, Facebook, Yahoo, Twitter and Games etc. through a web page.

Settings

- ◆ **Profiles:** The mobile phone provides multiple user profiles that may be customized to specific events and environments. Customize the user profiles according to your preference and then activate the user profiles. The user profiles fall into four selections: **General, Silent, Meeting and Outdoor**. When you insert an earpiece to the mobile phone, the mobile phone automatically enters the Headset mode. There is no option for activating the Headset mode on the screen. If you set **Call Settings » Advanced Settings » Answer Mode** to Any Key: all incoming calls will be automatically answered with any key.
- ◆ **Phone Settings:** This function allows adjustment in time, date, language, display, and other changes. **Note:** *Flight mode will suspend signal-transmitting functions – thereby disabling the device's capacity to place or receive calls or text messages. Other functions that do not require signal transmission (e.g., games, built-in camera, and MP3 player) are still available.*
- ◆ **Call Settings:** You can set caller ID, call waiting, call divert, call barring, line switching.
Advanced Settings: blacklist, auto redial, IP dial, call time reminder, answer mode
- ◆ **Network Settings:** Access this interface to set network GPRS parameters. When a network connection has been established, the phone will register with the SIM of the service provider.
- ◆ **Security Settings:** The security settings ensure the device is protected from unauthorized use.
- ◆ **Connectivity:** You can manage data accounts through this function.
- ◆ **Restore Settings:** Use this function to restore factory settings. The pre-set password is 1122.

Call History

The call center keeps record of missed calls, dialed calls and received calls.

Multimedia

- ◆ **Camera:** The phone provides a camera feature to capture pictures. In the camera interface, you may press the Selection key to take a picture and may press up or down Direction key to zoom in and zoom out. You may also press left and right to adjust exposure rate.
- ◆ **Image Viewer:** Use this feature to view pictures or images.
- ◆ **Video Recorder:** This function enables you to record video.
- ◆ **Video Player:** Use this feature to play video files.
- ◆ **Audio Player:** Use this feature to play audio files. You may control the audio player by pressing the direction keys: Play/Pause (Selection key), Previous Song/Next Song (Left and Right Direction key), Fast Forward (Long Press Right Direction key) and Rewind (Long Press Left Direction key). You may also adjust play repetition and randomize.
- ◆ **Sound Recorder:** Use this feature to record sound. The sound recorder supports .WAV and .AMR file extensions.
- ◆ **FM Radio:** You can use the phone as a traditional FM radio. In the radio interface, you may press left or right direction key to search channels automatically, press OK key to power on/off, and press * and # key to tune volume.

Organizer

- ◆ **Bluetooth:** Bluetooth can make a wireless connection to other compatible devices such as mobile phones, headsets and some mobile car kits. You can also use Bluetooth to send images, clips, notes, and transfer files. Power on Bluetooth and search and then pair the device.
- ◆ **File Manager:** You may use the file manager to conveniently manage various directories and files on the phone

and the SD card.

- ◆ **Games:** The game F1 race is embedded in the phone. For specific operation, please refer to 'help' option of the game.
- ◆ **Calendar:** This feature provides a monthly-view calendar to keep track of appointments and daily events.
- ◆ **Torch:** You can turn on/off the flashlight through this function.
- ◆ **Alarm:** Five alarm clocks are set but deactivated by default. You can activate one, multiple or all of them as needed. For each alarm clock, the ringing time can be set.
- ◆ **STK:** STK service is the tool kit of SIM card. This phone supports the service function .The specific items are depended by SIM card and network.

Calculator

To use the calculator: Press the up, down, left, right and middle key to select $+$, $-$, \times , \div , $=$ respectively.