Can I replace the battery of my Philips Sonicare Toothbrush?

The rechargeable battery inside your Philips Sonicare Toothbrush cannot be replaced.

How often can I use my Philips Sonicare toothbrush per charge?

Do you want to know the operating time of your fully charged Philips Sonicare toothbrush? Find the operating time for your Philips Sonicare tootbhrush.

Operating time for each toothbrush

Below operating times are based on a full charge and regular use (twice a day). It can take up to 24 hours before your Philips Sonicare toothbrush is fully charged. To avoid an empty battery, you can always leave your toothbrush on the charger between brushings.

Operating time from a full to empty

- DiamondClean Smart; up to 2 weeks
- DiamondClean; up to 3 weeks
- Flexcare Platinum Connected; up to 2 weeks
- Flexcare and Flexcare+; up to 3 weeks
- ProtectiveClean; up to 2 weeks
- 3 Series; up to 3 weeks
- 2 Series; up to 2 weeks
- Healthywhite+; up to 3 weeks
- Essence+; up to 10 days
- Essence; up to 2 weeks

What are the differences in modes of my Philips Sonicare Toothbrush?

Some Philips Sonicare Toothbrush models come with different brushing modes. Find out what the differences are in brushing modes.

Brushing modes

Brushing modes vary across Philips Sonicare Toothbrushes. Please refer to the user manual for the specific modes that come with your toothbrush.

The brushing modes run for different lengths of time:

- **Clean mode** has a higher frequency of vibrations in comparison to a standard mode for better cleaning. Brushing time is **2 minutes**

- **Deep Clean mode** is for extra cleaning. The unique motion of the brush head in this extended three-minute mode is more powerful than any other mode. Brushing time is **3 minutes**
- **White mode** is a two-minute clean mode, followed by a 30-second polishing mode. Brushing time is **2:30 minutes**
- **Polish mode** runs at a lower frequency of vibrations than the standard cleaning mode. Brushing time is **1 minute**
- **Gum Care mode** has a 1-minute massage cycle after the standard 2-minute clean mode to clean your gums. Brushing time is **3 minutes**
- **Gum Health mode** has an extended massage cycle after the standard 2-minute clean mode to clean your gums. Brushing time is **3:20 minutes**
- **Sensitive mode** has a lower frequency of vibrations in comparison to the standard mode. Brushing time is **2 minutes**
- **Tongue Care mode** is a 20-second mode designed to clean your tongue, together with the Tongue Care brush head. Brushing time is **20 seconds**