USER MANUAL

Remote Control LED Taper Candle

English Version User Manual

Thank you for purchasing the SoulBay LED taper candles.

Please read the instructions carefully before using, and save the manual for future use.

Packing includes

SKU	LD056	LD059
LED candles Quantity	6	9
Remote Control	1	1
Candle holders Quantity	6	9







Features

- Electric Candle gives you a realistic appearance without the smoke, fake scent or messy dripping wax.
- Lasts more than 150 hours lighting time (require 3*1.5V AAA batteries, not included), batteries can be replaced.
- Four Light Modes - Static, Fast Flicker, Slow Flicker and Flame Flicker. You can also adjust the brightness (increase or decrease).
- 4H / 6H Timer Function - 4H & 6H for your convenient use. Energy Saving!

- The remote control is built in a private-code. Therefore, it won't interfere with TV or other electrical products.
- LED Taper Candles Set is ideal for home, hotel, wedding, parties, holiday and daily table-top decorations, a great gift choice as well.

Specification

Remote Control Candle		Remote control	
Operating voltage	1.5V AAA battery* 3	Operating voltage	3V CR2025 Coin Battery
Work current	16mA	Work current	3mA
Standby current	60UA	Standby current	10uA
The working time	>150 hours	The working time	>60 days
Standby time	100 days	Remote distance	3 m-5m

Product description

Power Source:

LED Taper Candles - Requires 3 AAA batteries (LR03) (not included)

Remote Control - One CR2025 battery (included, replaceable).



How to use

***Install the candle**

1. Twist the candle bottom, put three AAA batteries inside the candle and cover the candle bottom - 【The negative electrode is down and positive electrode is up.】
2. Tighten the bottom until the candle lights up.

***Using the remote control**

1. Remove the transparent insulation sheet of remote, then you can control the candles with it.
2. The distance of Remote is 0-5 meters, 3 meters range performs best.
3. How to change the Remote battery: Open the cover on the backside of the remote and put one CR2025 battery into it. Then tighten the battery compartment.

***Remote Function**

1. Press “ON” or “OFF” button - Turn ON/ OFF the candles within 3-meter distance.
2. Press “FL” “SL” button - to set its flickering modes.
   “FLF” button - flicker like real flame.
   “Light” button - for steady brightness.
3. Press “+” or “-” button - to adjust the brightness.
4. Press “4H” or “6H” button, then enter the 4-hour or 6-hour timer function.

***Timer Function**



Press “4H / 6H” button, the candle will be set in 4 Hour/ 6 Hour Timer Mode. That means the pre-programmed timing sequence is of 4 hours/ 6 Hours on, 20 hours/ 18 Hours off, **for every 24 hours daily recycle.**

【**NOTE:** Press the “OFF” button to shut off the timer mode. If the batteries are completely drained, the “Timer” mode will be cancelled also.】

Note

- In timer mode, all the candles might not turn on or off at the same time. The slight error range is less than 2 minutes.
- The infrared beam of the remote control must be pointed directly at the candle. If you fail to turn on/off all the candles at the same time, please press the remote button again.

Important Safety Inforamtion

1. When the light becomes weak, please replace the battery soon.
2. Timer function is most recommended to use, which can help to enhance the battery life, save energy and protect our environment.
3. Recommended for indoor use. Appropriate temperature: 10℃~45℃, humidity:60-85%.
4. Remove the batteries when not in use for a long time and store lights in a cool and dry place.
5. Do not manually disassemble and install the products.
6. Do not contact the candle light with alkalis, acids, oils or corrosive liquids.

FAQ

1. When I press the “ON” key on the remote control to operate all the candles, there is one of the candles that is not bright, why?

Solution: Please be sure that the battery is working and being installed correctly, then press the “ON” button again. If it's still not bright, then the affected one(s) might be defective. Please contact us for replacement.

2. Why is the candle light not bright enough?

Solution: Please press “+” key on remote control to increase brightness. If this still didn’t work, please install a new battery.

3. Can the remote control be used for the TV?

Answer: NO.

4. The remote control does not work?

Solution: Please make sure the battery is installed correctly, if it still doesn’t work, then it might be faulty. Please contact us to get a new one.