

## Prior to installation, determine:

**1) Where the cabinet should go** (i.e., what room, proximity of an outlet, sufficient clearance: 45 inches in front of the board and 66 across on center for full range of motion, location of 16-inch on center wall STUDS on which to ANCHOR, direction door should open)

**2) How high the ironing board to be.** Adjust the cutout height accordingly. For example, we recommend 25 inches off the floor for a standard 36-38 inch high ironing surface.

For a HIGHER ironing board height, INCREASE the distance from the floor to the bottom of the cutout. *Example: 28 inches*

For a LOWER ironing board height, DECREASE the distance from the floor to the bottom of the cutout. *Example: 22 inches*

## Rough Cut

*Measure twice; cut once.*

1. Measure. Pencil sketch in your cut: 14.25 wide x 46.25 high, 25 inches above the floor (adjust +/- as desired for ironing board height). Measure again.

2. Check that sketch will end with the ironing board at the right height and the cabinet BETWEEN studs.

3. Rough cut opening into wall.

## Install Accessories

4. Install door hinges on the door (DO NOT ATTACH THE DOOR TO THE CABINET YET). Hinges will be on the RIGHT to open the door to the right; Hinges should be on the LEFT to open the door to the LEFT. Do not over tighten screws.

5. Install the accessory hook in the upper corner of the door, opposite from the hinges. The hook should be 2 inches from the top of the door and 1.5 inches from the side of the door to not interfere with the ironing board or cabinet frame.

## Installing the Cabinet into the Cutout

6. Lift the cabinet into the cutout, fitting it in bottom edge to top edge.

7. Anchor the cabinet to the wall studs by placing screws through the side of the cabinet, under the shelves.

8. Attach the cabinet door to the cabinet frame.

