

INSTRUCTIONS

1. Ensure Tub or Sink is completely empty
2. Please StopShroom directly on top of drain, as centered as possible
3. Press down on suction cup to secure in place
4. Fill Tub or Sink with water

