Installation instruction for low water pressure shower heads and handhelds

The original Fire Hydrant Spa Shower Heads and handhelds which are DESIGNED LOW WATER PRESSURE SHOWERHEAD FROM TAKE A SHOWER LLC.

Tools which are needed: Plyers and a cloth to put between piers and shower head

1. Remove the old Shower head
    a. Take your protective washcloth and turn it left (counter clockwise).
    b. Once the shower head starts to turn please you figure pressure to turn the shower head until it comes off.
2. Install the new shower head or handheld bracket (for a handheld shower head)
    a. TURN IT TO THE RIGHT after applying Teflon tape and the rubber washer which are included
    b. Finger tighten the shower head or bracket until it is snug. It should take just a little turn, with your plyers. 1/8 of a turn to snug it tight to ensure a watertight seal. Please be careful and not too tight.

Please, do not hesitate to call customer service @ 239-530-8625 or email us at info@take-a-shower.com with any questions, problems or broken parts.

Thank you, customer service