

MOUNTING YOUR POPCLIP MOUNT



Install your PopClip mount at room temperature.



Decide where you'd like to place your mount before installing - you can only mount it once!

1 extra 3M™ adhesive

Clean your chosen spot before installation.



**WILL NOT STICK
TO ARMOR ALL®!**



Let cleaned area dry before attaching your mount. Press firmly for 12 seconds.

Wait 8 hours before mounting your phone.



PopSockets LLC is not responsible for:

- Any damage to any surface caused by the use or installation of your mount.
- Any discoloration resulting from the installation and removal of your mount.



popsockets.com

REMOVING YOUR POPCLIP MOUNT



Use fishing line or dental floss in a sawing motion to cut the adhesive away from surface.



Don't reuse the adhesive.

Collapse the PopSocket grip-stand in order for the PopClip mount to properly hold the grip-stand.



NO!

YES!

**READ BEFORE
INSTALLING!**