

# Coavas Window Film Installation

## 01/

### The Most Important Tips



- \* Remove The Backing Film
- \* The More Water You Use, The Better
- \* Static Side To The Window

## 02/ Installation Steps



1 Clean Window.



2 Measure window .



3 Measure and Cut film.



4 Wet window,  
more water more better.



5 Peel off backing film .



6 Position Film  
and Squeeze out Bubbles



7 Done

## 03/ Installation Kits



Marker



Utility  
Knife



Measuring  
Tape



Squeegee



Water  
Sprayer

For more installation videos, please check the product details page.

## About Return And Refund

Please Make sure to contact the seller **FIRST** in case you need to handle the return, defect item or other issues to prevent additional shipping costs from your side.

## About Sharing



Your Product Review  
Is Biggest Support For Us.

# Customer Service

