

Coavas Window Film Installation

01/

The Most Important Tips



- * Remove The Backing Film
- * The More Water You Use, The Better
- * Static Side To The Window

❄ Please use a hair dryer to soften the film or soak the film in warm water under cold weather .

02/ Installation Steps



1 Clean Window.



2 Measure window .



3 Measure and Cut film.



4 Wet window,
more water more better.



5 Peel off backing film .



6 Position Film
and Squeeze out Bubbles



7 Done

03/ Installation Kits



Marker



Utility
Knife



Measuring
Tape



Squeegee



Water
Sprayer

❄ Please use a hair dryer to soften the film or soak the film in warm water under cold weather .

About Return And Refund

Please Make sure to contact the seller **FIRST** in case you need to handle the return, defect item or other issues to prevent additional shipping costs from your side.

About Sharing



Your Product Review
Is Biggest Support For Us.

Customer Service

