




AmazonBasics remanufactured toner cartridge replacement for Brother® TN570 high yield black



1. Press the front cover release button and open the front cover.
2. Remove the drum unit and toner cartridge assembly.




3. Push down the blue lock lever and remove the toner cartridge from the drum unit.




4. Unpack the new toner cartridge and remove the protective cover.

5. Place the new toner cartridge into the drum unit and listen for it to lock into place.



6. Clean the drum unit corona wire by gently sliding the blue tab from right to left several times.



7. Return the blue tab to its "home position" by aligning the arrows on the blue tab and cartridge.
8. Place the drum unit and toner cartridge assembly back into the printer. Close the front cover.

Need help? Go to www.amazon.com/help and click the "Contact Us" button at right.

To recycle your empty toner cartridge please go to www.amazon.com/amazonbasics for the recycling instructions.

Keep out of reach of children.