


# SoundBot®

## SB571 Quick Start Guide & User Manual

### PRODUCT FEATURE



### FEATURES



### CHARGING YOUR SPEAKER

Before the initial first use, please charge the speaker for full 6 hours

The LED indicator light will turn red when it is being charged and go off when it's fully charged.

### IN THE BOX

- SB571 Bluetooth 6W+6W Stereo Speaker
- MicroUSB Charging Cable
- 3.5mm Audio Cable
- User Guide

### PAIRING YOUR DEVICE

1. Be sure that SB571 is fully charged.
2. Turn on Bluetooth connectivity of your Bluetooth enabled media device, such as iPhone, iPad, iTablet, Smartphone, Computers...etc.and set the media device to be "visible" or "discoverable."
3. Turn on SB570 by switching the power button on the back of the speaker.
4. After turning on the SB571, the LED lights will alternate between red and blue to indicate that the speaker is in "pairing mode."
5. Choose "add new Bluetooth device" or "setup Bluetooth device" on your media player device to search for Bluetooth devices. Select SB571 to pair and connect.
6. If the pairing attempt fails or times out (roughly 3 minutes), delete all the paired devices from the paired Bluetooth devices on your media player and reboot both device before repeating pairing process from step 2 to 6 again.
7. Once paired successfully, the LED indicator lights will turn blue and blink twice every 3 seconds.
8. If pairing with another Bluetooth enabled device is required, press the Play/Pause button for 3 seconds, the speaker will be disconnected from the previous paired Bluetooth device, followed by an alert tone "paring." then you can repeat the paring process again (Steps 2-6)
9. Repeat step 2 to step 6 again to pair with the new Bluetooth enabled media player device such as tablet, smartphone, iPhone, computer,...etc.

### CONTROLLING YOUR MUSIC

Once SB570 speaker is connected to a Bluetooth enabled device, press the SKIP/PREVIOUS button to skip to the next soundtrack or play the previous soundtrack.

Press and hold the UP/DOWN button on the speaker to increase/decrease the volume on the speaker.

Press the Play/Pause button on the speaker to start or pause songs.

Tips: The A2DP compatible media device (sound source) may have another set of volume UP/DOWN control. To maximize/minimize the volume, please adjust the volume on both the media player and SB571. For none A2DP media players, volume can be adjusted from the media player.

### ANSWERING CALLS

SB571 can function as a portable speakerphone for incoming calls when connected wirelessly via Bluetooth.

- To answer a call - Press the TALK/PLAY button.
- To end a call - Press the TALK button again.
- To refuse an incoming call - Double clicking the TALK button.
- To re-dial the last number called - Double clicking the TALK button.

### USING SIRI

When the speaker is connected to an iPhone/iPad via Bluetooth, press and hold the TALK button for 3 seconds to activate the SIRI function on iPhone/iPad. Then talk to the speaker after hearing "SIRI" alert.

- Tips:
1. iPhone/iPad may not be able to recognize speech command with noisy background.
  2. SIRI may not work if iPhone/iPad is not connected to the internet.

### USING THE LINE-IN AUDIO JACK

If your media device is not Bluetooth enabled, SB571 can still be connected to SB571 via 3.5m line-in audio jack.

Tips: TALK, PLAY/ PAUSE, PREVIOUS & NEXT, only work when SB571 is connected wirelessly via Bluetooth. In case of wired connection, the soundtrack can only be controlled from the media player device.

### BATTERY STATUS ON IPHONE AND IPAD

When the speaker is connected to iPhone/iPad via Bluetooth, the battery status of the speaker can be displayed on the iPhone/iPad screen.

### SPECIFICATIONS

Dimensions: 162.5\*42.5\*63MM  
Weight: 330g (speaker only)  
Speaker Driver: stereo, 40MM, 40mm  
Speaker Output: 6W x 2  
LF diaphragm Dimension: 25\*40MM  
Signal-to-Noise Ratio: ≥80db  
Distortion: ≤0.1%  
Battery Life: Up to 12 hours (via audio input) Up to 8 hours (via Bluetooth)  
Battery Charging Voltage: 5V(500mA)  
Working Voltage: 3.3-5V  
Battery Charging Time: 3.5-4 hours  
Battery Capacity: 1000mAh  
Interface: Bluetooth, 3.5mm audio line-in jack, Micro USB charging port  
Operating Frequency Range: 2.4GHz-2.48GHz  
Bluetooth Transmission Distance: 33 feet  
Bluetooth Compliant: V3.0

### CARE AND MAINTENANCE

- Do not expose the speaker to liquid, moisture, or humidity to avoid damage to the products internal
- Do not expose the speaker to extremely high or low temperatures as this may shorten the life of the electronic device, destroy the battery, and/or distort certain plastic parts.
- Do not dispose of the speaker in fire as they circuitry may explode.
- Avoid using SB571 with sharp objects, as it may cause scratches and damages.
- Do not attempt to disassemble the speaker.

### SAFETY INSTRUCTIONS

Keep the unit away from heat sources direct sunlight, humidity, water and any other liquids. Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent electric shock, explosion and/or injury to yourself and damage to the unit.

Do not use the unit if it has been dropped or damaged in any way.

Do not puncture or disassemble the exterior surface of the product in any way.

Keep the unit free from dust, lint, .. etc. Do not use this unit for anything other than it's intended use or purpose.

Keep the product out of reach of children. Do not use the speaker at excessive volume level as it may damage hearing.

Do not expose batteries or battery pack to excessive heat, such as direct sunlight or open flame.

[www.SoundBot.com](http://www.SoundBot.com)

All trade names are registered trademarks of respective manufacturers listed. Bluetooth technology and trademark are registered property of Bluetooth SIG. All rights reserved.