



Rampage Products Light Bar Trouble Shooting Guide



Wire schematic



Testing

By connecting the wires to the light bar off of the vehicle you can ensure the bar itself is working correctly. If it works correctly during the bench test but not when plugged into the vehicle, check the connections on the vehicle or take to a qualified installer to review the wiring on the vehicle. If one function specifically is missing be sure to check the plug connections inside the vehicle plug. Clean and remove any corrosion then spray with WD40 or a dielectric grease.

***NOTE:** If the light bar has a red wire it must be connected to the + side of the battery or power supply for the other functions to work.