



Race 3 User Manual



Main Features:

1. Compact design for laptop users
2. Cherry MX switches inside
3. Arbitrary programming key-code and LED colors (Backlit only)
4. Build in 4 layers for programming
5. PBT DSA profile keycaps with Dye-Sublimated technology
6. Anodized CNC-machined aluminum case (Narrow bezel)
7. Detachable Micro USB cable

Package Content :

1. Keyboard x 1
2. Micro USB Cable x 1
3. Extra Mac & RGBY modifiers keycap

 <http://amazon.com/Vortexgear> or <https://vortexgear.us> 
 <https://amazon.ca/Vortexgear> or <https://vortexgear.ca> 



Keyboard Layout (Default):



1. Switch O.S:

- ❖ Windows: Pn + W
- ❖ Mac: Pn + M
 - Windows interchangeable with Alt
 - F1~F12 please refer to the mac keyboard layout
 - Some keys need to set their own
- ❖ Linux: Pn + L
 - Caps lock interchangeable with L_Ctrl

2. Switch Keyboard Layout:

- a) QWERTY: Fn + Home
- b) COLEMAK: Fn + PgUp
- c) DVORAK: Fn + PgDn



3. Spacebar LEDs instructions:

- a) Left side LED – Switching Layers (Fn + R_shift)
 - i. Red - Layer 1
 - ii. Green - Layer 2
 - iii. Blue - Layer 3
 - iv. None - Default
- b) Right side LED – Switching layout Windows lock
 - i. Red - COLEMAK
 - ii. Green - DVORAK
 - iii. Blue – Windows lock
 - iv. None – QWERTY (Default)

4. Other functions:

- a) Programming steps please refer to POK3R manual [<https://images-na.ssl-images-amazon.com/images/I/81HJ6x12RzL.pdf>]
- b) Reset the current layer key-codes: Fn + R
- c) Reset all layers' key-codes and restore to default: L_Alt + R_Alt
- d) Swap Fn position:

Hit Fn + L_Alt for 3 seconds then select new Fn key location directly