

Soundance®

Bluetooth Speaker User Manual

Model B5

Thank you for purchasing Soundance bluetooth speaker. Please read this manual carefully and keep it for future reference.

Features of the speaker:

1. Latest Bluetooth 4.1+ TWS (True Wireless Stereo) + EDR(Enhanced Data Rate) Technology, enables you to use two speakers pairing via Bluetooth to create a wireless dual-channel system to deliver true stereo sound effect. Data transmission is 3 times faster than last generation of Bluetooth technology, which make sure the music is played in a more stable and undistorted way.
2. Full Sound high quality speaker give you truly impressive music with detailed and transparent sound effect without distortion.
3. When used individually, the speaker can connect to up to two smart phones at the same time.
4. 3.5mm line-in jack for wired devices
5. Built-in Microphone for phone Calls. Support auto switch to phone call during Bluetooth music mode and auto switch back to music after phone call.
6. Support using your Bluetooth devices (smart phone, ipod, ipad etc) as remote

control for the speaker via Bluetooth.

Operating Instructions:

1. Charging

Connect the Micro-USB connector of the charging cable to the DC5V input socket of the speaker, and plug the USB connector of the charging cable to an external USB power supply socket with a minimum supply current of 1A. The external USB power supply can be the USB socket in your computer/laptop, the USB adaptor of most cellphone USB chargers with DC5V output, or the 5V USB port of a power socket etc.

When charging, the LED indicator next to the charge port will turn red. The red LED will turn off when the speaker is fully charged. .


2. On/Off


Slide the On/Off/TWS button to “On” position or to “TWS” position to turn on the speaker. When the speaker is used individually, please slide to “on” position. When use two speakers to create a wireless dual-channel stereo system, please slide to “TWS”. The LED indicator next to the charge port will turn blue when the speaker is on.

3. Bluetooth



1.) When speaker is used individually

- a.) Slide to power button to “on” position, the LED indicator next to charge port will turn blue.
- b.) Turn on your Bluetooth device (such as a smart phone, laptop, PDA etc) , search for Bluetooth equipment “B5”, and then pair up with the speaker. There will be voice indication from the speaker when Bluetooth connection is established.
- c.) Bluetooth music playing – You can now play the music in your Bluetooth device via Bluetooth from the speaker. Volume and track selection will




controlled from your Bluetooth device as a remote control. You can also use the  button on the speaker to play or to pause the music.

- d.) Following the instructions above, the speaker can connect to up to two Bluetooth devices at the same time when speaker is used individually.
- e.) Double press of  button can mute the speaker.

2.) TWS (True Wireless Stereo) Mode – Use two speakers to form a wireless two-channel- stereo system.

- a.) Before first use, please turn off the Bluetooth function of other Bluetooth devices near the speakers.
- b.) Slide the button to “TWS” position on the two speakers at the same time. The two speakers will then pair with each other to create a Dual-Channel-Stereo-System. After pairing, the Dual-Channel-Stereo-System will automatically assign one speaker as left channel and the other as right channel. Left channel speaker will be the speaker to receive data from your Bluetooth device.
- c.) Turn on your Bluetooth device and search for Bluetooth equipment “B5”, and then pair up with the speaker. The speaker will indicate that “second device connected” which means your Bluetooth device is also connected to the Dual-Channel-Stereo-System.
- d.) Now you can play music in your Bluetooth device from this Dual-Channel-Stereo-System and use your Bluetooth device as the remote control for volume control and track selection. You can also use the  button on the speaker to play or to pause the music.
- e.) Double press of  button of one speaker can mute that speaker.


3.) Bluetooth Phone call

When paired to your phone, and when there is an incoming call, the speaker will speak out the incoming call number. A short press of the  button will answer the incoming call. Keep pressing down the  button will reject the call. A short press of the  button during the call will terminate the call. Also, the phone answering and rejection can also be controlled from your phone paired to the speaker.

Note: Microphone is in the middle of the DC charge port and Aux Line in jack, please talk close to the microphone when making phone calls. When use two speakers on TWS mode, please talk to the microphone on the left channel speaker.

4. AUX / Line in:

Insert the audio cable into the 3.5mm jack of speaker and connect the other side to your laptop / smart phone / mp3 / mp4/CD player etc to play music file from AUX/Line in. Please note that under TWS mode, the audio cable should be inserted to the 3.5mm Aux jack of the left channel speaker.

5. **Color light** – When playing music, three color lights inside the speaker will be on and flashing. If you wish to turn off the lights, just keep pressing down the  button for two seconds to turn it off.

6. Technical data

Power	High capacity Li battery	
	External USB 5V supply	
	Working voltage : 3.4V-4.2V	
	Charging voltage: 5V 1000mA	
Technical	Frequency	80HZ-20KHZ
	SNR	≥90db
	Sensitivity Rate	85db
	THD	0.3%
	Speaker	Φ45mm 4 Ω 3w 16 strands
Speaker Size	58*58*58mm(2.3*2.3*2.3 inches)	
Bluetooth Range	Up to 15 meters (50feet)	

Note: when power is low, sound quality will be affected. To avoid this regularly keep speaker charged to maintain best sound quality.

Trouble shooting:

1. Can't turn the speaker on:

Check if the battery is in low. Recharge and then try to turn on again. The

2. Can't charge the speaker:


Check the power supply is working and that the output of the power supply to the charge cable is 5V and > 1A.

Check that the charge cable and connectors of the cable are not damaged.

3. No sound:

Check the speaker is paired with the right Bluetooth device. If not, disconnect the Bluetooth connection and pair again to the right device.

Check the Bluetooth device's volume setting.

Check if the speaker is muted. Double press of  button to unmute the speaker.

Warning:

1. Do not use the product in high temperatures. Always keep the product away from fire. For your own safety, never throw the product into a fire which may cause an explosion and personal injury.
2. Do not use the product close to high-voltage wires or electronic equipment.
3. Keep the speaker away from water, and avoid using the speaker in high-humidity environments.
4. Keep the speaker away from any strong magnetic fields.

Support:

If you have any questions or problems in using the speaker, please feel free to write to: Victormobile@126.com

