

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING. KEEP AWAY FROM WATER.

DANGER - Any appliance is electrically live even when the switch is off. To reduce the risk of death by electric shock:

1. **Always unplug appliance immediately after using.**
2. Do not use while bathing or in the shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in, or drop into, water or any other liquid.
5. If an appliance falls into water, unplug it immediately. **Do not reach into the water.**

WARNING - To reduce the risk of burns, electrocution, fire, or injury to persons:

1. **This appliance should never be left unattended when plugged in.**
2. **Do not pull, twist, or wrap line cord around appliance.**
3. This appliance should not be used by, on, or near children or individuals with certain disabilities.
4. Use this appliance only for its intended use, as described in this manual. Do not use attachments not recommended by the manufacturer.

5. **Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to an authorized service center for examination and repair.**

6. Keep the cord away from heated surfaces.
7. Never use while sleeping.
8. Never drop or insert any object into any opening.
9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
10. Do not use an extension cord with this appliance.
11. This appliance is hot when in use. Do not let heated surfaces touch eyes or skin.
12. **Do not place the appliance on any surface while it is operating.**
13. **Do not touch hot surfaces of the appliance; use handles or knobs.**

SAVE THESE INSTRUCTIONS

OPERATING INSTRUCTIONS

This appliance is intended for professional use. Use on Alternating Current (60 Hz) only. Standard appliances are designed to operate at 120 volts AC.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

IMPORTANT NOTICE

These styling appliances have a special protective application and the barrel will be extremely hot when the temperature regulator dial is set at its highest setting (50). Extra care should be taken when using. This product may emit smoke during initial use. The smoke is not harmful and will quickly disappear. It is only the protective application on the heating element being burned off.

SUPER STYLING GUIDE

Your best looks begin with a good haircut that's well maintained. Always treat hair right with superior quality shampoos, conditioners, and finishing products.

FOR TOUSLED HAIR

Create soft, tousled waves by curling each hair section in a random direction. Then turn head upside down, shake, and gently scrunch hair with fingers. Bring head back to position and repeat for fullest volume.

FOR WIDE WAVES

Pick up a section of hair and place the curling iron under it close to the scalp, making a half turn downward. Remove the

curling iron. Working with the same hair section, start where you left off and place the curling iron on top of the hair, curling it up a half turn. Proceed down the same hair section, alternating the curl upward and downward. Repeat procedure with remaining sections of hair. For best results, hair should be about 6–8 inches long.

CURLING IRON BASICS

1. Plug the appliance into a standard electrical outlet (120V).
2. Position the temperature regulator dial to the setting that is appropriate for your hair type. You can use the chart outlined below as a reference. The iron will heat up very quickly.

TEMPERATURE SETTINGS	HAIR TYPE
1–10 (250°F–275°F)	Fragile, very fine hair
11–20 (276°F–310°F)	Thin, easy-to-curl hair
21–30 (311°F–360°F)	Normal textured hair
31–40 (361°F–390°F)	Wavy or curly hair
41–50 (391°F–450°F)	Coarse, very thick hair


3. Section hair evenly, and comb each section before winding. Place curling iron midway up the hair section, then spread hair evenly between spoon and barrel. To avoid crimped ends, make sure they are securely wound under the spoon in the direction of the desired curl.
4. Wind the hair up as far as you want it curled, being careful not to let the iron touch the scalp. Hold in place for 8–12 seconds. For looser, free-flowing curls, roll more hair. For tighter, bouncier curls, roll less hair.
5. To remove curling iron, unwind the hair. To set the curl, do not comb or brush hair until it cools.
6. Some experimenting is necessary when first using the curling iron or when changing to a different hairstyle.

NANO TITANIUM

Your Nano Titanium™ curling iron has many benefits. Nano titanium is an exceptional conductor of heat and is stable in ultra-high temperatures. The Nano titanium barrel combines the technology of micro particles of titanium, providing the ultimate heat performance for beautiful, healthy hair. Nano titanium yields maximum far-infrared heat, penetrating the hair from within for gentle styling without damaging hair. Nano titanium emits negative ions for faster styling, locking in hair's own natural moisture. This Nano titanium iron will give your hair a smooth, silky shine while eliminating frizz.

SOL-GEL TECHNOLOGY

The Sol-Gel technique is a delicate, precisely controlled lab process that transforms nanoscale particles of titanium and ceramic from a liquid (SOL) to a solid (GEL) form, resulting in a much higher concentration of titanium and ceramic (more than 65%, vs. less than 15% on conventional barrel coatings). The titanium ceramic coating is 37% harder (longer lasting and chip resistant), less porous (chemically resistant) and 22% smoother (reduces friction and helps preserve the integrity of the hair).



USER MAINTENANCE

Your iron is virtually maintenance-free. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow to cool and wipe exterior with a cloth. If any abnormal condition occurs, unplug the unit, allow it to cool, and return it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

CAUTION



NEVER allow the power supply cord to be pulled or twisted. Never wrap the cord around the unit. Damage will occur at the high flex point of entry into the unit, causing it to rupture and short circuit. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

NOTICE

THIS PRODUCT IS EQUIPPED WITH AN INSTANT HEAT CIRCUITRY. STATE-OF-THE-ART TECHNOLOGY ALLOWS THE HEATER TO REACH THE OPERATING TEMPERATURE IN LESS THAN ONE MINUTE. DO NOT LEAVE PRODUCT ON OR PLUGGED IN WHILE NOT IN USE. UNIT WILL BURN OUT IF POWER IS KEPT ON FOR AN EXTENDED PERIOD OF TIME. WARRANTY WILL BE VOIDED. TURN UNIT OFF AND UNPLUG WHEN NOT IN USE.

STORAGE

When not in use, your appliance is easy to store. Allow unit to cool, then simply put back in the box and store out of reach of children in safe, dry location. Do not jerk or strain cord at plug connections.



LIMITED 2-YEAR WARRANTY

BaByliss®PRO will repair or replace (at our option) your unit free of charge for 24 months from the date of purchase if the appliance is defective in any workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed, together with your purchase receipt and \$15.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-326-6247 for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 24 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 24-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL BABYLISS®PRO BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. Some states do not allow the exclusion or limitation of special,

incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

SERVICE CENTER

BaByliss®PRO
Service Department
7475 N. Glen Harbor Blvd.
Glendale, AZ 85307

©2010 BaByliss®PRO

10BA115477

IB-10252

Para su seguridad y para seguir disfrutando de este producto durante años, siempre lea las instrucciones cuidadosamente antes de usarlo.

BaByliss®PRO

Nano Titanium™

TENACILLAS DE RIZAR PROFESIONALES

Modelos BABNT75S, BABNT100S, BABNT125S, BABNT125S

PARA USO PROFESIONAL ÚNICAMENTE