











# Assembly Instruction

ITEM NO. 18401-3SC

## REVERSIBLE SOFA CHAISE W/2 PILLOWS


**NOTE: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.**

### COMPONENT LIST

NO.	DRAWING	QTY	DESCRIPTION
A		3	BACK CUSHION
B		1	SOFA FRAME
C		1	OTTOMAN FRAME
D		1	CHAISE SEAT CUSHION
E		2	SEAT CUSHION
F		2	PILLOWS
G		8	GASKET
H		8	BUN FEET

Please follow the drawings below to assemble the item.

**Step 1.** Assemble the gaskets and bun feet to the bottom of the sofa and chaise then rotate the bun feet in order to tighten it



**Step 2. Completed**



### **CARE INSTRUCTION FOR PU AND LINE-LIKE FURNITURE:**

In order to maintain the original appearance of your PU and LINE-LIKE furniture, please follow below care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and / or exposure to heating and air conditioning outlets will fade/damage PU and LINE-LIKE. Do not place your upholstered furniture too close to windows, radiators, or vents, and be sure to use window treatments to block the sun's rays.
- Vacuum or wipe with a soft brush to remove dust.
- Clean fabric PU and LINE-LIKE with professional cleanser.