



# CAM LINK

UNLEASH YOUR CAMERA



## SUPPORTED CAMERAS

While Cam Link can capture any HDMI input, it's best to verify your camera's compatibility. Below you'll find a list of cameras that we, and creators like you, have tested.

CANON	GOPRO	NIKON	PANASONIC	SONY
<ul style="list-style-type: none"> <li>▲ EOS 5D Mark III</li> <li>▲ EOS 600D</li> <li>▲ EOS 650D</li> <li>✗ EOS 6D</li> <li>✗ EOS 70D</li> <li>✗ EOS M10</li> <li>▲ EOS Rebel SL1</li> <li>✓ EOS Rebel SL2</li> <li>✗ EOS Rebel T3i</li> <li>✓ Legria HF R806</li> <li>✗ Powershot G7 X Mark II</li> <li>✓ VIXIA HF G30</li> <li>✓ VIXIA HF G40</li> <li>✓ VIXIA HF R700</li> <li>✓ VIXIA HF R800</li> </ul>	<ul style="list-style-type: none"> <li>✓ HERO3+ Silver</li> <li>✓ HERO3 White</li> <li>✓ HERO4</li> <li>✓ HERO5 Black</li> <li>✓ HERO6 Black</li> </ul>	<ul style="list-style-type: none"> <li>▲ D5100</li> <li>✗ D7100</li> <li>✓ D750</li> </ul>	<ul style="list-style-type: none"> <li>✓ HC-V770</li> <li>✓ Lumix DC-GH5</li> <li>✓ Lumix DMC-G7</li> <li>✓ Lumix DMC-GH4</li> </ul>	<ul style="list-style-type: none"> <li>✓ A5100</li> <li>✓ A6000</li> <li>✓ A6300</li> <li>✓ A7</li> <li>✓ A7s II</li> <li>✓ Cyber-shot RX100 V</li> <li>✓ DSC-RX100M4</li> <li>✓ FDR-AX33</li> <li>✗ RX100 IV</li> </ul>

**NOTE:** Just because your camera is not on this list does not mean it doesn't work with Cam Link, only that we have not tested compatibility yet. You can easily test whether your camera is supported by following a few quick steps detailed in this video: [www.youtube.com/watch?v=o6KsYpEPoss](https://www.youtube.com/watch?v=o6KsYpEPoss)

Find more information:

[www.elgato.com/gaming/cam-link/camera-check](http://www.elgato.com/gaming/cam-link/camera-check)

✓ = This camera is fully compatible with Elgato Cam Link.

▲ = This camera has limited compatibility with Elgato Cam Link with regards to maximum resolution or continuous video output.

✗ = This camera is not compatible with Elgato Cam Link.