



## **GP-68 Digital Thermometer**

**Thank you for choosing our product! We invite you to spend a few minutes to read the user instructions before first use.**

The package includes a new **upgraded** version of the digital thermometer with a set of new and improved features:

- Water proof - It can survive an accidentally fall into water.
- A comfort handle grip for better handling.
- Large Bright LCD with Backlit light that is automatically turned off.
- Can be re-calibrated when needed using a simple procedure.
- Enabling Vertical attachment to refrigerator or other elements which consists a magnet using an internal magnet.
- Hold temperature function to stop the display from changing the readout.
- Min/Max temperature record.
- Auto-off: The unit will automatically turn off after 10 minutes if no other buttons are pressed keep battery life.
- °F/°C switchable using a push button.
- Display resolution: 0.1°C.
- Measurement range: -50°C ~300°C ( -58°F ~572°F ) .
- Measurement accuracy:  $\pm 1^{\circ}\text{C}$  at -20°C ~200°C and  $\pm 2^{\circ}\text{C}$  at the other ranges.

### **Operation:**

\*\* The GP-68 digital thermometers comes pre-calibrated though, it is recommended to calibrate the thermometer before first use according to the **Ice-Water method**. It is possible anytime afterwards to re-calibrate in case of inaccuracy in measurements. To calibrate the temperature, please insert the probe into a glass full of ice and water and hold down the “hold” key for 5 seconds. After 5 seconds, the display will show “CAL” on the screen. Use the C/F key to increase the digit or the “HOLD” key to decrease the digit until you reach 0°C or 32°F. After several seconds the display will show again the reading temperature.

1. Before using the thermometer, please pill-off the protected film from the front panel.
2. To start the measurement, unfold the probe from its housing and the LCD will immediately display the temperature.
3. The default display units are Fahrenheit. If you are willing to change it to Celsius, please push the C/F key.
3. Data-hold: Before withdrawing from food, press “HOLD” key. This will hold the temperature reading until pressed again.
5. To display the minimum or the maximum temperature, push the “HOLD” key for 3 seconds. It will firstly display the saved maximum temperature. By clicking again the “HOLD” key, the display will show the minimum saved temperature.

To enable light on the screen, press the light button. It will turn off after several seconds.

### **Warnings and precautions!**

**DO NOT LEAVE THE THERMOMETER IN THE OVEN WHILE COOKING.**

**DO NOT TOUCH HOT PROBE WITH BARE HANDS.**

Wash the metal probe in soapy water.

Clean the thermometer by hand or using water.

Do not completely immerse the digital thermometer in water for minutes.

Sterilize the metal probe by inserting it into a boiling water for several minutes.