

Installation Instructions

1. LOOSEN OR REMOVE BATTERY. HOLD DOWN BOLTS.
2. WASH OFF SIDES OF BATTERY – WIPE DRY.
3. WRAP BLANKET AROUND BATTERY, PULL TIGHT AT CORNERS, AND TIE WITH TAPES PROVIDED
4. TIGHTEN BATTERY HOLD – DOWNS.
5. RUN CORD TO FRONT GRILLE, TAPING WHERE NECESSARY.

WARNING: KEEP PRINTED SIDE OUT. DO NOT OVERLAP AND ENERGIZE ONLY WHEN APPLIED TO BATTERY.

DO NOT OPERATE WHEN OUTSIDE AIR TEMPERATURE IS ABOVE FREEZING (32° F / 0° C)