

User Manual

GT08 Smartwatch


Thank you for choosing this product. Please read this manual before using.

Before first use:

- The watch should be charged for 2 hours at least before first use. This device can connect to the USB port of a desktop or a laptop for charging. If you use a power adapter, the adapter should be 5V, 1A.
- The battery may have been dislocated during transportation/ use – remove battery and replace again. The battery is under the back cover of the watch together with the SIM and media card slots.

1. Product details:

1.1 Product details



HOME button: Power On/Off ; Awaken/turn off screen ; Back to main menu

USB port:Charging/Data ;

Touch screen: each function (main menu) will be shown and displayed on capacitive touch screen.

1.2 Products quick into

You can enter into next page by sliding screen to the left, and return to last page by sliding screen to the right; enter into the notice board after sliding from up to down, and return to main mean from down to up. The screen will not change if the drag distance is too short.

1.3 Clock Display




Setting method :

Method 1: Power on, when the phone is in clock mode, click the middle screen and set different clock interfaces of your choice.

Method 2:Power on, Main menu: setting--phone setting--standby menu display --unlock selection, choose the clock mode of your choice.

1.4 Product theme settings



Florid

Colorful

Classics

Setting method:

Main menu : Theme setting, choose the theme of your choice.

2. Product quick use

2.1 Download the Sync software (BT Notification).

- Scan QR code at the phone ,down load the APP which can match your android phone. This APP can only be used for the Sync between watch and phone, it does provide GPRS.

- If you have already downloaded the related software, please check the version and use the newest related software in order to ensure all function normal use. Please update the software when there is a new one.

2.2 Install and use the Sync software


Android Application installation :

Please install the android application in your smart phone. You can store it into your phone memory or install by Sync assistant.

Android application usage (already installed)

(Smart phone) Setting -- Accessibility—Enter into Bluetooth screen, enable this service. (please choose “OK” when shown a warning notice) . The application runs on

the background automatically and sync function will be switched on as below:



Click the Bluetooth notices and choose the Notification service, select your Personal or System application in Notify application.

Telephone service is including SMS, incoming call and seek watch.

Notice :

Please don't shut the Bluetooth notify service when you are clearing software by background or close background application software. It will affect the Sync function between watch and phone if shut it.

2.3 Bluetooth Connection and Sync function

2.3.1 From phone to watch

Phone setting—turn on the Bluetooth --search for devices , please click pair devices

when found GT08, choose ‘yes’ in your mobile phone, the pairing will be done.

Please choose “OK” when there is phone book request. You may also choose ‘do not remind again’, so that you are not asked again if you want to sync the phone book when you connect next time.

Notice: The Sync software can open in sync APP already installed and Accessibility, the mobile will show Bluetooth connected done after 2-5min; the watch will inform you the time of Sync with phone, than the Sync will be switched on. The message will sync to you watch when it is received to mobile .

2.3.2 From watch to phone

BT Dialer on GT08 —search new device—found your smart phone - connect. The next steps are the same as in 2.3.1

2.4 Base function

2.4.1 Messages (texts)

Sync phone or watch messages.

2.4.2 Bluetooth

Sets the Bluetooth status, turn on/off.

2.4.3 Calls records

You can check your phone call records after you connect the watch with the Bluetooth.

Showing all records including missed call, dialed calls and received calls. You can check the date, time and phone number of the missed call after you choose it, and you can call this number.

2.4.4 BT dialer

Paired devices from smart watch

2.4.5 Remote notifier

When there is an incoming message (SMS) on the connected phone, the smart watch will alert you to read them.

2.4.6 Remote camera

Use phone camera to take photos remotely via the watch. You need to switch on the camera of the phone in advance.

2.4.7Anti lost

Watch seek phone, or phone seek watch.

2.4.8 Settings

Notice: sets clocks display and theme in phone setting. In the security Settings, the safe code is 1122.

2.4.9 Pedometer

It can be used as a tool to avoid insufficient or excessive exercise by measuring calories or calories consumption based on collected data, such as number of steps, distance, time to control exercise.

If you want to return to the main menu but keep the pedometer running during the exercise, please press the power button.

2.4.10 Sleep monitor

Shows your sleep quality based on your sleep times.

2.4.11 Sedentary remind

You can set a time to remind you up to do some exercise.

2.4.12 Quick response

The watch can download sync software when you scan the quick response.

2.4.13 Smart search

Search information about watch

2.4.14 Alarm

2.4.15 Calendar

2.4.16 Calculator

2.4.17 Profiles

2.4.18 File manager

2.4.19 Audio player

Can play music from the smart phone after connecting the watch with the Bluetooth.

2.4.20 Theme setting

2.4.21 Camera

2.4.22 Video recorder

2.4.23 Image viewer

2.4.24 Video player

2.4.25 Sounder recorder

2.4.26 Phone QQ

To use the QQ function need to insert a SIM card into your watch and then you will be able to browse the Internet.

2.4.27 Browser

To use the Browser function need to insert a SIM card into your watch and then you will

be able to browse the Internet.

SIM tool

3. Notice

3.1 Fully charge before use, the charge time needed is 1-2 hours.

3.2 Use the accessories cable and charger, or your android phone accessories .

3.3 Bluetooth will disconnect when you exceed certain distance (2-3 meters), the smart search function can't be used before reconnecting with Bluetooth.

3.4 Please reconnect with BT if the watch is disconnected occasionally (please Manual connect if the Bluetooth is disconnected for more than 5 minutes) . Once connected again, sync the phone book again to see any missed/ received calls.

3.5 When playing music, some of the music's name can be shown and some can't, this is normal and depends on the different android phone used.

4. Common trouble shooting

Please refer below for solutions to main problems with the watch, if the problem is still unsolved, please contact the seller.

4.1. Unable to switch on

The time of pressing the power button is too short, please keep it more than 3 seconds.

Low power, please charge the watch.

Battery may have been dislocated during transportation/ use – remove battery and replace again. The battery is under the back cover of the watch together with the SIM and media card slots.

4.2. Watch is shutting down automatically

Low power, please charge the watch

4.3. Usage time too short.

Battery is not full, please make sure it is full power(full charge need 2hours at least).

During the use of SIM card, the power will be run off sooner if the signal is poor.

4.4. Unable to charge.

The battery's life will be reduced after few years, please check if the battery is work.

Change to a new charger if it is unworkable.

Please check if the USB slot is connecting well, if no, please try again.

4.5. No caller's name when incoming call

Forgot to choose upload the phone book when connected with BT, or unselected keep upload the phone book.

Forgot to sync the phone book when reconnected, please pair the device and connect BT again.

4.6. Bad phone call voice.

Watch and phone are separated too far, please get closer ;Bad signal of BT.

Bad signal of your own phone call, please change to a better signal location.