

Care and Use: Lunch Kits

Please follow these simple tips to get the maximum performance and satisfaction from your THERMOS® brand product. Used according to our instructions, it will give you years of trouble-free enjoyment.

CAUTION

- For best results, wipe interior and exterior with damp sponge and mild soap after each use.
- For drying, use soft towel or air dry.
- **DO NOT** submerge entire box in water while cleaning.
- **DO NOT** use abrasive cleaners or cloths.
- **DO NOT** wash in a dishwasher.
- **DO NOT** place lunch box in a microwave or any type of oven or on or near other heat source which may damage the product. Plastic can melt and burn.
- **DO NOT** place in a freezer.
- Not intended for use by children under 3 years of age.

CONTAINER CARE & USE (on selected models)

- Wash bottle and lid thoroughly after each use with warm soapy water and rinse with clear, warm water.
- For drying, use soft towel or air dry.
- Dishwasher safe on the top shelf only.
- **DO NOT** place in a microwave or any type of oven or on or near other heat source which may damage the product. Plastic can melt and burn.
- **DO NOT** put carbonated beverages in the bottle.
- **DO NOT** put hot beverages or food in the bottle.
- Dairy or other food products that spoil easily should not be kept in the bottle for prolonged periods.

CARE & USE (on selected models)

- Dishwasher safe on the top shelf only.
- Remove lid prior to placing container in the microwave.
- **DO NOT** place in oven or on or near other heat source which may damage the product. Plastic can melt and burn.

YEAR LIMITED WARRANTY

Thermos L.L.C. warrants this genuine Thermos® brand lunch kit to be free from defects in material or workmanship for a period of one year from the date of original purchase. Any problem that is caused by abuse or negligence is not covered. Normal wear and color fading are not covered. Thermos' sole obligation under this warranty and any implied warranty is limited to

the repair or replacement, at Thermos' option, of any component that fails to conform to this warranty within 30 days after its receipt by our factory service department. **IN NO EVENT WILL THERMOS BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES.** Some states do not allow the exclusion of incidental, consequential or special damages, so the proceeding exclusion may not apply to you. This is a factory guarantee. Please do not return this lunch kit to the retailer. Send defective unit or component along with written explanation of defect directly to:

In USA, by mail

Thermos Customer Service
355 Thermos Road
Batesville, MS 38606 USA
1-800-831-9242
www.thermos.com

In Canada:

Canadian Thermos Products Inc. - Warranty Service
355 Thermos Road
Batesville, MS 38606 USA
1-800-831-9242
www.thermos.com

or, call Customer Service:

In the USA: 1-800-831-9242
Ou appeler le Service à la clientèle:
Au Canada 1-800-669-7065

This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.