




250 PSI Tire Inflator Gauge



Instructions

Use the Etekcity Tire Inflator Gauge to inflate tires to the optimal pressure level.

Inflate Tires Using an Air Compressor

- Thread one of the NPT connectors to the bottom of the tire gauge.
- Connect the Etekcity Inflator Gauge to an air compressor using the NPT connector.
- Press the Air Bleed Valve/Reset Button to ensure the gauge is set to Zero.
- Connect an Air Chuck to the rubber hose. Use the chuck to connect to the tire valve.
- Fill by pressing the Valve Controller to desired pressure level.
- Release excess air using the Air Bleed Valve/Reset Button.

Specifications

- Inflation Range: 0-250 PSI
- Accuracy: $\pm 1\%$
- Display Resolution: 0.1 PSI Display
- Type: Backlit LCD
- Measurement Units: PSI, KPA, Bar, Kg/cm²
- Compatibility: NPT air compressor connector

Package Contents

- 1 x Etekcity Tire Inflator Gauge
- 1 x User Manual
- 4 x Valve Caps
- 1x Twist-on Air Chuck 1 x Brass Air Chuck
- 2x AAA Batteries
- 1 x 1/4" NPT Steel Fitting 1 x Valve core tool
- 1 x Thread Seal Tape Roll 1 x Twist-on Air Chuck


Questions or Concerns? (855) 686-3835 • support@etekcity.com



Know Your Tire Inflator Gauge

Inflator Gauge Diagram

- | | |
|---------------------------------|--------------------------------|
| 1 Valve Controller | 5 Interchangeable Brass Chucks |
| 2 Air Bleed Valve/Reset Button | 6 18" Rubber Hose |
| 3 NPT Male End | 7 Digital Gauge Display |
| 4 NPT Threaded Female Connector | 8 Battery Compartment |



Helpful Hints

In order to get a strong seal, place the nozzle directly onto the tire valve. Putting the gauge on the nozzle from an angle could result in an inaccurate reading. Once the gauge is placed, firmly press the gauge straight down.

1 Year Warranty by Etekcity

Etekcity warrants all products to be of the highest quality in material, craftsmanship and service for a minimum of 1 year, effective from the date of purchase. Should you encounter any issues or have any questions regarding your new product, feel free to contact our helpful Customer Support Team. Your satisfaction is ours!

TEL: (855) 686-3835
Email: support@etekcity.com

