



## Important Information on how to connect your LAVA HDTV Antenna

Thanks for choosing our HDTV Antenna. This is the most easiest installation remote controlled HDTV antenna in the market. It is just plug and play.

Please read this guide before you install your antenna.

1. Open the box and assemble the antenna as the instruction manual.
2. Test the Antenna Rotation function inside your house before you put the antenna outside. If there is problem to test the antenna rotation, stop here and call customer service for support.
3. **Please connect the cable from the Antenna outside to the control box inside your house directly. DO NOT use a switch or splitter in the connection.**

If you need to connect through the cable outlet on the wall, please make sure there is no splitter in the connection. Check where the cable box in your house locate, use a F-F coupler to connect the cable from the Antenna to the cable run into your room directly.

### **What you need to know after you connect your Antenna?**

After you connect your Antenna to the TV, refer to your TV instruction on how to set up the single source to Air/Antenna type and scan the digital channels.

If you are using a digital converter box, please refer to the instruction for the converter box to scan the channels.

For most of the HDTV today, you will need to set up the signal source correctly in order to get the digital channels.

You can go to your TV menu and find the setting or installation option. Set up the signal source to AIR/Antenna.

After you set up the signal source, go to Channel scan or Channel manage to scan the digital channels. This process will usually take 5-10 minutes to finish. You will be able to see the Channels count during the scan process.

If the Antenna power on OK there should be no problem for the reception.

For technical support please contact your seller or

LaVa Electronics Inc.  
2580 E Philadelphia St. STE E  
Ontario, CA 91761  
Tel: 909-923-8743  
E-mail: support@lavasat.com