




Thank you for your purchase! This is a cutting edge product that uses 3440 x 1440 display resolution, which not everyone is familiar with. Should your display not look right, you may need to manually change the display resolution.


The correct screen resolution settings on your computer will make images sharper and avoid a distorted, stretched out picture. While Windows and Apple have their own set default scaling settings and colors for each display, which are usually the best for your system, you can always adjust manually it if something doesn't look right.

Change Screen Resolution on Windows 10

Go to your Desktop, right-click your mouse and go to **Display Settings**.




The following panel will open. Here you can adjust the size of text, apps, and other items and also change the orientation. To change the resolution settings, scroll down this window and click on Advanced Display Settings.



Select 3440 X 1440 screen resolution from the drop down menu and click Apply.

Change Screen Resolution on Mac OS

Go to System Preferences and click on **Displays**



If **Resolution** is set to **Default for display**, click on **Scaled**, then select the 3440 x 1440 option.



Should you have any questions, our tech support is happy to help! Give us a call at

[1-855-229-9472](tel:1-855-229-9472)

Or visit us on the web at

<https://viotek.com/contact/>