

1

Introduction

Thank you for purchasing our battery powered Heated Socks. To ensure proper use and care of your Heated Socks and our Mobile Warming batteries please read this user manual prior to use.

Includes

- One - Pair of Ultra-light weight antimicrobial heated socks
- Two - 3.7V 2200 mAh Lithium-ion batteries (Model#MW-370)
- One - 4.2v Dual AC battery charger (Model# ASA16U08)

WARNING

- Only use the MW battery(s) provided with garment(s).
- Do not attempt to disassemble or alter any part of this garment.
- Do not store MW battery(s) below -4F(-20°C).
- Do not allow MW batteries or charger to come in contact with water or other liquids. If water or other liquids enter the battery interior immediately unplug the garment from the battery. Continued use of the garment may result in fire or electrical shock.
- Do not place this garment near a heat source or expose battery(s) to direct flame or heat as the battery(s) may explode.
- Disconnect MW battery pack from the garment(s) when not in use.
- Garment(s) will discharge battery even when power is off.

3

CHARGING INSTRUCTIONS

To ensure the best battery performance and a long battery life follow these steps.

Step 1- Plug the charger into a properly rated AC outlet (110v-220v).

Charger Plug

Step 2- Plug the charger output cable into the battery(s) charging port(s).



Note: Power indicator LED lights will flash through all 3 lights when charging.

When fully charged all 3 indicator lights will glow solid Green.

Battery Port

CARE WARNINGS

- Always disconnect and remove MW battery(s) from the garment(s) power lead wiring harness.
- Do not machine tumble dry, iron, or dry clean.
- Do not wring out the garment(s) as this may cause damage to the heating elements and or wire harness.
- Do not fully submerge in water or other liquids.

5

WASH INSTRUCTIONS



- To wash, disconnect the battery(s) from the power lead/wire harness, and remove battery from garment(s).
- Hand wash only, Wipe down with a wet cloth and mild detergent.
- Lay flat air dry only. Do not machine dry.

LIMITED TWO (2) YEAR WARRANTY

Our warranty applies only to the original purchaser and only for items purchased from an authorized Mobile Warming Dealer or thru our on-line store www.mobilewarming.com

When you purchase a Mobile Warming brand product from an authorized Mobile Warming dealer within the United States both the construction and electrical heating components of the product are warranted to be completely free from factory defects in materials and workmanship for two (2) years from the date of purchase. If any failure in the construction or the heating function of any Mobile Warming product purchased from an authorized Mobile Warming dealer within the United States occurs due to the manufacturer's defect within two (2) years of the purchase of the product, the product will be repaired at no charge.*

2

PAIRING INSTRUCTIONS

Note: Socks are pre-paired from the factory and are ready to use out of the box. Sometimes you may need to re-pair the socks with the wireless controller do the following:

Step 1- Simultaneously Press and Hold "Power" button on Battery and Press and Hold "single dot" button on wireless controller for 3 seconds.



Step 2- Battery indicator light will light up after successful pairing then Release both buttons.



TEMPERATURE CONTROL



	100%	65%	25%
Power Level	100%	65%	25%
Temperature	136°F (57.7°C)	116°F (46.6°C)	116°F (36.6°C)
Battery Life	4.0Hrs	6.0Hrs	11.0Hrs

NOTE: TEMPERATURE RATINGS WILL VARY BASED ON THERMAL QUALITY OF FOOTWEAR WORN.

4

- Please charge the battery fully before use.
- If problems with the battery occurs refer to caution label marked on battery case or contact us at www.mobilewarming.com

LITHIUM-ION BATTERY



Model #: MW-370
Rating: 3.7V 2200mAh
Input: DC 4.2V 1000mA
Power: 8.14Wh



BATTERY CHARGER



This dual battery charger is compatible with all Mobile Warming 3.7V 2.0Ah Lithium-ion Batteries.

Model #: ASA16U08
Rating: 3.7V 2200mAh
Input: AC 100-240V, 50/60Hz, 0.5A Max
Output: DC 4.2V ~ 0.72*2

Replacement or additional batteries and chargers available at www.mobilewarming.com

6

ELECTRICAL COMPONENTS OF THE GARMENT

When you purchase a Mobile Warming heated garment from an authorized Mobile Warming dealer within the United States the electrical components of the garment are warranted to be free from factory defects and workmanship for the lifetime of the garment.

90-DAY RECHARGEABLE BATTERY & CHARGER WARRANTY

Mobile Warming rechargeable Lithium-ion battery packs and chargers are under warranty from factory defect for 90 days from the initial purchase date. Mobile Warming will repair or replace any battery or charger found defective under normal use with the 90 day warranty period.

WARRANTY EXCLUSIONS

Any damage caused to any Mobile Warming Gear item by misuse, abuse, improper care, accident, normal wear and tear, or the natural breakdown of materials over an extended period of time and use are not covered in this warranty. Any alterations or repairs (attempted or otherwise) performed on any Mobile Warming Gear item voids any and all warranties offered by Mobile Warming for that particular item. Mobile Warming is technical athletic apparel and is not intended for use as work wear or for use in strenuous or demanding circumstances or extreme conditions.

For information on how to handle a warranty claim, please visit our website at www.mobilewarming.com

*Costs associated with shipping the item in under warranty is the responsibility of the purchaser.