

- Be sure to fully charge the battery (according to the supplied charger manual) before using to ensure maximum runtime. Use only the supplied charger or other approved manufacturer chargers.
- Expected runtime for the Hydroshot on High Speed running non-stop is around 15 minutes (up to 30 minutes on Low Speed). Tool is designed for spot cleaning only and not jobs where a normal pressure washer would be used.
 - Use Low Speed and High Speed interchangeably depending on the task at hand to extend runtime.
 - Turn machine on/off between jobs to extend runtime.
- Batteries will become warm during usage and increase in temperature when used continuously. However, there is an internal switch that will automatically shut the battery down if it reaches a certain operation temperature.
 - The battery should be cool before re-charging or it could impact the overall performance.
- Store the battery in a dry and controlled temperature environment for maximum performance.
- Additional battery and fast charger accessories are also available.