


For Multi-GPU configuration

1. Make sure Updating BIOS to latest version
<https://www.msi.com/Motherboard/support/B250-GAMING-M3#down-bios>
2. In BIOS, set Settings\Advanced\Integrated Graphics Configuration\Initiate Graphic Adapter to be IGD
install the first VGA on 1x PCIE slot and try install driver for it.



3. Load BIOS, set Settings\Advanced\PCI Subsystem Settings\Above 4G memory/Crypto Currency mining to "Enabled"
4. Then user can try install the VGA one by one and test the mining software.

If customer is having issue installing VGA, it could be caused by the riser adapter or graphic card itself.