

**Q. What is Imprint™ Smart Mapping?**

A: Smart Mapping technology describes the robot's ability to learn, map and adapt to your home. Roomba® i7 learns your floorplan as it cleans and remembers this map for future cleaning jobs – this enables the robot to determine the best way to clean based on the orientation of each room, furniture placement, etc. Once the robot has learned your space and you have labeled your rooms, your Smart Map also enables you to clean a room, multiple rooms, or an entire level of your home all from the iRobot HOME App.

**Q. How does Roomba® i7 build its Smart Map and know your rooms?**

A. Roomba® i7 builds a map of the area each time it starts a new cleaning job. After cleaning the same space a few times, Roomba® i7 will produce a Smart Map that is pre-segmented into different spaces or rooms. This map can be customized in the iRobot HOME App. You can merge, split and label rooms as you see fit. After that, you can schedule the Roomba® i7 to clean certain rooms at certain times, or have the robot clean an entire level of your home.

**Q. Can the Roomba® i7 remember more than one floor plan?**

A. Yes! The Roomba® i7 can remember up to 10 unique floor plans, so you can carry the robot to a different floor or a different home. As long as the robot has mapped the space, it will recognize its location and clean as directed.

**Q. How often does the Clean Base™ need to be emptied?**

A. Clean Base™ is designed to hold 30 robot bins of dirt and debris. For some households, this might be one month, for others it could be longer. Results vary based on floor surfaces, whether or not you have pets, etc. Once the bag is full, you will be notified via the iRobot HOME App and you can simply remove it and replace it with a new one.

**Q. Does the Clean Base™ work with previous Roomba® models?**

A. No, Clean Base™ Automatic Dirt Disposal only works with a Roomba® i7. Roomba® i7 is equipped with a dust bin that is specially designed for use with the dirt disposal unit.

**Q: Is the robot bin dishwasher safe?**

A: No. The washable bin should be rinsed by hand using warm water. Important: Be sure to remove the filter before rinsing the bin. Allow bin to dry completely before reinstalling the filter.