




MSI

Download the software for controlling the lighting on the motherboard
主板燈光控制軟件下載位置

Click the link below to visit the download page

<https://tw.msi.com/Landing/mystic-light-motherboard#mystic>



Click the link marked in the picture above to download the software
make sure you choose the one compatible with the chipset on the motherboard
點選紅色圈位置下載 MSI 主機板控制軟件
注意對應主板晶片

RAZER SYNAPSE

RAZER 控制軟件

<https://www.razer.com/synapse-3> Download the software
軟件載點

To well run the software, you need to install Microsoft .NET Framework 4.5 (or a higher level) first.

作業系統需要有安裝 Microsoft .NET Framework 4.5 (含) 以上

After finish downloading, connect to Razer device.

安裝好上述軟件，再將雷蛇裝置接上。



ASRock

Download the software for controlling the lighting on the motherboard
主板燈光控制軟件下載位置

Click the link below to visit the download page

<https://www.asrock.com/microsite/PolychromeRGB/>



RAZER SYNAPSE

RAZER 控制軟件

<https://www.razer.com/synapse-3> Download the software

軟件載點

To well run the software, you need to install Microsoft .NET Framework 4.5 (or a higher level) first.

作業系統需要有安裝 Microsoft .NET Framework 4.5 (含) 以上

After finish downloading, connect to Razer device.

安裝好上述軟件，再將雷蛇裝置接上。

