

Sansa Fuze+ Firmware 02.38.06

A "Format in FAT32 error" message appears when using *microSD/microSDHC* cards with the Sansa Fuze+ player

Firmware is the software code that powers your Fuze+. You can think of it as the operating system. SanDisk actively and periodically updates the capabilities, functionality, and reliability of the Firmware. For an optimal experience with your Fuze+, SanDisk recommends that you update your Firmware with each new release. It's fast, easy, and free!

SanDisk has just released firmware version 02.38.06 for the Sansa Fuze+. Download links and the release notes are available below.

Windows Users can Connect the device in any Mode and follow the instructions below.

Mac and Linux users can connect their Fuze in MSC or Auto Detect mode and follow the instructions below.

MSC mode instructions:

- Turn on the Fuze+
- Navigate to **Settings** on the menu of the device itself
- Scroll down to and select **USB Mode**
- Select **MSC**

Sansa Fuze+ Firmware 02.38.06 Download and Installation instructions

- **Manual Firmware Update** (Download and Instructions)
- Manual Firmware Update (All Regions) - [Click here to download](#)
- All languages are now in one firmware version. After firmware update you will need to select your Language and Region preference.
 - **Remove any external card from the Fuze+ before performing firmware update**
 - Ensure your battery is > 50% full.
 - Plug in your Sansa Fuze+ to your computer.
 - Extract the **firmware.sb** file from the .zip file you just downloaded into a folder on your computer.
 - Once extracted, drag the file to the [root directory](#) of your Sansa Fuze+.
 - Disconnect the Sansa Fuze+ and let the firmware update begin.
 - Once it finally finishes doing its update, it will turn itself off.
 - Turn the Fuze+ on, Select your language and region preference
 - Once its back to the main menu, head to "Settings" > "Info", and verify the "Version" is now 02.38.06"x".