



NOSQUITOTM
by **STINGER**[®]

Indoor Insect Trap

MODEL MA06

OWNER'S MANUAL

IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions before using the NOsquito Indoor Insect Trap.

1. Remove all packing materials from the unit. To avoid danger of suffocation, keep packing material away from babies and children.
2. This product is equipped with 2-conductor cord and 2-prong plug to fit the proper type receptacles. To reduce the risk of electrical shock, only plug into a properly installed outlet.
3. Always disconnect plug before cleaning, changing bulbs or when not in use.
4. Use only extension cords that have plug and receptacles that match the product plug. Do not use extension cords that are damaged or defective.
5. Electrical rating of the extension cord must be as great as the electrical rating of the product.
6. Do not abuse cord – never carry unit by cord or yank it to disconnect from receptacle. Keep cord away from heat, oil, sharp edges or wet surfaces.
7. Do not use if unit is damaged or wet.
8. Do not clean this product with water spray. Do not place where it can fall into water. Do not immerse in water.
9. The Indoor Insect Trap may be placed on furniture, a shelf or on the floor, but always in a vertical position.
10. Ensure there is space around the unit for air to circulate.
11. This device is intended exclusively for the use for which it was created and the producer is not responsible for any damage caused by improper use. For indoor use only.
12. The Indoor Insect Trap is an appliance and should be kept out of reach of children and pets.
13. HOUSEHOLD USE ONLY.
14. When using an extension cord the cord should exceed the rating of the product, be suitable for the plug and receptacle and the cord should be marked with a SJW-A, SJEW-A only.
15. In addition a device for retaining an extension cord connection to the power supply cord should be used.

GENERAL INFORMATION

The NOsquito Indoor Insect Trap will lure indoor flying insects with its special fluorescent ultraviolet (UV) light and capture them in a non-escapable catch-tray. Insects may be left in the catch-tray until they dehydrate and die or can be released outdoors. The unit is for indoor use only and can be used year round.

HOW TO USE YOUR NOSQUITO INDOOR TRAP

1. Unpack unit, save carton and packing materials for storage.
2. Position the Indoor Insect Trap at a height of about 3-6 feet from the floor. For best results, place unit in the darkest area of the room far from windows and other competing sources of UV light. The Indoor Insect Trap is effective when used intermittently to control various outbreaks but performs best when run continuously. Often insects will breed and “over-winter” or hibernate inside your home. Also during brief periods of warm weather, mosquito, fly and ladybug activity may increase.
3. Plug cord into an outlet or U.L. Listed extension cord as described in “IMPORTANT SAFETY INSTRUCTIONS”.
4. To turn unit ON, slide the ON/OFF Lever (A) all the way to the right (see Fig. 1). The light and the fan will turn on and Inlet Valve (B) will open. In this position, the Indoor Insect Trap will lure and trap insects. NOTE: in the ON position, the Catch-tray (C) is locked cannot be removed.
5. To turn unit OFF, slide the ON/OFF Lever all the way to the left (see Fig. 1). The light and the fan will turn off and the Inlet Valve will be closed preventing the escape of live insects. In this position, the Catch-tray is unlocked and can be removed for emptying or cleaning.
6. To remove Catch-tray, ensure ON/OFF Lever is in the OFF position. Pull the Catch-tray straight out by slightly pushing in the Finger Grips (D) located on either side of the tray (see Fig 1).
7. To empty Catch-tray, pull the Snap Tab (E) at the back and separate the top and bottom (See Fig 2). Please use caution when emptying the tray; make sure the insects (especially stinging insects) are inactive. If you notice that beneficial insects have been captured, it is your choice to release them outdoors or let them dehydrate in the unit. Clean the Catch-tray as necessary by rinsing under running water and dry with a paper towel.
8. To reassemble Catch-tray, slide top and bottom together until Snap-Tab is engaged. Be sure ON/OFF Lever is in the OFF position and the Inlet Valve is closed. Slide Catch-tray back into unit by aligning the bottom on the tracks until it snaps in place (See Fig 3).




Fig. 1




Fig. 2




Fig. 3

BULB REPLACEMENT

For maximum effectiveness, replace the bulb (Model B04) every 1500/2000 hours of use (at least once a year) to maintain optimal UV attraction. Even though the bulb's light may be visible to you, its ability to attract insects diminishes over time.

1. Unplug unit. (VERY IMPORTANT)
2. Using a #1 Phillips screwdriver, remove the cap screw in the center rim above the NOsquito logo. Lift lid (See Fig 1).
3. Twist bulb 90° (See Fig 2a) and pull upward until bulb is removed (See Fig 2b). Dispose of bulb properly.
4. Insert new bulb into both socket ends and twist 90° to lock (See Fig 3).
5. Close lid and replace cap screw.
6. For any questions or concerns regarding bulb replacement, please call Stinger Consumer Service at 1-800-477-0457.



Fig. 1



Fig. 2a



Fig. 2b




Fig. 3

ORDERING REPLACEMENT BULBS

The fluorescent ultraviolet bulb in your Indoor Insect Trap has been designed for maximum attraction to flying insects. Do not replace the original bulb with normal lighting bulbs. Replacement bulbs (Model B04) are available at participating retailers or can be ordered directly from Stinger Division of Kaz, Inc by visiting www.StingerProducts.com or by calling 1-800-477-0457.

TROUBLE-SHOOTING

Problem:	Possible Cause:	Correction:
Bulb does not light.	1. No electrical power or unit turned off.	1. Ensure ON/OFF Lever is pushed all the way to the right in the ON position. Check plug and receptacle and fuse or circuit breaker.
	2. Bulb not seated properly.	2. Check socket for proper bulb seating and alignment by gently turning the bulb until it clicks.
	3. Burned out bulb.	3. Replace bulb if needed following instructions under "BULB REPLACEMENT".
	4. Catch-tray not seated properly.	4. Ensure Catch-tray is properly seated.
Fan does not operate.	1. No electrical power.	1. Check plug and receptacle and fuse or circuit breaker.
	2. Fan is jammed.	2. Check fan for obstructions. Make sure fan is not obstructed and moves easily when tapped.
Cannot replace Catch-tray.	1. Catch-tray is not properly aligned.	1. Insert Catch-tray properly as described above.
	2. Bottom and top part of Catch-tray are not assembled correctly.	2. Fit bottom and top part of Catch-tray properly before inserting back into unit.
	3. Inlet Valve is not closed.	3. ON/OFF Lever is not in OFF position.
	4. ON/OFF Lever is not in OFF position.	4. Move to OFF position.

TECHNICAL ASSISTANCE

If you have questions regarding your NOSquito Insect Trap, please call Stinger Consumer Service at 1-800-477-0457.

ACCESSORIES

PART	DESCRIPTION
B04	4 Watt Replacement bulb for MA06

LIMITED WARRANTY

STINGER Division of Kaz Inc warrants to the original purchaser that this product is free from defective materials and workmanship for a period of 1 year from date of original date of purchase. Retain your original receipt as proof of purchase. This warranty does not apply to the bulb, nor to, in our judgment, misuse or abuse. If this unit has been altered, no warranty is in force. This warranty does not apply to this unit if purchased outside the United States or Canada. In no case shall Stinger be liable for any incidental, punitive, consequential, or any other damages of any kind for breach of this or any other warranty, expressed or implied, whatsoever. Some states do not allow limitation on how long an implied warranty lasts, so the above limitations and/or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state.



KAZ, Incorporated

Stinger Division
Attn: Consumer Relations
250 Turnpike Road
Southborough, MA 01772

Consumer Service 800-477-0457 • Fax 508-481-0509 • Email info@StingerProducts.com
or visit us online at www.StingerProducts.com