

The iFox Creations Waterproof Bluetooth Speaker

User Manual



Speaker Operation

- ① Power On: Press and hold the power button for 3 seconds to switch the speaker on and 5 seconds to turn it off - until you hear the speaker beep.
- ② Previous/V-: Short press to play the previous song. Press and hold to turn down the volume.
- ③ Next/V+: Short press for next song. Press and hold to turn up the volume
- ④ PLAY/PAUSE :Play or pause the music.

- ⑤ PHONE button: Pick up or hang up the phone, Double click to redial the last number

Full list of uses for the PHONE button:

- Press to answer a phone call when your phone rings through the speaker.
- Press to hang up and finish a call.
- Press and hold for about 3 seconds to reject a phone call.
- Press twice quickly to redial the last phone number.
- Press and hold for about 3 seconds (until the speaker beeps) to cut off the Bluetooth pairing that connects to your cell phone and to switch to another device. Then pair the other device as normal
- Press once to operate the Siri on Apple devices

Notice: Once the speaker pairs and connects to your cell phone successfully, next time when you switch on this speaker, it will connect to your cell phone automatically as long as the Bluetooth is on in your mobile.

Key Feature:

- Waterproof IP grade : IP67
- Bluetooth 3.0 wireless
- Hand free talk support
- Dedicated Suction Cup
- Charging by USB
- Siri Control

Specification

- Frequency Range: 100Hz-2.4GHz
- Operating Distance: 10 Meters
- Built in Microphone
- Power Rating: 3W

- SNR: ≥ 85 dB
- Battery Capacity:650mAh
- Charging Voltage: DC 5V
- Charge Time: approx. 3 hours
- Playing Time: approx. 6 hours
- Housing Material: ABS

Packing Content

1. Waterproof Bluetooth Speaker
2. USB Charging Cable
3. Dedicated Suction Cup
4. User Manual

Bluetooth pairing

Please make sure your cellphone (or media playing device) is Bluetooth-enabled. Specific pairing steps may vary with different devices. Please refer to the user manual of your device for further information.

1. To pair, firstly be sure that the speaker is powered off. Press and hold the power button until the LED light blinks in blue rapidly and the speaker beeps.
2. Activate the Bluetooth search function in your media player such as smartphone, tablets or music players
3. Choose the device name "My speaker_F12" from the list of Bluetooth devices discovered and pair with the media player. Enter password"0000" if applicable
4. The blue LED light will flash regularly when its paired successfully and connected to the Bluetooth
5. Once you have a device paired and would like to pair a different device with the speaker then press

and hold the phone button until the speaker beeps. Then pair the new device.

Charging the Speaker

The Bluetooth speaker is powered by a built-in rechargeable lithium battery that can be operated by the following steps:

1. Release the DC 5V charging port cover.
2. Connect the standard USB plug end of the cable to a power USB port on a computer or other USB charging device. For first time use, a full charge is recommended.
3. A red LED light is on while the unit is charging and off when the speaker is fully charged.

Application

Compatible with Smartphones, iPhone, Tablet, iPad, iPod, Android & Bluetooth Devices with Built-in Mic for wireless Speakerphone and music playing.

Dedicated Suction Cup and IP67 Waterproof for Showers, Bathroom, Pool, Boat, Car, Beach, Boat, Office, Indoor& Outdoor Use.

1. In the shower room: stick the suction cup on the smooth wall or mirror.
2. In the pool: place speaker upside down and it will float.
3. In the car: stick suction cup to the windshield of the car

If you need to remote control your phone (such as phone call or play music), please press the phone button, then you

can remote control via Siri .(Currently supports Apple devices iPhone4s/iPad2 and earlier)

Notice: Please make sure the plug cover on the charging port is tight before you drop it in the water to keep it waterproof.

Troubleshooting

Symptoms	F012 speaker can't be powered on	Not able to pair with the speaker	Volume too low
Causes	Low battery level	Speaker already on or not in the pairing mode	Battery is not charged up or volume is not set to the maximum on the speaker & media player
Solutions	Recharge the battery 	Refer to "Bluetooth Pairing" section	Increase the volume via press & hold the volume up button on the speaker. Increase the volume on the media players

Safety Instructions

Read this manual carefully before operating

- Do not use this device near any heat sources such as radiators, heaters, stoves, or other heat-producing machinery.
- Do not leave it in direct sunlight.
- Keep the speaker out of children’s reach to avoid a choking hazard.
- Clean with soft cloth. Do not use harsh chemicals to clean.
- Do not clean this device when it is charging. Always unplug from the power source before cleaning the device.
- Do not insert any metal object into the device. There is a risk of a short circuit.
- Do not try to repair or open this device yourself.

Thank you for buying from iFox Creations. We very much appreciate your custom. If you have any problems or questions at any time please reply to this e mail or visit our website and our support team will assist you immediately.

