


# Mini Digital Hygro-thermometer User Manual

## OVERVIEW

- A: Change Temperature display between °F and °C  
B: Magnet inside here



## FEATURES

1. Temperature display in °C / °F
2. Powered by 1x CR2032 battery (included)
3. Temperature range: 0.0°C ~ 50.0°C (32 °F ~ 122.0 °F )
4. Humidity display range: 20%~95%
5. Comfort level indication
6. Table standing, wall hanging or magnet attaching

## POWER ON

1. Remove the plastic tab from the battery compartment prior to use;
2. The LCD will display all digits and icons for 3 seconds, followed by the temperature reading.

## TEMPERATURE

1. After power on, the temperature will display automatically. It will update reading each 10 seconds.
2. If you want to change between Fahrenheit and Celsius, press " C/F" button on the front.
3. Accuracy: when temperature is between 10.0°C ~ 40.0°C , the accuracy is +/- 1.5°C , if out of this range the accuracy will be +/- 5°C . Temperature resolution:0.1 °F (0.1°C ) .

## HUMIDITY

1. It will display humidity after power on.
2. Accuracy: for humidity between 40% ~ 80% , the accuracy is +/- 5% , if out of this range the accuracy will be +/- 7% .

## COMFORT LEVEL INDICATION

- ☺ Comfortable: Temperature between 18.0°C to 26.0°C , and the humidity between 40%RH to 60%RH.
- ☹ Un-comfortable: Temperature lower than 10.0°C or higher than 30.0°C , and humidity lower than 30%RH or higher than 70%RH.
- 💧 Normal Comfortable: Temperature between 10.0°C to 17.9°C or 26.1°C to 30.0°C and the humidity between 30%RH to 39%RH or 61%RH to 70%RH.