





Wireless Speaker

SRS-XB10

Unable to pair the speaker with a BLUETOOTH device

Bring the speaker and the BLUETOOTH device to within 1 m (3 ft) of each other.

If the  (BLUETOOTH) indicator is not flashing quickly in white, press and hold the  (power)  PAIRING button until you hear beeps and the  (BLUETOOTH) indicator begins to flash quickly in white.

Connect the speaker to a booted computer or AC outlet via a USB AC adaptor (not supplied). Otherwise, charge the battery of the speaker sufficiently.

Once the speaker is initialized, an iPhone/iPad/iPod touch may not be able to connect to the speaker. In this case, delete pairing information on the iPhone/iPad/iPod touch then pair them again.