



This Is A Manual.

Inflatable Air Mattress

TABLE OF CONTENTS

Important Safety Instructions	4
Operation	5
Care & Cleaning	6
Warranty	6
Warning	6
Drop Us A Line	6

IMPORTANT SAFETY INSTRUCTIONS

Before using this appliance, please read the manual carefully and keep it for future reference. Incorrect operation due to ignoring of instructions may cause harm or damage. Always observe the following important safety instructions.

1. WARNING: To prevent possible electric shock, do not attempt to plug in power cord with wet hands.
2. WARNING: To prevent possible electric shock, connect power cord into a grounded receptacle protected by a ground-fault circuit interrupter (GFCI).
3. WARNING: To prevent possible electric shock, never use a damaged power cord. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
4. WARNING: Do not use extension power cords with this product.
5. WARNING: This appliance is for indoor household use only. Keep it away from fire.
6. WARNING: In order to reduce the risk of electric shock, do not expose it to rain. Store indoors.
7. RISK OF COMBUSTION: Do not place the air mattress against or near any open flames, heaters, furnaces or other hot objects.
8. IMPORTANT: Do not operate the electric pump for more than 4 minutes at one time, take 5 minutes break between uses, as overheating may occur and the pump will automatically shut off. It will be ready to use after cooling down. This automatic shut off is for your safety. Unplug the electrical power cord when it is not in use.
9. WARNING: Do not obstruct the air passage opening or insert any objects into the opening at any time.
10. WARNING: Do not stand, jump or use the air mattress as a trampoline. Always supervise children near the air mattress.
11. WARNING: This product is not a raft or floatation device. Do not use it near or in the water.
12. WARNING: Children must not be left unattended when using the air mattress.
13. WARNING: The storage bag is not a toy. To avoid danger of suffocation, keep the air mattress storage bag and any other bags away from children. Fold up the bag and store away from children when not in use.
14. WARNING: Keep pets away from the air mattress. Pets may tear or puncture the air mattress.
15. IMPORTANT: Make sure the area is flat, smooth and free of sharp objects that can puncture the air mattress. Do not set up the air mattress near stairs, doors, drops, sharp edges or breakables.
16. IMPORTANT: To minimize any chance of rolling, tipping or swaying, avoid sleeping on the edge of the air mattress. Edges provide less support than the middle of the air mattress.
17. IMPORTANT: This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
18. WARNING: Infants have suffocated on inflatable mattresses. Never place infant aged birth to 15 months to sleep on this inflatable air mattress/air bed. Infants can suffocate on an under inflated or deflated mattress, on bedding, by co-sleeping with another person, and by entrapment between the mattress and bed frame or between the mattress and a vertical surface.
19. WARNING: Children can be entrapped between the inflatable mattress and an adjacent vertical surface. Provide at least a shoulder width space between the inflatable mattress/air bed and adjacent vertical surfaces such as walls, dressers, or other objects.
20. WARNING: Always keep the inflatable mattress fully inflated when in use.
21. WARNING: To reduce the risk of electric shock, always unplug the power cord from the electrical outlet before cleaning.

THIS MATTRESS IS INTENDED TO BE USED WITHOUT A FOUNDATION. This mattress meets the requirements of 16 CFR part 1633 (federal flammability (open flame) standard for mattresses) when used without a foundation. 8017253

SAVE THESE INSTRUCTIONS
For Household Use Only

Operation

INFLATION INSTRUCTIONS

1. Make sure the optional inflation air valve is securely closed.
2. Plug the AC electrical line cord into an AC electrical outlet protected by a ground-fault circuit interrupter. Check the correct voltage before connecting.
3. Turn the Knob to the INFLATE position. The pump will start inflating automatically.
4. When the mattress is fully inflated, turn the Knob to the OFF position.
5. Disconnect the AC line cord from the wall socket.
6. Always keep the Knob on the OFF Position while the mattress is in use.


Tips: Over pressure protection is on while inflating. There is a blow-off valve inside of pump which will be triggered once the pressure is up to 3.5 Kpa (0.507 psi).

Manual Inflation Option

If the electric pump is not available then a conventional foot or manual air pump can be connected to the optional inflation valve for inflation.

Note: Do not use air compressor or high pressure pumps. Do not over inflate - excessive inflation of the air chambers can cause the chamber to burst or damage to the welding seams.

1. Remove the valve totally from the valve insertion. Then pull the stopper out of the valve extension. Inflate the mattress by air pumps. Blow in sufficient air until the chamber is fully inflated.
2. Close the valve by firmly inserting the stopper and pressing the valve into the chamber.




DEFLATION INSTRUCTIONS

1. Make sure the optional inflation air valve is securely closed.
2. Plug the AC electrical line cord into an AC electrical outlet protected by a ground-fault circuit interrupter.
3. Turn the Knob to DEFLATE position. The pump will start deflating automatically.
4. When deflation is completed, turn the Knob to OFF position.
5. Disconnect the AC line cord from the wall socket.
6. Always keep the Knob to OFF position before storage and maintenance.

Manual Deflation Option

Remove the valve from the valve insertion. Then pull the stopper out of the valve extension. It should deflate the air. To get all of the air out, start to fold or roll the mattress starting from the end opposite of the air hole and moving towards it.



Care & Cleaning

CLEANING AND MAINTENANCE

1. Wipe the appliance clean with a mild soapy solution, then leave it in a shady and cool place to dry.

Caution: Do not use any alkali, chemical or acid detergent to clean the appliance. Do not leave or store the appliance in places where it is likely to be exposed to extreme temperature or direct sunlight, as it will shorten the life of the appliance.

2. Fold the air mattress loosely and avoid sharp bends, corners and creases to avoid damage to the air mattress.
3. No specific maintenance is required for the built-in electric pump.

4. Place the air mattress inside the storage bag and store in a dry and indoor place.

REPAIR INSTRUCTIONS

- Small pinhole and puncture leaks can be repaired with the included repair patch.

1. Locate the leak place.

2. Deflate the air mattress.

3. Clean the area surrounding the leakage.
4. Cut the repair patch into required shape and size, which should be a little larger than the leaking area. Stick the patch on the leaking area and press firmly.

5. Wait for more than 30 minutes before you start inflating.

Note: If the damage area is bigger than 1" (2.5cm), we recommend using silicone or rubber based glue for repair. Read warning statement on the glue prior to use.

Warranty

Vremi offers a 12-month warranty on all of our products purchased new and unused from Vremi LLC or an authorized reseller, with an original proof of purchase and where a defect has arisen, wholly or substantially, as a result of faulty manufacturing, parts or workmanship during the Warranty Period. The warranty does not apply where damage is caused by other factors, including without limitation: (a) normal wear and tear; (b) abuse, mishandling, accident or failure to follow operating instructions; (c) exposure to liquid or infiltration of foreign particles; (d) servicing or modification of the product other than by Vremi. These are our general terms for the warranty service, but we always urge our customers to reach out to us with any issue, regardless of warranty terms. If you experience an issue with a Vremi product, please contact us at support@vremi.com or (646) 490-9904, and we will do our best to resolve it for you.

Warning

This manual is to be used with all items with the model numbers

VRM050659N

WARNING: Keep all plastic bags away from children.

Drop Us A Line

CHAT WITH US

vremi.com/chat

CALL US

(646) - 490 - 9904

EMAIL US

support@vremi.com

