

## User Manual for Network and SIM Card

1. The tablet only supports Standard SIM Card. A standard SIM Card measures 0.59 x 0.98 inch. If you do not know if your sim card is a standard sim card or not, please measure it. As long as it is 0.59 x 0.98 inch, it is a Standard SIM Card.

2. The tablet supports the frequency band GSM(2G)/WCDMA(3G) (GSM: 850/900/1800/1900MHz, WCDMA: 2100/1900/850MHz). Any carrier using the frequency band GSM(2G): 850/900/1800/1900MHz or WCDMA(3G): 2100/1900/850MHz is compatible with this tablet. For example, it supports AT&T standard SIM card for 3G and GSM(2G), ONLY supports T-Mobile for GSM(2G), NOT supports Verizon or Sprint or anyother network that uses CDMA network.

3. How to insert the Standard SIM Card? Please put the SIM Card with gold square face down and facing forward, put the unfilled corner backward, just insert like the below pictures show.

### Below pictures to show how to insert the SIM Card Correctly.

