





STEP 1 - POWER UP



Power Button

Press and hold the power buttons for 5 seconds to turn on the device.
(It may take a few seconds for the Cube to start projecting an image.)


STEP 2 - INPUT




SD Card
Insert a micro SD card to view photos and videos.

Mini HDMI Port
Connect an HDMI cable to your smartphone, tablet, or computer to display all your favorite media.

STEP 3 - OUTPUT



Point the remote control to the sides.



To Use SD Card:
Select Movie, Photo,
Text, or Music.

To Use Mini HDMI Port:
Select External Devices
if content doesn't
automatically play.

ADDITIONAL CONNECTIONS

The Cube is compatible with all HDMI compliant devices. Some devices may require an additional proprietary adapter.

Included in box: Mini HDMI to HDMI cable, Micro USB cable, and charger

MAC & PC WITH HDMI PORT

HDMI CABLE (INCLUDED)

MAC & PC WITHOUT HDMI PORT

HDMI CABLE (INCLUDED) + PROPRIETARY HDMI ADAPTER (NOT INCLUDED)

iOS DEVICES

HDMI CABLE (INCLUDED) + PROPRIETARY APPLE HDMI ADAPTER (NOT INCLUDED)

For the complete manual please visit RIF6.com/manual

FCC STATEMENT

“NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/ TV technician for help.”

CALIFORNIA PROP 65 WARNING



State of California Proposition 65 Warnings:

The wires of this product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

C  B E

