

# Measuring Guide


## Furniture Sizes



**Chair** (seats 1)  
outside arm to  
outside arm -  
32 in. to 43 in.



**Loveseat** (seats 2)  
outside arm to  
outside arm -  
58 in. to 73 in.



**Sofa** (seats 3 or more)  
outside arm to  
outside arm -  
74 in. to 96 in.

## Seat cushion styles


### Box Cushion

One, two and three piece  
slipcovers in form fit  
and relaxed fit fabrics.





### T- Cushion



One, two and three piece  
slipcovers in form fit  
and relaxed fit fabrics.



### Form Fit and Relaxed Fit Arm Width Guidelines




### Form Fit and Relaxed Fit Seat Width Guidelines




## Wing Recliners and Wing Chairs

**Form Fit Box Cushion  
Wing Recliner**  
Seat Width - 24"  
Back Height - 45"


Fits both box cushion  
and wing recliners



**Form Fit T-Cushion**  
Seat Width - 32"  
Back Height - 45"




**Relaxed Fit  
T-Cushion**  
Seat Width - 29"  
Back Height - 42"




## Recliners and Lift Recliners

**Sure Fit Form Fit**  
78" to 88"



**Medium Sure Fit  
Form Fit**  
68" to 78"

**Large Sure Fit  
Form Fit**  
78" to 92"



## Ottomans



**Form Fit - 30"**  
Measure the longest  
side of ottoman


**Relaxed Fit -  
up to 116"**  
Measure all 4 sides  
and add together

## Furniture Covers

### Standard Covers

**Seat  
Widths**

Chair 24"  
Loveseat 48"  
Sofa 70"




**Back Lengths**  
39" or 46"

### Deluxe Covers

**Seat  
Widths**

Chair 26"  
Loveseat 52"  
Sofa 76"



**Back Length 50"**  
(longer arm length)

### Chaise Covers

Seat  
Width - 34"  
Seat  
Depth - 65"



## Dining and Folding Chairs



**Short Dining  
Chair Cover**  
Back Height  
up to - 42"  
Seat Width - 18.5"



**Long Dining  
Chair Cover**  
Back Height  
up to - 42"  
Seat Width - 18.5"



**Folding  
Chair Cover**  
Back Height  
up to - 32"  
Seat Width -  
15" square