SINGLEPASS LUXE

User Guide

1" professional straightening and styling iron
Model No. 76505, 76506, 76507, 76508, 76509, 76510, 76511, 76512, 76513, 76514, 76515, 76516, 76517, 76518, 76519

IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USING

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:



DANGER

KEEP AWAY FROM WATER

Electricity and water are a dangerous combination and can cause death by electric shock. Do not allow electrical cords to come into contact with water or other liquids.

ELECTRICAL APPLIANCES ARE ELECTRICALLY LIVE WHEN PLUGGED IN, EVEN IF TURNED OFF.

To reduce the risk of death by electric shock:

1. Always unplug the appliance immediately after using.
2. Do not use while bathing.
3. Do not place or store the appliance where it can fall or be pulled into a bath tub or sink.
4. Do not place in or drop into water or other liquid.
5. If the appliance falls into water, unplug it immediately. Do not reach into the water.

IMPORTANT SAFETY INSTRUCTIONS



WARNING

To reduce the risk of burns, electrocution, fire or injury to persons:

1. An appliance should never be left unattended when plugged in.
2. Close supervision is necessary when this appliance is used on, or near children or individuals with certain disabilities.
3. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
4. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water. Return the appliance to a service center for examination and repair.
5. Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
6. Never use while sleeping.
7. Never insert any object into the styling iron.
8. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
9. Do not use an extension cord with this appliance.
10. This styling iron is hot when in use. Do not let eyes and bare skin touch the heated surfaces.

IMPORTANT SAFETY INSTRUCTIONS

WARNING

11. Do not place the heated styling iron directly on any surface while it is hot or plugged in.
12. Do not use if the plug is loose in the outlet, as there may be risk of fire, electric shock, electrical shortage and burning.
13. Make sure to remove the plug from the wall outlet after use.



Do not use the appliance near a bath tub, washbasin or other vessel filled with water. Never place the appliance in water or any other liquid.

SAVE THESE INSTRUCTIONS

MAINTENANCE INSTRUCTIONS

SINGLEPASS LUXE

1. Your appliance is virtually maintenance free. It contains no user serviceable parts, and no lubrication is needed.
2. Keep heated surfaces clean and free of dust, dirt & hairspray.
3. If cleaning becomes necessary, disconnect the appliance from the power source and let it cool. Wipe the exterior with a damp cloth.
4. If any malfunction occurs, unplug the appliance, allow it to cool and return it to a service center to repair.
5. Never wrap the cord around the appliance since this will cause the cord to wear prematurely and break. If the cord becomes twisted, untwist it prior to use.
6. Handle the cord carefully for longer life and do not put any stress on the cord where it enters the handle. Avoid jerking, twisting or straining especially at the plug connections. It could cause the cord to fray and possibly break.
7. Do not attempt to repair the appliance yourself.

STORAGE

When not in use, your styling iron should be disconnected and stored in a safe, dry location, out of reach of children. Do not wrap the cord around the styling iron. Allow the cord to hang or lie loose and straight at the point of entry into the styling iron.

MAINTENANCE INSTRUCTIONS

SINGLEPASS LUXE

SERVICING OF DOUBLE-INSULATED APPLIANCES

In a double-insulated appliance, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated appliance, nor should a means for grounding be added to the appliance.

Servicing a double-insulated appliance requires extreme care and knowledge of the system, and should be done only by qualified service personnel.

Replacement parts for double-insulated appliance must be identical to the parts they replace. A double-insulated appliance is marked with the words “DOUBLE INSULATION” or “DOUBLE INSULATED”. The symbol (square within a square) may also be marked on the appliance.

OPERATING INSTRUCTIONS

SINGLEPASS LUXE

This appliance is intended for household use.
Use on Alternating Current (60/50 Hz) only.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.



WARNING

AUTO SHUT-OFF

After approximately one hour, the unit will automatically shut itself off. To reactivate the unit, press the Power & Temperature Adjustment Button.


AUTO WORLD VOLTAGE

This appliance contains a special electronic circuit that automatically converts it for worldwide usage - from 120VAC 60 Hz to 240VAC 50 Hz. Just plug it into the local power outlet and use it as normal; the styler will automatically adjust to the local current. You may need an adapter to allow the plug to fit into the local outlets.


Note: Tool heat up time may vary based on country and voltage.

OPERATING INSTRUCTIONS

SINGLEPASS LUXE



Temperature Guide




CAUTION

Do not let the heated plates touch your skin as you may get burnt.


OPERATING INSTRUCTIONS

SINGLEPASS LUXE


1 Press the Power & Temperature Switch to turn the iron on. Lights will cascade up, then turn solid when the unit is ready to use.




2 To change the temperature*, double click the Power & Temperature Switch until the lights flash. Then continue to click to cycle through the temperature settings.



3 Release the Power & Temperature Switch after reaching your desired temperature. The selected temperature light(s) will flash, and all lights will cascade up or down to your selected temperature. Wait for the lights to turn solid before using the iron.



4 To turn off the iron, press and hold the Power & Temperature Switch until the lights turn off.




*See Temperature Guide in Operating Instructions for recommended settings.

HOW TO USE YOUR

SINGLEPASS LUXE


1 Start with dry, detangled hair. Twist the top part of your hair out of the way and secure it with one of the included sectioning clips. Gather the rest of your hair into the other clip, leaving a thin section out to begin styling.



2 To avoid kinks, style your hair using thin, horizontal sections* so the iron can be positioned close to the roots.




*Expert Tip:



HOW TO USE YOUR

SINGLEPASS LUXE

3 Glide iron through in the direction of hair growth at a speed slower than when brushing hair. Repeat steps 2 and 3 until hair is fully styled.



*Expert Tip:

Slow down for perfect results in a single glide:

Fine hair: Glide iron at 2-3 inches per second

Medium Hair: Glide iron at 2 inches per second

Coarse Hair: Glide iron at 1 inch per second

T3 LIMITED WARRANTY TERMS & CONDITIONS

T3 Micro will repair or replace (at our option) T3 products for twenty-four (24) months from the date of purchase if they are defective in workmanship or materials. This limited warranty does not cover (1) damage due to misuse or abuse, such as incorrect voltage supply, dropping, or failure to follow enclosed instructions or (2) tampering, such as repair or attempt to repair. To obtain service under this warranty, please visit t3micro.com/warrantyclaim to submit a warranty claim, or call us at (866) 376-8880 to receive detailed instructions. You will be required to provide proof of purchase.

THIS LIMITED WARRANTY IS ONLY VALID IF THE PRODUCT IS PURCHASED FROM AN AUTHORIZED SELLER OF T3 GOODS AND IF THE ORIGINAL SERIAL NUMBER ON THE PRODUCT HAS NOT BEEN REMOVED OR OTHERWISE TAMPERED WITH.

Any implied warranties, obligations, or liabilities, including but not limited to the implied warranty of merchantability and fitness for a particular purpose, shall be limited in duration to the 24 month duration of this written limited warranty. Some states do not allow a limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

IN NO EVENT SHALL T3 BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED.

Visit www.T3micro.com/register to complete your warranty registration.

THIS PAGE INTENTIONALLY
LEFT BLANK

THIS PAGE INTENTIONALLY
LEFT BLANK

THIS PAGE INTENTIONALLY
LEFT BLANK

MODEL NO.

76505, 76506, 76507, 76508, 76509, 76510, 76511, 76512, 76513, 76514, 76515, 76516, 76517, 76518, 76519

SPECIFICATIONS

Operating Voltage: 120-240V, 60/50 Hz

Power Consumption: 38W

T3 Micro, Inc.

Venice, CA USA

Made in China



WARNING

Do not use the appliance near a shower, bathtub, washbasin or other vessel filled with water. Never place the appliance in water or any other liquid.

Intertek

0184-76505-E

Model: 76505, 76506, 76507, 76508, 76509, 76510, 76511, 76512, 76513, 76514, 76515, 76516, 76517, 76518, 76519
This device complies with Part 15 of the FCC Rules:
Operation is subject to the following two conditions:

(1) this device may not cause harmful interference,

(2) and (2) this device must accept any interference received, including interference that may cause undesired operation.