



PERLESMITH

Installation Instructions

V1.0



PSTVA01



Thank you for choosing our product! We strive to provide the best quality and services for our customers. Would you kindly share your experience on Amazon if you are satisfied? Should you have any issues, please don't hesitate to contact us.

Telephone:
800-5566-806 Mon-Fri 10am - 6pm (PST) (USA) (CAN)
Email:
supportus@perlesmith.com (US/CA/DE/UK/FR/IT/ES/JP/AU)

DIGITAL INDOOR TV ANTENNA

Please read the instructions carefully before you use the tv antenna.

ATSC
Compatible

HDTV
Compatible

Package contents



Antenna with attached
16.4 ft cable



Power adapter




Stickers&Pins

Features:

- 1.Light as a Feather,allows you to place it anywhere.
- 2.Match your home decoration, can be easily hidden behind a picture,book shelf or television.
- 3.Fast and easy set up with 3 steps-Unwrap, Plug it in and Scan channels.
- 4.You can put it higher on wall; lay flat on table; on window (strongly recommended), and it will provide you with opportunities to watch crystal clear digital & HD show.


Set up guide:

Option1: Connect the end (F-male) of attached coaxial cable to Set-top-box,then connect the converter box to your TV.



Connected to TV through set top box


Option2:Connect the end (F–male) of the attached coaxial cable to the back of TV,then plug the USB cable to your TV’s USB port.



Connected to HDTV with digital tuner in built

In the TV’s setup menu, set the tuner mode to “Antenna” or “Air” . Refer to the TV manual for detailed instructions.

In the TV’s setup menu, set TV to scan for channels. This can sometimes be listed as auto–program, auto–scan, channel search or channel scan. Refer to the TV manual for detailed instructions.




If reception is sporadic, try moving the antenna to another location and rescanning the TV until optimum position is found (picture 1,2&3 examples).



Stick on the wall



Lay flat on the table



Stick on the window

Note:

- 1.Placing the antenna higher or close to/in a window may result in better reception.You must rescan whenever you move the antenna.
- 2.If you use a flat HDTV,please go though your TV manual to make sure your TV is with built–in tuner for freeview.
- 3.Make sure you are using a HD receiver;otherwise no HD channels can be picked up.Please read receiver manual.
- 4.You should retune your Freeview TV’s and digital receiver from time to time to ensure you are receiving all available service.Retuning takes only a few minutes and can be done with your remote control.
- 5.TV reception depends on the distance from your home to the transmitting tower and the surrounding environments.