

# MINI

Travel Dryer

## USER MANUAL



## IMPORTANT SAFETY INFORMATION

**WARNING: TO REDUCE THE RISK OF SERIOUS INJURY, READ ALL INSTRUCTIONS AND WARNINGS COMPLETELY BEFORE USING THIS PRODUCT.**

The MINI has been carefully engineered for both effectiveness and safety. However, basic safety precautions should always be followed when using the MINI, especially when children are present, including the following. All relative safety instruction can also be found at [www.instyler.com](http://www.instyler.com).

**WARNING:** The power cord on this product contains lead, a chemical known to the State of California to cause (cancer and) birth defects or other reproductive harm. WASH HANDS AFTER HANDLING.

- **MINI IS NOT INTENDED FOR USE BY CHILDREN.**
- **KEEP AWAY FROM WATER.**
- **DANGER:** As with most electrical appliances, electric parts are live even when the switch is off. To reduce the risk of electric shock:

**WARNING TO REDUCE THE RISK OF BURNS, ELECTROCUTION, FIRE, OR INJURY TO PERSONS:**

1. **ALWAYS UNPLUG UNIT IMMEDIATELY AFTER USE ESPECIALLY WHEN USED IN A BATHROOM.**
2. **DO NOT** use while bathing or showering.
3. **DO NOT** place or store the MINI where it can fall or be pulled into a tub, toilet or sink, or any other water source.
4. When the hairdryer is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the hairdryer is switched off.
5. **DO NOT** place or drop into water or other liquid.
6. If the MINI falls into water, **DO NOT REACH INTO THE WATER!** Unplug device immediately.
7. For additional protection, the installation of a residual current device (RCD) having a rated residual operating

current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.

8. MINI is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
9. Children should be supervised to ensure that they do not play with the appliance.
10. Cleaning and user maintenance shall not be made by children without supervision.
11. Unplug this appliance before cleaning.
12. Counterfeit versions of the MINI do exist. To ensure you have purchased a genuine product and to reduce risk of burns, electrical shock and malfunctions, purchase from authorized dealers only.
13. Use the MINI for its intended purpose as described in this manual. **DO NOT** use attachments not recommended by the manufacturer.
14. **NEVER** operate the MINI if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if it has been dropped in water. If the power supply cord or plug is damaged, the MINI must be replaced by the manufacturer or an authorized service agent in order to avoid hazard.
15. Keep this product and the cord away from water and heated surfaces. **DO NOT** wrap the cord around the MINI.
16. The MINI should never be left unattended when plugged in.
17. **NEVER** use while sleeping.
18. **NEVER** drop or insert any object into any opening or hole on the MINI.
19. **DO NOT** use an extension cord with the MINI.
20. **DO NOT** operate with a voltage converter.
21. This product is designed for hair styling. **DO NOT** use for any other purpose.
22. This product is a personal care device and is **NOT**

intended for commercial use. This appliance is for household use only.

23. **DO NOT** use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
24. Always store this appliance and cord in a moisture free area.
25. **DO NOT** plug or unplug this appliance when your hands are wet.
26. Keep your hair out of the air inlets when using this product.
27. **DO NOT** direct the hot air towards eyes or other sensitive areas.
28. **DO NOT** block the air opening of the product or place it on a soft surface that may block the air opening. Keep air openings free of lint and hair.
29. **DO NOT** use this product if any parts become damaged. Inspect the MINI prior to beginning hair styling to ensure all parts are secure in their place.
30. **DO NOT** subject this product to excessive force or shock that may result in malfunction, shorter lifespan or distorted parts.
31. **DO NOT** tamper with this product's components. Doing so may cause unnecessary damage. This product contains no user-serviceable parts.
32. **DO NOT** use the MINI near water.
33. Attachments may be hot during use. Allow them to cool before handling.
34. **DO NOT** place the appliance on any surface while its operating.
35. Close supervision is necessary when the appliance is used by, on, or near children or invalids.
36. Be sure the dual voltage selector is in correct voltage position before operating. Before plugging in, read the information about dual voltage contained in the instruction section of this manual.
37. This appliance was set at the factory to operate at 120 volts. Refer to Operating Instructions section of this

manual for conversion to 240 volt operation.

- 38. **DO NOT** use liquid cleaners, aerosol cleaners or any cleaner containing alcohol, detergent, abrasive or corrosive materials.
- 39. This product has a polarized plug (one blade is wider than the other). As a safety feature, this plug will only fit in a polarized outlet one way. If the plug does not fully fit in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician for help. **DO NOT** attempt to defeat this safety measure.

**OPERATING INSTRUCTIONS:**

This appliance is intended for household use only. Standard Dryers are designed to operate at 120/240 volts A.C This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

**SAVE THESE INSTRUCTIONS.**

**KEEP THIS MANUAL IN A SAFE PLACE FOR FUTURE REFERENCE AND MAKE SURE ANYONE WHO USES THIS PRODUCT ALSO READS THIS MANUAL. READ ALL INSTRUCTIONS BEFORE USING YOUR MINI.**

**NO ASSEMBLY REQUIRED.**

**GROUND FAULT CIRCUIT INTERRUPTERS**


**IF YOU MUST USE YOUR HAIR DRYER IN THE BATHROOM, INSTALL A GFCI NOW!**

YOUR LOCAL ELECTRICIAN CAN HELP YOU DECIDE




**G**ROUND  
**F**AULT  
**C**IRCUIT  
**I**NTERRUPTERS  
...can save a life!

This message is about...



Electricity and water don't mix. If your hair dryer falls in water while it's plugged in, the electric shock can kill you, even if the switch is "off." A regular fuse or circuit breaker won't protect you under these circumstances. A GFCI offers you far greater protection. GFCI is a sensitive device which reacts immediately to a small electric current leak by stopping the electricity flow.



**CHECK ALCI SAFETY FEATURE EVERY TIME YOU USE DRYER.**

This hair dryer is provided with an Appliance Leakage Circuit Interrupter (ALCI), This safety feature that renders the tool inoperable under some abnormal conditions, such as accidental immersion in water. To make sure the ALCI is functioning properly and the exclusive water sensing system is working, perform the following test:

1. Plug in the dryer and press the test button on plug.
2. Dryer will stop functioning. There will be an audible click and the reset button will pop out.
3. To reset: ALCI with a reset button: Unplug unit. Then push reset button in, then reinsert into outlet.
4. Be sure to repeat test every time you use this dryer to confirm the ALCI is operational.
5. If ALCI is not functioning properly, return the dryer to Bersheart, LLC.
6. If a water immersion occurs, contact manufacturer immediately for examination and repair.
7. Should the dryer go off and the reset button pop out during use, this could indicate a malfunction in the dryer. Remove the plug from the outlet and allow the dryer to cool. Reset the ALCI. Reinsert the plug into the outlet
8. The dryer should function normally. If not, return to Quality Assurance for examination and repair.

## Features



**Tourmaline Ceramic Grill**  
Evenly distributes heat and emits negative ions to reduce frizz

## How to Use

1. The Dual Voltage switch allows you to choose a voltage of 120V or 240V depending on your requirement. You cannot change the voltage setting while the dryer is in use.
2. For use in the United States, the voltage selector switch should be placed in the 120V position. For use in several countries, the voltage selector may need to be placed in the 240V position. Confirm the voltage available at each location before using the appliance. For connection to a 240V supply, use an adapter.

## Drying Basics

1. Towel dry hair to remove excess moisture. Blot with the towel rather than rub the hair to avoid causing excess frizz and split ends.
2. Comb through and detangle the hair with a wide toothed comb.
3. Plug MINI into an electrical outlet and turn on by selecting desired heat setting.
4. Direct the MINI at the hair and not the scalp. Begin by briskly blowing it all over the hair to remove excess water.
5. When hair is mostly dry, section the hair and begin to style. Begin at the nape of the neck and brush hair while following the motion with the MINI. Work up to the scalp, sides and front of hair until entire head is dry and desired style in complete.

## Concentrator

The removable concentrator nozzle creates more powerful airflow, styling accuracy and control. Point the MINI with the concentrator at a 90° angle to the section you are drying and run the brush under it, working from roots to ends. Keep the concentrator pointed downward at all times and never let it touch the hair.

## Styling Tips

### Body & Volume

For extra body and volume, turn head upside down while drying. Direct the MINI's airflow at the roots for lift. When hair is dry, flip hair back and style into place with a brush.

### Straightening

Separate hair into sections and use a large round brush or paddle brush to brush hair from underneath. Hold hair taut while drying each section and run the MINI down the length of the hair several times until dry. Curve the ends slightly under as you brush down the shaft. Repeat with all sections until completely dry.

### Curls & Waves

Set the MINI to Low Heat. Move the MINI around the hair while scrunching the hair in your hand with your favorite styling product. Continue until tousled, natural-looking waves are completely dry.

### Hair Care Tips

1. To prevent burning scalp or damaging hair, keep the MINI roughly 8 inches away from head.
2. Always point the dryer down the hair shaft to smooth the hair cuticle for silky and shiny looks.
3. For a smooth and salon-like blowout look, finish by styling with the InStyler MAX 2-Way Rotating Iron.
4. For quick and easy touch ups between shampoos, simply use the MINI to restyle.

## Cleaning & Maintenance

### Maintenance Instructions

The MINI is virtually maintenance free. For maximum performance, the dryer must be kept clean.

1. Keep all air intake vents clean and free of clogs as this will cause the MINI to overheat.
2. Untwist cord periodically if it becomes twisted due to use. Store MINI and cord in a safe place where they will not get damaged. Do not wrap the cord around the MINI.
3. Do not attempt to repair the MINI. Contact a service provider if there are any issues with your appliance.

### Cleaning Instructions

1. Begin cleaning by unplugging the MINI from the outlet.
2. Use a soft bristle brush to gently remove any particles lodged in the filter.
3. If the unit is dirty, wipe with a dampened cloth (DO NOT use a wet cloth with a chemical solution).

### Storage

When not in use, MINI should be unplugged. Make sure the unit is completely cooled and out of reach of children. Store the MINI in a dry and safe place. Never wrap the cord around the MINI.

## Troubleshooting

### **Cool air is coming out of the MINI (even when the High Heat setting is selected).**

This could be caused by a blockage of dust or some other obstruction in the air intake grill. Power off the dryer and unplug it from the power source. Use a soft bristle brush to gently remove any particles lodged in the filter. If this does not fix the problem, please contact customer service.

### **The MINI is overheating.**

Overheating can be caused by a blockage in the air intake grill or airflow outlet of the dryer. Check for hair, dust, or some other obstruction that could be blocking the airflow.

### **The plug of the MINI is very hot.**

Check to make sure that the plug is not loose from the socket. Tight contact is necessary for optimal performance.

### **There is a spark coming from the outlet when the MINI is plugged in.**

Check to make sure there is no dust, hair or other blockage in the air intake grill or airflow outlet. Power off the dryer and unplug it from the power source. Use a soft bristle brush to gently remove any particles lodged in the filter. If this does not fix the problem, please contact customer service.

### **The MINI has no airflow or intermittent airflow.**

The power cord could be damaged. Please stop use and contact customer service.

### **The power cord on the MINI is hot or discolored.**

The power cord could be damaged. Please stop use and contact customer service.

## Limited 1 Year Warranty

This warranty is for the original purchaser of the MINI, and is non transferable. Tré Milano, LLC warrants that MINI will have no defects in material and workmanship under normal household usage for one year from the date of purchase. Keep the original sales receipt for proof of purchase to attain warranty provisions. Within a one year period from the date of purchase, Tré Milano, LLC will repair or replace, on its own accord, any MINI or parts found to be defective. This warranty does not cover any shipping and handling charges which may incur. This warranty does not include any damages caused by accident, misuse, neglect, abuse, use on a voltage other than marked on the product, or use for commercial purposes.

If your MINI is found to be defective within the time period of this warranty, please contact the Tré Milano, LLC Customer Service Department Toll Free number **800-307-0078**. If the product is discontinued or no longer available, a replacement may be made with a similar product of equal or greater value. Any attempt to repair or service this product on your own will void the warranty.

# Arbitration Agreement

## IMPORTANT INFORMATION

THIS ARBITRATION AGREEMENT AFFECTS YOUR LEGAL RIGHTS AND REMEDIES BY PROVIDING THAT DISPUTES BETWEEN YOU AND TRE MILANO, LLC MUST BE RESOLVED THROUGH MANDATORY, BINDING ARBITRATION, RATHER THAN IN A COURT. PLEASE READ THIS AGREEMENT CAREFULLY. YOUR ACCEPTANCE OF THE TERMS OF THIS AGREEMENT SHALL BE EVIDENCED BY THE FIRST TO OCCUR OF: (1) YOUR OPENING OF ONE OR MORE OF THE INSTYLER PRODUCT UNITS PURCHASED OR RECEIVED BY YOU (COLLECTIVELY, THE "PRODUCT"), (2) YOUR OPENING OF ONE OR MORE OF THE INSTYLER ACCESSORY PRODUCTS PURCHASED OR RECEIVED BY YOU (COLLECTIVELY, THE "ACCESSORY PRODUCTS"), OR (3) YOUR RETAINING THE PRODUCT OR THE ACCESSORY PRODUCTS FOR MORE THAN TEN (10) DAYS AFTER PURCHASE OR RECEIPT. IF YOU DO NOT AGREE TO THE TERMS OF THIS AGREEMENT, YOU MUST RETURN THE PRODUCT AND/OR THE ACCESSORY PRODUCTS, AS THE CASE MAY BE, WITHIN TEN (10) DAYS OF RECEIPT AT NO COST TO YOU. YOU MAY RETURN THE PRODUCT AND/OR THE ACCESSORY PRODUCTS BY CALLING Tré MILANO AT (800) 307-0078 AND REQUESTING A CREDIT RETURN AUTHORIZATION NUMBER. THIS ARBITRATION AGREEMENT COVERS ALL DISPUTES BETWEEN YOU AND TRE MILANO, LLC REGARDING BOTH THE PRODUCT AND THE ACCESSORY PRODUCTS.

### 1. RESOLUTION OF CLAIMS OR DISPUTES.

Any claim or dispute between you and Tré Milano, LLC (including any of Tré Milano, LLC's subsidiaries or affiliates, collectively "Tré Milano") arising out of or relating in any way to the purchase or use of the Product, the Accessory Products or this Agreement shall be resolved through final, binding arbitration. This mandatory arbitration obligation applies regardless of whether the claim or dispute involves a tort, fraud, misrepresentation, product liability, negligence, violation of a statute, or any other legal theory. Both you and Tré Milano specifically acknowledge and agree that you waive your right to bring a lawsuit based on such claims or disputes and that you waive your right to have such claims or disputes resolved by a judge or jury. Notwithstanding the foregoing, you have the right to seek relief in small claims

court for claims or disputes within the scope of small claims jurisdictional limits.

### 2. LIMITATION OF LEGAL REMEDIES.

All arbitrations under this Agreement shall be conducted on an individual (and not a class-wide) basis, and an arbitrator shall have no authority to award class-wide relief. You acknowledge and agree that this Agreement specifically prohibits you from commencing arbitration proceedings as a representative of others or joining in any arbitration, litigation or other proceeding brought by any other person.

### 3. ARBITRATION PROCEDURES.

- a. Before commencing any arbitration proceedings under this Agreement, you must first present the claim or dispute to Tré Milano by calling 800-307-0078 and asking for the Legal Department and allowing Tré Milano the opportunity to resolve the claim or dispute. If your claim or dispute is not resolved within sixty (60) days, you may commence arbitration proceedings in accordance with the terms of this Agreement.
- b. The arbitration of any claim or dispute under this Agreement shall be conducted pursuant to the American Arbitration Association's ("AAA") United States Commercial Dispute Resolution Procedures and Supplementary Procedures for Consumer-Related Disputes. These rules and procedures are available by calling AAA at 800-778-7879 or by visiting its web site at [www.adr.org](http://www.adr.org).
- c. The arbitration of any claim or dispute under this Agreement shall be conducted in the State of California and the County of Los Angeles; provided that if the parties do not agree on a location for the arbitration, then the AAA shall determine a reasonably convenient location.
- d. The arbitration of any claim or dispute under this Agreement shall be conducted by an arbitrator who is independent and impartial.
- e. The exchange of information and timing of the arbitration shall be supervised by the arbitrator and shall be in accordance with procedures provided by the arbitrator.
- f. The arbitration of any claim or dispute under this Agreement and the resolution or settlement thereof shall be confidential and shall not be disclosed by the parties to any third parties other than their respective professional representatives.
- g. Each party shall have the right, at their own expense, to 15



- be represented by an attorney (or other spokesperson if permitted by law) of their own choosing.
- h. All administrative expenses of arbitration proceedings commenced under this Agreement shall be divided equally between you and Tré Milano, except that: (a) if the claim or dispute that is the subject of the arbitration proceedings is less than ten thousand dollars (US \$10,000), you will be responsible for no more than one hundred twenty-five dollars (US \$125) in administrative expenses; (b) if the claim or dispute that is the subject of the arbitration proceedings is more than ten thousand dollars (US \$10,000) but less than seventy-five thousand dollars (US \$75,000), you will be responsible for no more than three hundred seventy-five dollars (US \$375) in administrative expenses; and (c) if the claim or dispute that is the subject of the arbitration proceedings is more than seventy-five thousand dollars (US \$75,000) or non-monetary, then you will be responsible for administrative expenses in accordance with the Commercial Fee Schedule provided by the AAA. You acknowledge and agree that each party shall pay the fees and costs of its own counsel, experts and witnesses.

#### 4. CHOICE OF LAW.

This Agreement shall be governed by the United States Federal Arbitration Act and the laws of the state of California.

#### 5. SEVERABILITY.

If any provision of this Agreement is declared or found to be unlawful, unenforceable or void, such provision will be ineffective only to the extent that is found unlawful, unenforceable or void, and the remainder of the provision and all other provisions shall remain fully enforceable.

#### 6. WAIVER OF DAMAGES.

Each of the parties hereby (a) irrevocably waives, to the maximum extent not prohibited by law, any right it may have to a trial by jury in respect of any proceeding directly or indirectly at any time arising out of, under or in connection with the purchase of the Product and the Accessory Products from Tré Milano or any transaction contemplated hereby or associated herewith; (b) irrevocably waives, to the maximum extent not prohibited by law, any right it may have to claim or recover in any such proceeding any special, exemplary, punitive or consequential damages, or any damages other than, or in addition to, actual damages.

**Get even more tips & tricks on our website and social sites!**

Share your videos, tips, questions with other InStyler fans!

 instylerus

 instylerhair

[www.youtube.com/instylerhair](http://www.youtube.com/instylerhair)



Voltage: 120V/240V

Power: 1000W

©2017 Trade Box, LLC. All rights reserved.  
InStyler®, IN BLU™, Illumination from Front Barrel and from Rear Port are registered trademarks of Trade Box, LLC.  
Part ID: PKG-MANE-ISHDM-1701