



NATURAL SWEEP™


92NO SERIES

Assembly

Your sweeper requires very little assembly.

1. Lay handle sections out with the handle grip at the top. Fit smaller threaded handle sections into larger handle sections and tightly screw together until secure.

2. Take the assembled handle and tightly screw the threaded end onto the connector piece on top of the sweeper pressing. While screwing the handle to the body of the sweeper, press down firmly, but carefully to ensure that the handle is securely connected



Emptying

To empty the dirt pans hold the sweeper over a trash bin and pull down on the tabs on the sides of the sweeper.



Maintaining

For best performance keep brushes and bearings clean of hair, threads and other debris.

The sweeper case will bow slightly to allow the center brush rolls to be removed for cleaning. To replace brush rolls fit the bearing to the proper axle end.



©2017 BISSELL Homecare, Inc.
Grand Rapids, Michigan
All rights reserved. Printed in China
Part Number 161-1836 01/17 RevA
Visit our website at: www.BISSELL.com