



Left Click



Right Click



Middle Click



Scroll
Vertical + Horizontal

STANDARD MOUSE



Double tap with 2 fingers

Windows 8 // Start Screen (Metro)
Windows 7 // Start Menu

Mac with Software // Mission Control



Swipe with 2 fingers

Windows 8 // Back and Forward
Windows 7 // Back and Forward

Mac with Software // Back and Forward



Left edge swipe

Windows 8 // Display the App bar



Right edge swipe

Windows 8 // Display the Charms bar

OS NAVIGATION



Double tap with 1 finger

Windows 8 with Software// Show and Hide desktop

Windows 7 with Software// Show and Hide desktop

Mac with Software // Smart zoom

ADVANCED GESTURES

SOFTWARE REQUIRED

SMOOTHER PERFORMANCE

CUSTOMIZABLE SETTINGS

OPTIMAL GESTURES