

# FORZA METALLO

USER'S MANUAL



REGISTER NOW AT  
[V-MODA.com/REGISTER](https://www.v-moda.com/REGISTER)



## CAUTION

If **serial number** on manual cover or bottom of packaging is missing or defaced, **please return to retailer** immediately.

IMMORTAL  
**LIFE**  
PROGRAM

**2YR**  
WARRANTY

english

To acquire a printable version of this manual, please visit [V-MODA.com/manuals](https://www.v-moda.com/manuals)

español

Para adquirir una versión impresa de este manual, visite por favor [V-MODA.com/manuals](https://www.v-moda.com/manuals)

français

Pour obtenir une version imprimable de cette manuel, veuillez consulter [V-MODA.com/manuals](https://www.v-moda.com/manuals)

italiano

Per ottenere una copia stampabile di questa manuale, visitare il sito [V-MODA.com/manuals](https://www.v-moda.com/manuals)

deutsch

Eine Handbuch zum Ausdrucken erhalten Sie unter: [V-MODA.com/manuals](https://www.v-moda.com/manuals)

한국어

수 동의 인쇄판을 얻으려면 [V-MODA.com/manuals](https://www.v-moda.com/manuals)

简体中文

要获得说明书的打印件，请访问 [V-MODA.com/manuals](https://www.v-moda.com/manuals)

繁體中文

要獲得說明書的打印件，請訪問 [V-MODA.com/manuals](https://www.v-moda.com/manuals)

日本語

本取扱説明書の電子版を以下のページからダウンロード・  
プリントアウトすることができます [V-MODA.com/manuals](https://www.v-moda.com/manuals)

## ROCK SAFELY

Enjoy your music responsibly. According to the American Speech-Language-Hearing Association, “listening to headphones at high volumes for extended periods of time can directly result in lifelong hearing loss”. At V-MODA, we are dedicated to providing an enjoyable listening experience, but we also care greatly about your personal health and safety. We recommend that you listen to your headphones at comfortable volume levels for reasonable periods of time.

### How to enjoy your music responsibly.

- Turn down the volume. A good point of reference is half volume
- Limit listening time. Give your hearing a “time out”


**Be aware of your surroundings.** Do not use headphones during activities such as driving, bicycling or jogging while on public roads. Many states have laws prohibiting such actions. Obey local laws, be alert, and listen responsibly.

**Caution around children.** Keep out of reach of children, the parts included with this product can be a choking hazard. This product is not intended for children under 7 years of age.

## WELCOME

Welcome to V-MODA, the music lifestyle. We sincerely hope you enjoy our headphones, the pinnacle of sound and quality design. With the essence of music at the foundation of all we do, we have precisely engineered our headphones to provide an enjoyable and natural sound signature, which invokes the sense of listening to your music live. **Play Hard. Rock Harder.**

## Package Contents



## USING YOUR HEADPHONES

1. Slide silicone fitting onto earbud




2. Insert earbud in corresponding ear canal  
("L" into left ear, "R" into right ear)



3. Verify the earbud is inserted all the way into your ear, creating a snug fit (similar to an earplug) to ensure highest sound quality and comfort
4. If the earbud does not feel 100% comfortable and inserted into your ear, try swapping the fittings with one of the other three sizes included and match the fittings size in both ears
5. Wear headphones with the cord hanging in front of your head to ensure headphones stay put during strenuous activity

## PROTECTING YOUR HEADPHONES

- Minimize exposure to moisture. Not intended for use while swimming, bathing or showering
- Use provided carrying case while idle
- Keep headphones clean and free of debris
- Do not pull on cable to disconnect plug from device
- Do not wrap cable around device while still plugged in as it puts unnecessary pressure on plug-cord connection



## OPTIMUM CLARITY

For improved clarity, clip the microphone control closer to your neckline.



## USING 3-BUTTON CALL/MUSIC CONTROL FEATURE

### 1. During music playback

- Press center button once to play and pause
- Press and hold + button to increase volume quickly
- Press and hold - button to decrease volume quickly
- Press center button twice for next track
- Press center button three times for previous track

### 2. During calls

- Press center button once to answer (music pauses automatically)
- To refuse an incoming call or to hang up an existing call, press and hold center button for 1-2 seconds, then release



### iOS VERSION COMPATIBILITY

Call/Music control compatible with iPhone 6s Plus, iPhone 6s, iPhone 6 Plus, iPhone 6, iPhone 5s, iPhone 5c, iPhone 5, iPhone 4s, iPhone 4, iPhone 3GS, iPad Pro, iPad Air 2, iPad Air, iPad mini with Retina display, iPad (3rd and 4th gen), iPad mini, iPad 2, iPad, iPod touch (2nd through 6th gen), iPod classic, iPod nano (4th through 7th gen) and iPod shuffle (3rd and 4th gen).

### ANDROID VERSION COMPATIBILITY (📱 ON REMOTE CONTROL)

Compatible also with any Android™ smartphone and all smartphones with a 3.5mm port, results may vary based on OS and App. Audio compatible with smartphones, tablets, portable gaming, computers and any device with a 3.5mm audio port. Select smartphone functionality may vary.

## USING YOUR SPORT EARHOOKS

To provide additional stability and minimize cable noise, please use the included sport earhooks, featuring Active Flex® technology. The independent suspension allows the earbud seal to remain intact and maintain the integrity of sound while flexing with every movement.

1. Start with earbud hanging about one inch below top of sport earhook (the curved end). Insert headphone cable into exterior channel, starting at the top, then moving downward towards the bottom of earhook
2. Secure on ear by wrapping top of sport earhook around the top of your ear with the bottom pointing towards your shoulder. Then insert earbud into your ear
3. Sport earhooks provide ultimate stability and minimize cable noise during even the most vigorous activity



## USING YOUR SPORT FINS

To provide additional stability when you run or workout, please use the included sport fins, featuring Active Flex technology. Sport fins come in three different sizes: try them out and choose the ones with the best fit for your ears.

1. Wrap sport fin around earbud making sure to match the corresponding one ("L" earbud with "L" sport fin, "R" earbud with "R" sport fin)
2. Insert earbud in corresponding ear canal ("L" into left ear, "R" into right ear)
3. Once the earbud is inserted, twist the sport fin and adjust it to rest comfortably in the bowl of your ear. The upper part of the fin fits just under your ear ridge




### NOTE

When you want to use sport fins you need to remove Remix rings if present on earbuds.

## USING YOUR 3D PRINTED CUSTOM CAPS

With the 3D printed custom caps you can revolutionize your in-ear headphones and forge your own personal relic which will be 3D sculpted in Italy and 3D printed in NYC.

1. Install Remix Rings to ensure that 3D printed custom caps are stable
2. Slide 3D printed custom caps onto earbud until the cap reaches the cable creating a snug fit



## TROUBLESHOOTING

If you are experiencing trouble with your headphones, please refer to the troubleshooting guidelines below. If the problem persists, please contact the V-MODA Six Star Service at [V-MODA.com/SUPPORT](http://V-MODA.com/SUPPORT), [support@v-moda.com](mailto:support@v-moda.com) or 1.888.VMODA.LA.

TROUBLE	SUGGESTIONS
No audio	Make certain the audio device's headphone jack is free of debris and that the headphone plug is securely connected.
Lack of or excessive bass or treble	Turn off any audio enhancement features on audio device. Ensure proper fitting is being used.
One earphone is quieter than the other	Remove silicone fitting and briskly blow into the earpiece. (It is possible there is debris inside housing, lodging sound driver in place.) NOTE: do not put your mouth around earbud.
Distorted sound	Check to make sure the problem is not with the audio device or the file to which you are listening. Ensure the EQ settings on the device are set properly. Make certain proper fitting is being used and that you have a snug fit (similar to that of an ear plug) and that the driver is pointed directly towards the ear canal.

### **REPLACEMENT ACCESSORIES**

Replacement silicone fittings, sport earhooks, sport fins, shirt clip and carrying case may be ordered at [V-MODA.com](http://V-MODA.com).

### **CLEANING YOUR HEADPHONES**

To keep your headphones clean, periodically remove the silicone fittings and wash them with a mild detergent and water. Do not forget to rinse and dry them before putting the fittings back on earbuds. Make also sure to wipe earpiece with a dry cloth or equivalent.

### **NOTE ON STATIC ELECTRICITY**

In particularly dry air conditions, mild tingling may be felt on your ears. This is a result of static electricity accumulated in the body, and not a malfunction of the headphones.

## CAUTION

If **serial number** on manual cover or bottom of packaging is missing or defaced, please **return to retailer** immediately.

REGISTER NOW AT

**V-MODA.com/REGISTER**

## Limited Warranty

For a period of two (2) years from the date of retail purchase by the original end-use purchaser, V-MODA warrants that this product is free from any defects in manufacturing, materials and workmanship, under the following conditions:

- V-MODA will repair or replace the product within a reasonable period of time and free of charge for two (2) years from the date of retail purchase by the original end-use purchaser
- Product must be purchased from a V-MODA authorized reseller and delivered to you in new condition, in original packaging. This warranty does not cover products purchased open box, sold as-is, sold by private party resale or any other third party purchases from unauthorized resellers
- This Limited Warranty does not cover defects resulting from cosmetic damage, acts of God, misuse, accidents, commercial use, unauthorized alteration or modification of the product, improper connection, improper use or attempted repair by unauthorized distributors or resellers

- This warranty is void if the label bearing the serial number has been removed or defaced
- To obtain service under this limited warranty, visit [V-MODA.com/WARRANTY](http://V-MODA.com/WARRANTY) to fill out the online warranty form and obtain further information
- To acquire a printable version of this warranty, please visit [V-MODA.com/WARRANTY](http://V-MODA.com/WARRANTY)
- For other customer service inquiries, please e-mail [support@V-MODA.com](mailto:support@V-MODA.com). You may also call 1.888.VMODA.LA Monday through Friday, 9:00 am to 5:00 pm (Pacific Standard Time)
- This limited warranty gives you specific legal rights, and you also may have other rights that vary from State to State or Country to Country. Some places do not allow limitations on implied warranties or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you

## V-MODA Immortal Life Program - Lifetime 50% discount

**We do not judge.** If you abuse your headphones crowdsurfing, stage diving, spelunking or otherwise, the V-MODA Immortal Life Program has your back.

All we ask is that you send the headphones (or what's left of them) to us and we will email you a 50% off VIP Code towards a comparable product from V-MODA.com.

Visit [V-MODA.com/Immortal](http://V-MODA.com/Immortal) for information on the lifetime 50% discount.

Visit [V-MODA.com/Support](http://V-MODA.com/Support), e-mail [support@V-MODA.com](mailto:support@V-MODA.com) or call 1.888.VMODA.LA, Monday through Friday, 9:00am to 5:00pm (Pacific Standard Time), for information on how to get your 50% off VIP Code.

**IMMORTAL  
LIFE  
PROGRAM**



**2YR  
WARRANTY**

For more support please contact V-MODA's  
**Six Star Service [V-MODA.com/SUPPORT](http://V-MODA.com/SUPPORT)**

©2016 V-MODA. All rights reserved. V, V-MODA, FORZA METALLO are registered trademarks of V-MODA.  
U.S. pat. nos. D602475, 8,019,111, and other patents pending.

iPhone®, iPad®, iPod® are trademarks of Apple Inc., registered in the U.S. and other countries.  
The trademark "iPhone" is used with a license from Aiphone K.K.

Android™ is a trademark of Google Inc. and is in no way affiliated with V-MODA.



## PLEASE DO NOT RETURN TO RETAILER

For any issues relating to your V-MODA product,  
please contact our Six Star Service directly.

visit

V-MODA.com/SUPPORT

email

support@V-MODA.com



twitter

@VMODASixStar

skype

V-MODASixStar

call

1.888.VMODALA



# ACTIVATE YOUR WARRANTY

AND

## 50% IMMORTAL LIFE PROGRAM

REGISTER NOW

AT

V-MODA.com/**REGISTER**



IMMORTAL  
**LIFE**  
PROGRAM

**v-moda**