


HARMAN KARDON® SOUNDSTICKS® WIRELESS SPEAKER SYSTEM

Introducing the evolved, wireless offspring of the illustrious SoundSticks II speaker system, which is part of the permanent collection at NYC's Museum of Modern Art (MoMA).

Our stunning work of art is now wireless.



The Harman Kardon® SoundSticks® Wireless speaker system evolved from the SoundSticks II that now resides in the permanent collection of NYC's MoMA. Taking the inspired design of its elder, Harman Kardon engineers improved the aesthetic with slight visual enhancements, and added *Bluetooth*® technology for a more seamless listening experience. Featuring a six-inch subwoofer, eight full-range drivers and 40 watts of amplification, the SoundSticks Wireless delivers the same beautiful sound and pop-culture appeal as its predecessor, only now you can seamlessly stream audio from any of your favorite *Bluetooth*-enabled devices – be it your iPhone, iPad, laptop, tablet or MP3 player.



Effortlessly Stream Beautiful Sound

- Integrated *Bluetooth* technology
- 6-inch (150mm) down-firing subwoofer
- Eight full-range transducers

Fabulous Form Meets Fabulous Function

- Awe-inspiring industrial design
- Touch controls for volume and mute
- 1/8-inch (3.5mm) stereo audio connection

Made for



KEY FEATURES

Harman Kardon® SoundSticks® Wireless Speaker System

Whether you're using the SoundSticks Wireless as complementary speakers to your computer or your home entertainment system, they're sure to make any design scheme more stunning, all while filling your entire room with unparalleled Harman Kardon sound.

HARMAN TrueStream™



HARMAN TrueStream™ allows you to wirelessly connect *Bluetooth*-enabled devices to get superior sound quality without the need for wires or docking.

Integrated *Bluetooth* Technology



No need to mess with wires. Play audio from your *Bluetooth*-enabled devices (such as your tablet, smartphone, laptop and MP3 player) with HARMAN TrueStream™, which offers audiophile-quality sound.

6-inch (150mm) Down-Firing Subwoofer



The down-firing subwoofer keeps your lows consistent, precise and powerful, all while reducing distortion and noise when listening to audio at higher levels. The flared port also increases bass output, and can be easily adjusted to fit any room.

Eight Full-Range Transducers



Experience audio as it was intended to sound with the powerful SoundSticks Wireless satellite speakers. Their full-range, easy-to-adjust transducers are designed to fill the room with crisp, clear audio.

Awe-Inspiring Industrial Design



The stunning, translucent speakers were a hit with art lovers worldwide, earning them a pedestal in homes, offices and the permanent collection of NYC's MoMA.

Touch Controls for Volume and Mute



Raise, lower and mute volume with a simple touch; it's exceptionally easy to use.

1/8-inch (3.5mm) Stereo Audio Connection



The SoundSticks Wireless connects to virtually any media player, offering maximum flexibility. Use it with your iPhone, iPad, computer, tablet, MP3 player and other popular media devices.

SPECIFICATIONS

beautiful/sound
harman/kardon
by HARMAN

Harman Kardon® SoundSticks® Wireless Speaker System

Engineered to turn all your audio into works of art.

What's included:

- 1 Harman Kardon SoundSticks Wireless Speaker System
- 1 power cable
- 1 power adapter
- 1 speaker cable
- 1 speaker adapter
- Instructions

HARMAN KARDON SOUNDSTICKS WIRELESS

SYSTEM

- Frequency response: 44Hz – 20kHz
- Audio input connection: 1/8" (3.5mm) stereo
- Power consumption: 65W (maximum); 4W (idle)

SUBWOOFER

- Low-frequency transducer: 6" (150mm) down-firing cone
- Amplifier output power: 20W RMS
- Dimensions (W x H): 9-3/16" x 10-3/16" (232mm x 258mm)
- Weight: 4.9 lb (2.2kg)

SATELLITES

- Full-range transducers: Four x 1" (25mm) per channel
- Amplifier output power: 10W RMS per channel
- Dimensions (W x H): 2" x 10" (51mm x 254mm)
- Weight: 1.5 lb (0.7kg)



Go online to register your purchase and access tips that will show you just how beautiful sound can be.

www.harmankardon.com/registermyproduct

HARMAN

HARMAN International Industries, Incorporated
8500 Balboa Boulevard, Northridge, CA 91329 USA
www.harmankardon.com

© 2012 HARMAN International Industries, Incorporated. All rights reserved.
Harman Kardon and SoundSticks are trademarks of HARMAN International Industries, Incorporated, registered in the United States and/or other countries. The "beautiful/sound" logo and HARMAN TrueStream are trademarks of HARMAN International Industries, Incorporated. The Bluetooth® word mark and logo are registered trademarks and are owned by Bluetooth SIG, Inc., and any use of such marks by HARMAN International Industries, Incorporated, is under license. iPad, iPhone and iPod are trademarks of Apple Inc., registered in the U.S. and other countries. "Made for iPod," "Made for iPhone," and "Made for iPad" mean that an electronic accessory has been designed to connect specifically to iPod, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone, or iPad may affect wireless performance. Features, specifications and appearance are subject to change without notice.

SOUNDSTICKS® WIRELESS


Setup Guide



harman/kardon®
by HARMAN

SOUNDSTICKS® WIRELESS

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. Do not expose this apparatus to dripping or splashing and ensure that no objects filled with liquids, such as vases, are placed on the apparatus.
16. To completely disconnect this apparatus from the AC Mains, disconnect the power supply cord plug from the AC receptacle.
17. The mains plug of the power supply cord shall remain readily operable.
18. Do not expose batteries to excessive heat such as sunshine, fire or the like.
19. Do not place naked flame sources, such as lighted candles, on the apparatus.



SOUNDSTICKS® WIRELESS

Specifications*

System

Frequency range: 44Hz – 20kHz

Power consumption: 4W idle,
65W maximum

Subwoofer

Transducer (1): 6" woofer

Amplifier output power: 20W RMS

Dimensions (W x H): 9–3/16" x 10–3/16"
(232mm x 258mm)





Weight: 4 lb (2.2kg)

Satellite

Transducers (4): 1" full–range per channel
Amplifier output power: 10W RMS
per channel

Dimensions (W x H): 2" x 10"
(51mm x 254mm)






Weight: 1.5 lb (0.7kg)

			
<p>Step 1. Place individual SoundSticks (satellites) beside monitor/computer.</p> <p>Place subwoofer as desired, but placement under desk provides best performance.</p>	<p>Step 2. Connect satellite cables to the dual subwoofer cable. Also connect the input cable to the subwoofer input cable jack.</p>	<p>Step 3. Insert SoundSticks input cable into the computer or other audio device.</p>	<p>Step 4. Plug power cord into power adapter.</p>

Troubleshooting

Symptom	Possible problem	Solution
<p>No sound from SoundSticks speaker system.</p>	<p>No power to subwoofer. Power adapter plug not inserted correctly.</p> <p>No volume or low volume.</p>	<p>Ensure power supply is connected to live power source and is properly connected to subwoofer. Please note: When subwoofer is powered, a power LED should light.</p> <p>Place plug with arrow symbol facing UP into the subwoofer.</p> <p>Touch the volume “Up” (+) pad on the volume control satellite to unmute and/or increase the system volume level.</p> <p>Note: Touching the volume “Down” (–) pad lowers the system volume. Touching both (+) and (–) volume control pads at the same time will mute the system.</p>

*These specifications are subject to change without notice.

				
<p>Step 5. Plug power adapter into subwoofer.</p>	<p>Step 6. Plug power cord into wall receptacle.</p>	<p>Step 7. Push the subwoofer volume knob/power ON/OFF button. Unit is on when the LED is lit. Use the subwoofer volume knob to balance the subwoofer's volume with that of the satellites.</p>	<p>Step 8. Turn on Soundsticks Wireless. (Unit will automatically enter pairing mode.) Put <i>Bluetooth</i>-enabled device in pairing mode. Select "Soundsticks Wireless" on device's pairing list. Passcode (if required) is 0000. When pairing is successful, Soundsticks Wireless' <i>Bluetooth</i> LED will illuminate.</p>	<p>Step 9. Adjust volume level by touching + or – button. Touching both the + and – buttons mutes the audio. When muted, touching either button unmutes the audio.</p>

www.harmanardon.com

Symptom	Possible problem	Solution
No sound from subwoofer, only satellites.	Subwoofer volume control set at minimum.	Rotate subwoofer volume control clockwise until relative volume level is appropriate.
No sound from satellites, only subwoofer.	Satellites not connected to subwoofer.	Check connection of satellites to subwoofer.
High frequencies sound dull.	Satellites not positioned properly.	Position and tilt (angle) loudspeakers toward listener. The sound from the satellites is very directional due to the four–element linear array design.
No sound from <i>Bluetooth</i> device.	Device not paired.	Pair device with Soundsticks Wireless. <i>Bluetooth</i> LED illuminates when pairing is successful.

This product is intended to be supplied by a listed direct plug–in power unit marked "Class 2" and output rated 16V DC minimum 1.5 A.

*Audio from a paired *Bluetooth* device will mix with the audio from a connected audio device. To listen to only one device, stop play on the other device.

harman/kardon®

HARMAN

HARMAN International Industries, Inc.
8500 Balboa Boulevard, Northridge, CA 91329 USA

www.harmankardon.com

Made in P.R.C.

© 2012 HARMAN International Industries, Incorporated. All rights reserved.

Features, specifications and appearance are subject to change without notice.

Harman Kardon and SoundSticks are trademarks of HARMAN International Industries, Incorporated, registered in the United States and/or other countries.

The *Bluetooth* word mark and logo are registered trademarks and are owned by the Bluetooth SIG, Inc., and any use of such marks by HARMAN International Industries, Incorporated, is under license.

Part No. 950-0454-001 Rev. A

