


GameSir G5

User Manual



We hope this manual can answer the questions you may have. If you have any further questions, please contact us:

- Facebook: <https://www.facebook.com/myGamesir>
- Customer Service: cs@gamesir.hk
- For More Support: <https://gamesir.hk>



1. Product Description

Supporting Bluetooth connection, GameSir G5 is compatible with Android devices (version 4.0 and above), iOS devices (version iOS 7.0 and above). It is specially designed for MOBA and FPS games. Its characteristic trackpad and multi-button layout, which corresponds with game interface, can make game control much more efficient and accurate. Download the most popular game titles in GameSir G5 adapted version through HappyChick Emulator and GameSir World app, or remap your favorite game with GameSir Remapper A2, it provides the better gaming experience with brand new way to control!

2. Product Specifics

Product Name	GameSir G5 Gaming Controller	Product Model	GameSir-G5
Working Platform	Android / iOS	Working Temperature	-20°C - 65°C
		Working Humidity	20 - 80%
Working Mode	Android standard / iOS standard / Dinput	Connection	Bluetooth 4.1
Charging Voltage	3.7V ~ 5.2V	Charging Time	2-3 hrs
Charging Current	400mA	Battery Capacity	800 mAh
Package Size	7.28 x 5.43 x 3.11 in.	Working Distance	Approx. 22.97 ft.
Product Size	6.38 x 3.98 x 2.66 in.	Net Weight	0.55 lb.

3. Product Overview



4.Function

Turn on / off

- Turn on: Long press "HOME" button for 2 seconds to turn on the gamepad.
- Turn off: Long press "HOME" button for 2 seconds to turn off the gamepad.

Low battery indicator

- When usable power is lower than 10%, HOME button turns red and flashes slowly. Please charge the gamepad timely.
- When usable power is lower than 5%, the gamepad will turn off automatically.

* HOME button flashes slowly in green when charging. HOME button keeps in solid green when fully charged.

Check the power

Quickly click POWER button to see indicator lights showing remain power. They recover to original status after showing power for 3 seconds continuously. Indicator lights instruction:

- 1)Fully charged: 75%~100%;
- 2)Reverse 3 lights: 50%~75%;
- 3)Reverse 2 lights: 25%~50%;
- 4)Reverse 1 light: 1%~25%;

Automatic turning off

- When the gamepad is on, it will turn off automatically when there is no connection for 2 minutes;
- When the gamepad is connected, it will turn off automatically when there is no control for 5 minutes;

TURBO function

The function is commonly adopted in shooting games. You finger gets fatigue while pressing the shooting button unceasingly, but TURBO function can realize continuous and strengthened shooting by holding still the TURBO button, meanwhile relieve your finger from fatigue.

Set up: Press still TURBO button, then press still the buttons you need to set up TURBO function;

Undo: Double click TURBO button, then clear all the set-up TURBO buttons; Adjust TURBO frequency: Press still TURBO, then press UP or DOWN of D-pad. Press UP to quicken, each press quickens 10ms. Press DOWN to slow, each press slows 10ms.

5.Connect The Gamepad

- 1) Make sure Bluetooth in your device is on
- 2) When the gamepad is off, long press HOME button for 2 seconds. It will flash quickly and enter pair mode:
 - a. Android phones: Enter GameSir World app > GameSir Spirit > Searching gamepad, and connect the gamepad with your phone.
Scan the QR Code or browse the link below to download GameSir World app.



<https://gamesir.hk/gsw>

- b. iOS phones: Enter Happy Chick Emulator > (gamepad icon) > Searching GameSir, and connect the gamepad with your phone.Caution: GameSir G5 only works on the games downloaded through Happy Chick Emulator on iOS devices.
Scan the QR Code or browse the link below to download Happy Chick.



<https://gamesir.hk/happychick>

When light indicators show (   ) and HOME button keeps solid, the gamepad is successfully connected. Enjoy your games!

For the complete setup tutorial, please visit <https://gamesir.hk/pages/g5-tutorial>

FAQs

How does the gamepad get connected?

Bluetooth connection for Android/iOS devices

Where can I download the games for GameSir G5?

- For Android users: please install GameSir World app to acquire the game list. You are also required to use GameSir Remapper A2 to active the smartphone before playing. Please check the URL for the detailed remap procedures: <https://gamesir.hk/pages/g5-tutorial>
- For iOS users: please install Happy Chick Emulator and download the latest GameSir G5 adapted games directly from the app.

What games can be supported?

GameSir G5 is mainly designed for MOBA and FPS games in smartphones, such as Arena of Valor, Mobile Legends, Rules of Survival, Knives Out and etc. More popular MOBA and FPS game titles will be listed on the apps consistently.

Others

- Inadequate power of the built-in battery may lead to failure of turning on. Please charge the gamepad with an USB cable and try turning on again.
- Please keep the gamepad close to your devices to prevent sudden disconnection. Try re-connection if such cases occur.
- RESET: There is a RESET hole at back side of the gamepad. Use some sharp bars such as a toothpick to stick into it to have the gamepad reset.

Troubleshooting

Why does GameSir G5 failed to control the game?

- If you are Android user, make sure the game is gamepad-supported, or the remap function is activated with GameSir Remapper A2. If you are iOS user, make sure the game you play is downloaded from Happy Chick Emulator.
- Extra button remap settings are needed in games to play normally. Please tap the floating blue icon in game to remap the buttons.