

Your Current TV Remote Can Control Your SB400/SB500.

After following the steps outlined in this guide, your cable or satellite remote will adjust the volume output from your soundbar system. Please **Note:** If you have a DirecTV remote control, use the DirecTV remote guide included along with this instruction sheet.

The steps involve pressing the Volume, Mute, and Power buttons of your preferred remote control with the remote positioned close to the numeric display of the soundbar. Once complete, the soundbar will respond to the buttons it has learned from your preferred remote control.

To insure accuracy, the learning routine records each button's commands twice, then confirms a successful button learning.


ZVOX® Audio has specific instruction sets available for a variety of popular remote controls. These instructions provide an alternate method for configuring your SB400/SB500 to respond to your preferred remote control. If you cannot easily teach the SB400/SB500 to respond to your preferred remote control, please contact ZVOX Audio about additional instructions for your preferred remote control.

PREPARE

1

Stand or sit within easy reach of the soundbar's control buttons (the end on your right hand side).

You will need to press two buttons on the SB400/SB500 end panel to start the learning process. Then you will press four buttons on your preferred remote control.




2

Locate the following buttons on your remote control:

- 1** VOLUME UP
- 2** VOLUME DOWN
- 3** MUTE
- 4** POWER

The learning process involves pressing these four buttons in sequence.


This remote is only an example. Your remote is probably different. Please locate these buttons on your remote.



3

Press both VOLUME buttons on the soundbar until "Lrn" appears (about 4 seconds). Then release both VOLUME buttons.

- Get ready to press **VOLUME UP** on the Remote Control.



Error Message of the SB400/SB500 Learning Routine

noCh

If you see the "no change" message (noCh) during the learning routine, the SB400/SB500 system did not accept the infrared code. The current step in the learning routine will repeat.

LEARN BUTTONS

volume up

1

UP 1

When **UP 1** appears, press VOLUME UP for 1 second.

You should see **---**

rEP

When **rEP** appears, press VOLUME UP for 1 second, again.

Good

You should see **---** followed by **Good**.

volume down

2

dn 2

When **dn 2** appears, press VOLUME DOWN for 1 second.

You should see **---**

rEP

When **rEP** appears, press VOLUME DOWN for 1 second, again.

Good

You should see **---** followed by **Good**.

mute

3

-- 3

When **-- 3** appears, press MUTE for 1 second.

You should see **---**

rEP

When **rEP** appears, press MUTE for 1 second, again.

Good

You should see **---** followed by **Good**.

power

4

Pr 4

When **Pr 4** appears, press POWER for 1 second.

You should see **---**

rEP

When **rEP** appears, press POWER for 1 second, again.

Good

You should see **---** followed by **Good**.

YOU ARE DONE!