











ITEM DESCRIPTION	MICROPHONE	CABLES								
	Directional Microphone DM-E1	USB Cable IFC-500U II	USB Cable IFC-500U	USB Cable IFC-400U	USB Cable IFC-200U	USB Cable IFC-100U	USB Cable IFC-600PCU	USB Cable IFC-400PCU	USB Cable IFC-150U II	USB Cable IFC-150AB III
										
ITEM CODE	1429C001 [Ⓢ]	9132B001 [Ⓢ]	1893B001 [Ⓢ]	3225C001 [Ⓢ]	1892B001 [Ⓢ]	3224C001 [Ⓢ]	1015C001 [Ⓢ]	9370A001 [Ⓢ]	9131B001 [Ⓢ]	3227C001 [Ⓢ]
UPC CODE	013803 275346	013803 237115	013803 078336	013803 309096	013803 078329	013803 309089	013803 267877	013803 038361	013803 237108	013803 309119
SUGGESTED LIST PRICE (\$)	400.00	50.00	50.00	70.00	35.00	60.00	16.00	16.00	35.00	60.00
DEALER NET PRICE (\$)	225.00	32.00	32.00	45.00	21.00	36.00	11.00	11.00	21.00	36.00
MAP* (\$)	249.99	—	—	—	—	—	—	—	—	—
1D X Mark II	•	•							•	
1D X	•				•					
1Ds Mark III			•		•					
1Ds Mark II/1Ds								•		
1D Mark IV/1D Mark III	• ^a		•		•					
1D Mark II n/1D Mark II/1D								•		
D2000										
5DS/5DS R	•	•							•	
5D Mark IV	•	•							•	
5D Mark III	•		•		•					
5D Mark II	•		•		•					
5D								•		
6D Mark II	•		•		•			•		
6D	•		•		•					
7D Mark II	•	•							•	
7D	•		•		•					
80D	•		•		•			•		
77D	•		•		•			•		
70D	•		•		•			•		
60D	•		•		•					
50D/40D			•		•					
30D/20D/10D								•		
D60/D30										
Rebel T7i	•		•		•			•		
Rebel T6s/T6i	•		•		•			•		
Rebel T5i/T4i	•		•		•					
Rebel T3i/T2i	•		•		•					
Rebel T1i			•		•					
Rebel T6			•		•			•		
Rebel T5/T3			•		•			• ^a		
Rebel SL2	•		•		•			•		
Rebel SL1	•		•		•					
Rebel XSi/Rebel XS			•		•					
Digital Rebel XTi/XT								•		
Digital Rebel								•		
EOS R	•			•		•				•
EOS M5	•						•			
EOS M6	•						•			
EOS M50	•						•			
EOS M3	•		•		•			•		
EOS M100/M10								•		
EOS M	•		•		•					
REMARKS	a - For 1D Mark IV		15.4 ft. / 4.7m		6.2 ft. / 1.9m			a - For T5 (For Mac/Windows)		











Note: **Bold products** are current, others shown for reference only.

* Please see Canon U.S.A., Inc.'s then-current Imaging Technologies and Communications Group Camera and Video Products Unilateral Minimum Advertised Price Policy (the "Policy") for the terms and conditions governing Minimum Advertised Pricing (MAP). Also, please see the terms and conditions of Canon U.S.A., Inc.'s Co-op Advertising Program which conditions reimbursement for co-op advertising in compliance with the Policy.

Ⓢ "Dealers do not earn any Co-op Advertising Allowance on purchases of these products."

ITEM DESCRIPTION	CABLES (CONT.)						OTHERS			
	USB Cable IFC-150AB II	USB Cable IFC-40AB II	USB Cable IFC-40AB III	Mini-HDMI Cable HTC-100	Stereo AV Cable AVC-DC400ST	Stereo Video Cable STV-250N	PCMCIA Adapter	GPS Receiver GP-E2†, ††	GPS Receiver GP-E1†	Wireless File Transmitter WFT-E8A
ITEM CODE	9133B001 [Ⓞ]	9134B001 [Ⓞ]	3226C001 [Ⓞ]	2384B001 [Ⓞ]	4076B001 [Ⓞ]	3067A002 [Ⓞ]	3229A002 [Ⓞ]	6363B001 [Ⓞ]	6364B001 [Ⓞ]	1173C001 [Ⓞ]
UPC CODE	013803 237122	013803 237139	013803 309102	013803 086737	013803 119343	013803 605983	750845 722413	013803 148596	013803 148701	013803 271676
SUGGESTED LIST PRICE (\$)	35.00	30.00	50.00	80.00	25.00	22.00	32.00	390.00	390.00	900.00
DEALER NET PRICE (\$)	21.00	18.00	32.00	48.00	17.00	13.00	21.00	230.00	230.00	539.00
MAP* (\$)	—	—	—	—	—	—	—	—	—	599.00
1D X Mark II				●						●
1D X				●	●			●	●	
1Ds Mark III							●			
1Ds Mark II/1Ds							●			
1D Mark IV/1D Mark III				● ^a	● ^a		●			
1D Mark II n/1D Mark II/1D							●			
D2000							●			
5DS/5DS R	●	●		●				●		
5D Mark IV	●	●		●						
5D Mark III				●	●		●	● ^a		
5D Mark II				●		●	●			
5D							●			
6D Mark II				●						
6D				●	●			●		
7D Mark II	●	●		●						
7D				●	●		●	● ^a		
80D				●				●		
77D				●				●		
70D				●	●			●		
60D				●	●					
50D/40D				● ^b			●			
30D/20D/10D							●			
D60/D30							●			
Rebel T7i				●				● [‡]		
Rebel T6s/T6i				●	●			●		
Rebel T5i/T4i				●	●			●		
Rebel T3i/T2i				●	●					
Rebel T1i				●						
Rebel T6				●				●		
Rebel T5/T3				●				● ^b		
Rebel SL2				●				● [‡]		
Rebel SL1				●	●			●		
Rebel XSi/Rebel XS				●						
Digital Rebel XTi/XT							●			
Digital Rebel							●			
EOS R			●	●				● ^{‡‡}		
EOS M5										
EOS M6										
EOS M50										
EOS M3				●						
EOS M100/M10				● ^c						
EOS M				●	●			●		
REMARKS				a - For 1D Mark IV b - For 50D c - For M10	a - For EOS-1D Mark IV		For all Compad Flash Cards	a - Firmware upgrade required. b - For Rebel T5		

† In certain countries and regions, the use of GPS may be restricted. Therefore, be sure to use GPS in accordance with the laws and regulations of your country or region. Be particularly careful when traveling outside your home country.
 †† As a signal is received from GPS satellites, take sufficient measures when using in locations where the use of electronics is regulated.
 ††† When the EOS 7D is used with the GP-E2 the following restrictions will apply: a) geotagging function will not work for movies while recording; b) geotagging features will not work for movies when using the Map Utility; c) electronic compass information and automatic time setting is not available; d) transmission via the hot shoe is not possible. ‡ The digital compass function is not supported. ††† The digital compass cannot be used with the camera, and the shooting direction is not recorded.
 Note: **Bold products** are current, others shown for reference only.
 * Please see Canon U.S.A., Inc.'s then-current Imaging Technologies and Communications Group Camera and Video Products Unilateral Minimum Advertised Price Policy (the "Policy") for the terms and conditions governing Minimum Advertised Pricing (MAP).
 Also, please see the terms and conditions of Canon U.S.A., Inc.'s Co-op Advertising Program which conditions reimbursement for co-op advertising in compliance with the Policy.
 Ⓞ "Dealers do not earn any Co-op Advertising Allowance on purchases of these products."

ITEM DESCRIPTION	OTHERS (CONT.)		POWER DRIVE BOOSTERS & CHARGERS							
	Wireless File Transmitter WFT-E7A (Version 2)	Wi-Fi Adapter W-E1	Ni-MH Pack NP-E3	Compact Power Adapter CA-PS700	Car Battery Cable CB-570	Car Battery Charger CBC-E6	Battery Charger LC-E19	Battery Charger LC-E17	Battery Charger LC-E12	Battery Charger LC-E10
										
ITEM CODE	5754B009 [⊕]	1716C001 [⊕]	7084A002 [⊕]	7875A002 [⊕]	8466A001 [⊕]	3350B001 [⊕]	1170C002 [⊕]	9968B001 [⊕]	6781B001 [⊕]	5109B001 [⊕]
UPC CODE	013803 237467	013803 282658	013803 010381	013803 015751	013803 026184	013803 104424	013803 271669	013803 247848	013803 156706	013803 137941
SUGGESTED LIST PRICE (\$)	1,300.00	50.00	170.00	65.00	50.00	270.00	540.00	70.00	70.00	70.00
DEALER NET PRICE (\$)	764.00	30.00	105.00	41.00	32.00	140.00	320.00	40.00	40.00	40.00
MAP* (\$)	849.99	—	—	—	—	—	—	—	—	—
1D X Mark II							•			
1D X					•		•			
1Ds Mark III					•		•			
1Ds Mark II/1Ds			•							
1D Mark IV/1D Mark III					•		•			
1D Mark II n/1D Mark II/1D			•							
D2000										
5DS/5DS R	•	•			•	•				
5D Mark IV	•				•	•				
5D Mark III	•				•	•				
5D Mark II					•	•				
5D					•					
6D Mark II					•	•				
6D					•	•				
7D Mark II	•	•			•	•				
7D					•	•				
80D					•	•				
77D							•			
70D					•	•				
60D					•	•				
50D/40D					•					
30D/20D/10D					• ^a					
D60/D30										
Rebel T7i							•			
Rebel T6s/T6i							•			
Rebel T5i/T4i				•						
Rebel T3i/T2i				•						
Rebel T1i				•						
Rebel T6				•						•
Rebel T5/T3				•						•
Rebel SL2							•			
Rebel SL1				•					•	
Rebel XSi/Rebel XS				•						
Digital Rebel XTi/XT				•						
Digital Rebel										
EOS R	• [‡]				•	•				
EOS M5				•			•			
EOS M6				•			•			
EOS M50				•				•		
EOS M3				•			•		•	
EOS M100/M10				•				•		
EOS M				•				•		
REMARKS			Includes connect cover	Body or body with Grip (Requires DC Coupler)	a - For 30D only					

‡ If WFT-E7's firmware is older than Version 2, updating is required. Interface Cable IFC-40AB III or IFC-150AB III is required.












Note: **Bold products** are current, others shown for reference only.

* Please see Canon U.S.A., Inc.'s then-current Imaging Technologies and Communications Group Camera and Video Products Unilateral Minimum Advertised Price Policy (the "Policy") for the terms and conditions governing Minimum Advertised Pricing (MAP). Also, please see the terms and conditions of Canon U.S.A., Inc.'s Co-op Advertising Program which conditions reimbursement for co-op advertising in compliance with the Policy.

⊕ "Dealers do not earn any Co-op Advertising Allowance on purchases of these products."

POWER DRIVE BOOSTERS & CHARGERS (CONT.)										
ITEM DESCRIPTION	Battery Charger LC-E8E	Battery Charger LC-E6	Battery Charger CB-2LW	USB Power Adapter PD-E1	AC Adapter AC-E19	AC Adapter AC-E6N	DC Coupler DR-E19	DC Coupler DR-E18	DC Coupler DR-E17	DC Coupler DR-E15
ITEM CODE	4520B003 [Ⓞ]	3348B001 [Ⓞ]	0763B001 [Ⓞ]	3250C002 [Ⓞ]	1171C002 [Ⓞ]	1425C002 [Ⓞ]	1172C001 [Ⓞ]	0250C001 [Ⓞ]	1431C001 [Ⓞ]	8623B001 [Ⓞ]
UPC CODE	013803 125856	013803 104417	013803 057461	013803 309614	013803 276305	013803 275247	013803 275513	013803 253054	013803 275377	013803 224306
SUGGESTED LIST PRICE (\$)	60.00	80.00	50.00	190.00	700.00	110.00	350.00	60.00	60.00	40.00
DEALER NET PRICE (\$)	40.00	50.00	34.00	116.00	400.00	70.00	200.00	36.00	36.00	24.00
MAP* (\$)	-	-	-	-	-	-	-	-	-	-
1D X Mark II					•		•			
1D X					•		•			
1Ds Mark III							•			
1Ds Mark II/1Ds							•			
1D Mark IV/1D Mark III							•			
1D Mark II n/1D Mark II/1D										
D2000										
5DS/5DS R		•				•				
5D Mark IV		•				•				
5D Mark III		•				•				
5D Mark II		•								
5D										
6D Mark II		•				•				
6D		•				•				
7D Mark II		•				•				
7D		•				•				
80D		•				•				
77D						•	•			
70D		•				•				
60D		•				•				
50D/40D										
30D/20D/10D										
D60/D30										
Rebel T7i						•		•		
Rebel T6s/T6i						•		•		
Rebel T5i/T4i	•									
Rebel T3i/T2i	•									
Rebel T1i										
Rebel T6										
Rebel T5/T3										
Rebel SL2						•		•		
Rebel SL1										•
Rebel XSi/Rebel XS										
Digital Rebel XTi/XT			•							
Digital Rebel										
EOS R		•		•		•				
EOS M5									•	
EOS M6									•	
EOS M50									•	
EOS M3									•	
EOS M100/M10										
EOS M										
REMARKS			Replacement battery charger (NB-2LH batteries)	Charging is only available for LP-E6N (not LP-E6)						











Note: **Bold products** are current, others shown for reference only.
 * Please see Canon U.S.A., Inc.'s then-current Imaging Technologies and Communications Group Camera and Video Products Unilateral Minimum Advertised Price Policy (the "Policy") for the terms and conditions governing Minimum Advertised Pricing (MAP).
 Also, please see the terms and conditions of Canon U.S.A., Inc.'s Co-op Advertising Program which conditions reimbursement for co-op advertising in compliance with the Policy.
 Ⓞ "Dealers do not earn any Co-op Advertising Allowance on purchases of these products."

	POWER DRIVE BOOSTERS & CHARGERS (CONT.)				BATTERY GRIP					
ITEM DESCRIPTION	DC Coupler DR-E12	DC Coupler DR-E10	DC Coupler DR-E8	DC Coupler DR-E6	Battery Grip BG-E22	Battery Grip BG-E21	Battery Grip BG-E20	Battery Grip BG-E18	Battery Grip BG-E16	Battery Grip BG-E14
										
ITEM CODE	6785B001 [Ⓞ]	5112B001 [Ⓞ]	4518B001 [Ⓞ]	3352B001 [Ⓞ]	3086C002 [Ⓞ]	2130C001 [Ⓞ]	1485C001 [Ⓞ]	0050C001 [Ⓞ]	9130B001 [Ⓞ]	8471B001 [Ⓞ]
UPC CODE	013803 156737	013803 133486	013803 124392	013803 104448	013803 306545	013803 288025	013803 281453	013803 250497	013803 237061	013803 222210
SUGGESTED LIST PRICE (\$)	40.00	40.00	40.00	70.00	490.00	300.00	490.00	220.00	320.00	270.00
DEALER NET PRICE (\$)	24.00	24.00	24.00	42.00	290.00	180.00	290.00	136.00	200.00	167.00
MAP* (\$)	—	—	—	—	—	—	—	—	—	—
1D X Mark II										
1D X										
1Ds Mark III										
1Ds Mark II/1Ds										
1D Mark IV/1D Mark III										
1D Mark II n/1D Mark II/1D										
D2000										
5DS/5DS R				•						
5D Mark IV				•			•			
5D Mark III				•						
5D Mark II				•						
5D										
6D Mark II				•		•				
6D				•						
7D Mark II				•					•	
7D				•						
80D				•						•
77D				•						•
70D				•						
60D				•						
50D/40D										
30D/20D/10D										
D60/D30										
Rebel T7i										
Rebel T6s/T6i								•		
Rebel T5i/T4i				•						
Rebel T3i/T2i				•						
Rebel T1i										
Rebel T6		•								
Rebel T5/T3		•								
Rebel SL2										
Rebel SL1										
Rebel XSi/Rebel XS										
Digital Rebel XTi/XT										
Digital Rebel										
 EOS R				•	•					
EOS M5										
EOS M6										
EOS M50	•									
EOS M3										
EOS M100/M10	•									
EOS M	•									
REMARKS										










Note: **Bold products** are current, others shown for reference only.

* Please see Canon U.S.A., Inc.'s then-current Imaging Technologies and Communications Group Camera and Video Products Unilateral Minimum Advertised Price Policy (the "Policy") for the terms and conditions governing Minimum Advertised Pricing (MAP). Also, please see the terms and conditions of Canon U.S.A., Inc.'s Co-op Advertising Program which conditions reimbursement for co-op advertising in compliance with the Policy.

Ⓞ "Dealers do not earn any Co-op Advertising Allowance on purchases of these products."

ITEM DESCRIPTION	BATTERY GRIP (CONT.)		BATTERY PACK							
	Battery Grip BG-E13	Battery Grip BG-E11	Battery Pack LP-E19	Battery Pack LP-E17	Battery Pack LP-E12	Battery Pack LP-E10	Battery Pack LP-E8	Battery Pack LP-E6N	Battery Pack LP-E5	Battery Pack LP-E4N†
										
ITEM CODE	8038B001Ⓢ	5261B001Ⓢ	1169C002Ⓢ	9967B002Ⓢ	6760B002Ⓢ	5108B002Ⓢ	4515B002Ⓢ	9486B002Ⓢ	3039B001Ⓢ	5751B002Ⓢ
UPC CODE	013803 204261	013803 142716	013803 271652	013803 247831	013803 155846	013803 133455	013803 124354	013803 240054	013803 096446	013803 145427
SUGGESTED LIST PRICE (\$)	300.00	490.00	230.00	75.00	75.00	75.00	70.00	100.00	70.00	230.00
DEALER NET PRICE (\$)	180.00	290.00	135.00	45.00	45.00	45.00	45.00	60.00	45.00	135.00
MAP* (\$)	—	—	—	—	—	—	—	—	—	—
1D X Mark II			•							•
1D X			•							•
1Ds Mark III			•							•
1Ds Mark II/1Ds										
1D Mark IV/1D Mark III			•							•
1D Mark II n/1D Mark II/1D										
D2000										
5DS/5DS R		•						•		
5D Mark IV								•		
5D Mark III		•						•		
5D Mark II								•		
5D										
6D Mark II								•		
6D	•							•		
7D Mark II								•		
7D								•		
80D								•		
77D				•						
70D								•		
60D								•		
50D/40D										
30D/20D/10D										
D60/D30										
Rebel T7i				•						
Rebel T6s/T6i				•						
Rebel T5i/T4i							•			
Rebel T3i/T2i							•			
Rebel T1i									•	
Rebel T6						•				
Rebel T5/T3						•				
Rebel SL2				•						
Rebel SL1					•					
Rebel XSi/Rebel XS									•	
Digital Rebel XTi/XT										
Digital Rebel										
EOS R								•		
EOS M5				•						
EOS M6				•						
EOS M50					•					
EOS M3				•						
EOS M100/M10					•					
EOS M					•					
REMARKS									Rechargeable Lithium-ion Battery Pack.	

† When using Battery Pack LP-E4/E4N with the EOS-1D X Mark II camera the continuous shooting speed and maximum burst rate will be lowered when compared to using the Battery Pack LP-E19.
 Note: **Bold products** are current, others shown for reference only.
 * Please see Canon U.S.A., Inc.'s then-current Imaging Technologies and Communications Group Camera and Video Products Unilateral Minimum Advertised Price Policy (the "Policy") for the terms and conditions governing Minimum Advertised Pricing (MAP).
 Also, please see the terms and conditions of Canon U.S.A., Inc.'s Co-op Advertising Program which conditions reimbursement for co-op advertising in compliance with the Policy.
 Ⓢ "Dealers do not earn any Co-op Advertising Allowance on purchases of these products."

ITEM DESCRIPTION	BATTERY PACK (CONT.)	REMOTE CONTROLLERS							MAGNIFIER	
	Battery Pack BP-511A	Wireless Remote Control BR-E1	Wireless Remote Controller RC-6	Wireless Controller LC-5	Timer Remote Control TC-80N3	Remote Controller Adapter RA-E3	Remote Switch RS-80N3	Remote Switch RS-60E3	Magnifier MG-Ef†	Magnifier MG-Eb†
										
ITEM CODE	9200A001Ⓢ	2140C001Ⓢ	4524B001Ⓢ	0295B001Ⓢ	2477A002Ⓢ	1157C001Ⓢ	2476A001Ⓢ	2469A002Ⓢ	0048C001Ⓢ	0047C001Ⓢ
UPC CODE	013803 035681	013803 288254	013803 123944	013803 054408	082966 581564	013803 270549	082966 581571	082966 581359	013803 250435	013803 250428
SUGGESTED LIST PRICE (\$)	70.00	50.00	30.00	680.00	210.00	45.00	70.00	30.00	45.00	45.00
DEALER NET PRICE (\$)	45.00	32.00	19.00	426.00	133.00	27.00	45.00	19.00	27.00	27.00
MAP* (\$)	—	—	—	—	—	—	—	—	—	—
1D X Mark II				•	•		•			
1D X				•	•		•			
1Ds Mark III				•	•		•			
1Ds Mark II/1Ds				•	•		•			
1D Mark IV/1D Mark III				•	•		•			
1D Mark II n/1D Mark II/1D				•	•		•			
D2000				•	•		•			
5DS/5DS R			•	•	•		•			
5D Mark IV			•	•	•		•			
5D Mark III			•	•	•		•			
5D Mark II			•	•	•		•			
5D	•		•	•	•		•			
6D Mark II		•	•	•	•		•			
6D			•	•	•		•			
7D Mark II			•	•	•		•			
7D			•	•	•		•			
80D			•		•‡	•		•		•
77D		•	•		•‡	•		•	•	
70D			•		•‡	•		•		•
60D			•		•‡	•		•		•
50D/40D	•			•	•		•			•
30D/20D/10D	•			•	•		•			•
D60/D30	•		•	•	•		•			•
Rebel T7i		•	•		•‡	•		•	•	
Rebel T6s/T6i			•		•‡	•		•	•	
Rebel T5i/T4i			•		•‡	•		•	•	
Rebel T3i/T2i			•		•‡	•		•	•	
Rebel T1i			•					•	•	
Rebel T6					•‡	•		•	•	
Rebel T5/T3					•‡	•		•	•	
Rebel SL2		•			•‡	•		•	•	
Rebel SL1			•		•‡	•		•	•	
Rebel XSi/Rebel XS			• ^a					•	•	
Digital Rebel XTi/XT			•					•		
Digital Rebel	•		•					•		
 EOS R		•			•‡	•		•		
EOS M5			•					•		
EOS M6			•		•‡	•		•		
EOS M50		•								
EOS M3			•							
EOS M100/M10										
EOS M			•							
REMARKS	Rechargeable Battery Pack. Identical to BP-512 except for external shape.	Bluetooth® remote; operates as far as 16 ft. / 5m, from camera.	Infrared remote; operates as far as 16 ft. / 5m, from camera. a - for XSi only	Extended range wireless controller system; maximum transmitter to receiver distance 330 ft. / 100m.	2.6 ft. / 80cm remote switch w/ self-timer (includes CR2023 Lithium-ion Battery).	Accessory support only available for TC-80N3.	2.6 ft. / 80cm electromagnetic cable release.	2 ft. / 60cm remote shutter release switch		











† Please note that the magnifier will reduce the field of view visible through the camera's viewfinder and display. This effect on the image through the viewfinder will be more pronounced while wearing glasses. The magnifier may blur the image visible through the viewfinder and may make it more difficult to focus the camera manually. Please note, the image taken with the camera will not be affected by any of the above.

‡ Requires Remote Controller Adapter RA-E3.











Note: **Bold products** are current, others shown for reference only.

* Please see Canon U.S.A., Inc.'s then-current Imaging Technologies and Communications Group Camera and Video Products Unilateral Minimum Advertised Price Policy (the "Policy") for the terms and conditions governing Minimum Advertised Pricing (MAP). Also, please see the terms and conditions of Canon U.S.A., Inc.'s Co-op Advertising Program which conditions reimbursement for co-op advertising in compliance with the Policy.

Ⓢ *Dealers do not earn any Co-op Advertising Allowance on purchases of these products.*

ITEM DESCRIPTION	EYECUPS				RUBBER FRAME	VIEWING ACCESSORIES				
	Eyecup Eg	Eyecup Ef	Eyecup Ec II	Eyecup Eb	Rubber Frame Ef	Anti-Fog Eyepiece Eg	Anti-Fog Eyepiece Ec	Angle Finder C	Electronic Viewfinder EVF-DC2 (Black)	Electronic Viewfinder EVF-DC2 (Silver)
										
ITEM CODE	1889B001 [Ⓞ]	8171A001 [Ⓞ]	2377A001 [Ⓞ]	2378A001 [Ⓞ]	8172A001 [Ⓞ]	2200B001 [Ⓞ]	2879A001 [Ⓞ]	2882A001 [Ⓞ]	1727C001 [Ⓞ]	1882C001 [Ⓞ]
UPC CODE	013803 078282	013803 020496	082966 509117	082966 509964	013803 020595	013803 081572	082966 505906	082966 540097	013803 287042	013803 287059
SUGGESTED LIST PRICE (\$)	20.00	12.00	17.00	12.00	10.00	60.00	50.00	280.00	249.99	249.99
DEALER NET PRICE (\$)	14.00	8.00	11.00	8.00	7.00	37.00	32.00	174.00	165.00	165.00
MAP* (\$)	—	—	—	—	—	—	—	—	—	—
1D X Mark II	•					•		•		
1D X	•					•		•		
1Ds Mark III	•					•		•		
1Ds Mark II/1Ds			•				•	•		
1D Mark IV/1D Mark III	•					•		•		
1D Mark II n/1D Mark II/1D			•				•	•		
D2000			•				•	•		
5DS/5DS R	•					•		•		
5D Mark IV	•					•		•		
5D Mark III	•					•		•		
5D Mark II				•				•		
5D				•				•		
6D Mark II				•				•		
6D				•				•		
7D Mark II	•					•		•		
7D	•					•		•		
80D				•				•		
77D		•			•			•		
70D				•				•		
60D				•				•		
50D/40D				•				•		
30D/20D/10D				•				•		
D60/D30				•				•		
Rebel T7i		•			•			•		
Rebel T6s/T6i		•			•			•		
Rebel T5i/T4i		•			•			•		
Rebel T3i/T2i		•			•			•		
Rebel T1i		•			•			•		
Rebel T6		•			•			•		
Rebel T5/T3		•			•			•		
Rebel SL2		•			•			•		
Rebel SL1		•			•			•		
Rebel XSi/Rebel XS		•			•			•		
Digital Rebel XTi/XT		•			•			•		
Digital Rebel		•			•			•		
EOS R										
EOS M5										
EOS M6									•	•
EOS M50										
EOS M3									•	•
EOS M100/M10										
EOS M										
REMARKS			Replacement eyecup for all EOS-1D series except Mark III	Replacement eyecup	Used with Dioptic Adjustment Lens E	Prevents condensation or fogging	Prevents condensation or fogging	Requires Adapter (included)		

Note: **Bold products** are current, others shown for reference only. † Requires Remote Switch Adapter RA-N3.
 * Please see Canon U.S.A., Inc.'s then-current Imaging Technologies and Communications Group Camera and Video Products Unilateral Minimum Advertised Price Policy (the "Policy") for the terms and conditions governing Minimum Advertised Pricing (MAP).
 Also, please see the terms and conditions of Canon U.S.A., Inc.'s Co-op Advertising Program which conditions reimbursement for co-op advertising in compliance with the Policy.
 Ⓞ "Dealers do not earn any Co-op Advertising Allowance on purchases of these products."

ITEM DESCRIPTION	VIEWING ACCESSORIES	DIOPTRIC ADJUSTMENT LENSES		DIOPTRIC ADJUSTMENT LENSES						
	Electronic Viewfinder EVF-DC1	Dioptic Adjustment Lens E (+2)	Dioptic Adjustment Lens E (+1.5)	Dioptic Adjustment Lens E (+1)	Dioptic Adjustment Lens E (+0.5)	Dioptic Adjustment Lens E (0)	Dioptic Adjustment Lens E (-2)	Dioptic Adjustment Lens E (-3)	Dioptic Adjustment Lens E (-4)	Dioptic Adjustment Lens Eg (+3)
										
ITEM CODE	9555B001	2839A001 [⊖]	2840A001 [⊖]	2841A001 [⊖]	2842A001 [⊖]	2843A001 [⊖]	2845A001 [⊖]	2846A001 [⊖]	2847A001 [⊖]	2192B001 [⊖]
UPC CODE	013803 242010	082966 505423	082966 505430	082966 505447	082966 505454	082966 505461	082966 505485	082966 505492	082966 505508	013803 081503
SUGGESTED LIST PRICE (\$)	299.99	17.00	17.00	17.00	17.00	17.00	17.00	17.00	17.00	45.00
DEALER NET PRICE (\$)	195.00	11.00	11.00	11.00	11.00	11.00	11.00	11.00	11.00	27.00
MAP* (\$)	—	—	—	—	—	—	—	—	—	—
1D X Mark II										•
1D X										•
1Ds Mark III										•
1Ds Mark II/1Ds		•	•	•	•	•	•	•	•	
1D Mark IV/1D Mark III										•
1D Mark II n/1D Mark II/1D		•	•	•	•	•	•	•	•	
D2000		•	•	•	•	•	•	•	•	
5DS/5DS R										•
5D Mark IV										•
5D Mark III										•
5D Mark II		•	•	•	•	•	•	•	•	
5D		•	•	•	•	•	•	•	•	
6D Mark II		•	•	•	•	•	•	•	•	
6D		•	•	•	•	•	•	•	•	
7D Mark II										•
7D										•
80D		•	•	•	•	•	•	•	•	
77D		•	•	•	•	•	•	•	•	
70D		•	•	•	•	•	•	•	•	
60D		•	•	•	•	•	•	•	•	
50D/40D		•	•	•	•	•	•	•	•	
30D/20D/10D		•	•	•	•	•	•	•	•	
D60/D30		•	•	•	•	•	•	•	•	
Rebel T7i		•	•	•	•	•	•	•	•	
Rebel T6s/T6i		•	•	•	•	•	•	•	•	
Rebel T5i/T4i		•	•	•	•	•	•	•	•	
Rebel T3i/T2i		•	•	•	•	•	•	•	•	
Rebel T1i		•	•	•	•	•	•	•	•	
Rebel T6		•	•	•	•	•	•	•	•	
Rebel T5/T3		•	•	•	•	•	•	•	•	
Rebel SL2		•	•	•	•	•	•	•	•	
Rebel SL1		•	•	•	•	•	•	•	•	
Rebel XSi/Rebel XS		•	•	•	•	•	•	•	•	
Digital Rebel XTi/XT		•	•	•	•	•	•	•	•	
Digital Rebel		•	•	•	•	•	•	•	•	
EOS R										
EOS M5										
EOS M6	•									
EOS M50										
EOS M3	•									
EOS M100/M10										
EOS M										
REMARKS		Requires Rubber Frame Eb, Ec or Ef	Requires Rubber Frame Eb, Ec or Ef	Requires Rubber Frame Eb, Ec or Ef	Requires Rubber Frame Eb, Ec or Ef	Requires Rubber Frame Eb, Ec or Ef	Requires Rubber Frame Eb, Ec or Ef	Requires Rubber Frame Eb, Ec or Ef	Requires Rubber Frame Eb, Ec or Ef	w/ Rubber Frame











Note: **Bold products** are current, others shown for reference only.
 * Please see Canon U.S.A., Inc.'s then-current Imaging Technologies and Communications Group Camera and Video Products Unilateral Minimum Advertised Price Policy (the "Policy") for the terms and conditions governing Minimum Advertised Pricing (MAP).
 Also, please see the terms and conditions of Canon U.S.A., Inc.'s Co-op Advertising Program which conditions reimbursement for co-op advertising in compliance with the Policy.
 ⊖ "Dealers do not earn any Co-op Advertising Allowance on purchases of these products."

ITEM DESCRIPTION	DIOPTRIC ADJUSTMENT LENSES (CONT.)						FOCUSING SCREENS			
	Dioptic Adjustment Lens Eg (+2)	Dioptic Adjustment Lens Eg (+1)	Dioptic Adjustment Lens Eg (0)	Dioptic Adjustment Lens Eg (-2)	Dioptic Adjustment Lens Eg (-3)	Dioptic Adjustment Lens Eg (-4)	Focusing Screen Eh-A	Focusing Screen Eh-S	Focusing Screen Eg-S	Focusing Screen Eg-D
ITEM CODE	2194B001 [Ⓞ]	2195B001 [Ⓞ]	2196B001 [Ⓞ]	2197B001 [Ⓞ]	2198B001 [Ⓞ]	2199B001 [Ⓞ]	9135B001 [Ⓞ]	9136B001 [Ⓞ]	3357B001 [Ⓞ]	3356B001 [Ⓞ]
UPC CODE	013803 081510	013803 081527	013803 081534	013803 081541	013803 081558	013803 081565	013803 237078	013803 237085	013803 104493	013803 104486
SUGGESTED LIST PRICE (\$)	45.00	45.00	45.00	45.00	45.00	45.00	45.00	45.00	45.00	45.00
DEALER NET PRICE (\$)	27.00	27.00	27.00	27.00	27.00	27.00	28.00	28.00	28.00	28.00
MAP* (\$)	-	-	-	-	-	-	-	-	-	-
1D X Mark II	•	•	•	•	•	•				
1D X	•	•	•	•	•	•				
1Ds Mark III	•	•	•	•	•	•				
1Ds Mark II/1Ds										
1D Mark IV/1D Mark III	•	•	•	•	•	•				
1D Mark II n/1D Mark II/1D										
D2000										
5DS/5DS R	•	•	•	•	•	•				
5D Mark IV	•	•	•	•	•	•				
5D Mark III	•	•	•	•	•	•				
5D Mark II									•	•
5D										
6D Mark II										
6D									•	•
7D Mark II	•	•	•	•	•	•	•	•		
7D	•	•	•	•	•	•				
80D										
77D										
70D										
60D										
50D/40D										
30D/20D/10D										
D60/D30										
Rebel T7i										
Rebel T6s/T6i										
Rebel T5i/T4i										
Rebel T3i/T2i										
Rebel T1i										
Rebel T6										
Rebel T5/T3										
Rebel SL2										
Rebel SL1										
Rebel XSi/Rebel XS										
Digital Rebel XTi/XT										
Digital Rebel										
EOS R										
EOS M5										
EOS M6										
EOS M50										
EOS M3										
EOS M100/M10										
EOS M										
REMARKS	w/ Rubber Frame	w/ Rubber Frame	w/ Rubber Frame	w/ Rubber Frame	w/ Rubber Frame	w/ Rubber Frame				

Note: **Bold products** are current, others shown for reference only.

* Please see Canon U.S.A., Inc.'s then-current Imaging Technologies and Communications Group Camera and Video Products Unilateral Minimum Advertised Price Policy (the "Policy") for the terms and conditions governing Minimum Advertised Pricing (MAP).
 Also, please see the terms and conditions of Canon U.S.A., Inc.'s Co-op Advertising Program which conditions reimbursement for co-op advertising in compliance with the Policy.










Ⓞ "Dealers do not earn any Co-op Advertising Allowance on purchases of these products."

FOCUSING SCREENS										
ITEM DESCRIPTION	Focusing Screen Eg-A	Focusing Screen Eg-A II	Focusing Screen Ef-D	Focusing Screen Ec-S	Focusing Screen Ec-L	Focusing Screen Ec-I	Focusing Screen Ec-H	Focusing Screen Ec-D	Focusing Screen Ec-CIV	Focusing Screen Ec-CV
										
ITEM CODE	3355B001 [Ⓞ]	8039B001 [Ⓞ]	2377B001 [Ⓞ]	0848B001 [Ⓞ]	4726A001 [Ⓞ]	4725A001 [Ⓞ]	4724A001 [Ⓞ]	4723A001 [Ⓞ]	1890B001 [Ⓞ]	6006B001 [Ⓞ]
UPC CODE	013803 104479	013803 204278	013803 086645	013803 057416	082966 520037	082966 052020	082966 520013	082966 520006	013803 078299	013803 145526
SUGGESTED LIST PRICE (\$)	45.00	45.00	45.00	45.00	45.00	45.00	45.00	45.00	45.00	45.00
DEALER NET PRICE (\$)	28.00	28.00	28.00	28.00	28.00	28.00	28.00	28.00	28.00	28.00
MAP* (\$)	-	-	-	-	-	-	-	-	-	-
1D X Mark II					●	●	●	●	●	●
1D X				●§	●	●	●	●	●§	●
1Ds Mark III				●	●	●	●	●	●	
1Ds Mark II/1Ds					●	●	●	●		
1D Mark IV/1D Mark III				●	●	●	●	●	●	
1D Mark II n/1D Mark II/1D				●a	●	●	●	●		
D2000					●	●	●	●		
5DS/5DS R										
5D Mark IV										
5D Mark III										
5D Mark II	●									
5D										
6D Mark II										
6D		●								
7D Mark II										
7D										
80D										
77D										
70D										
60D			●							
50D/40D			●							
30D/20D/10D										
D60/D30										
Rebel T7i										
Rebel T6s/T6i										
Rebel T5i/T4i										
Rebel T3i/T2i										
Rebel T1i										
Rebel T6										
Rebel T5/T3										
Rebel SL2										
Rebel SL1										
Rebel XSi/Rebel XS										
Digital Rebel XTi/XT										
Digital Rebel										
EOS R										
EOS M5										
EOS M6										
EOS M50										
EOS M3										
EOS M100/M10										
EOS M										
REMARKS			Etched Grid lenses	Super Precision Matte. For f/2.8 and faster lenses a - For 1D Mark II n only	Cross Split	Matte w/ Double Cross Hair Reticle	Matte w/ Scales	Matte w/ Grid	All Matte Standard Screen	

Note: **Bold products** are current, others shown for reference only.

* Please see Canon U.S.A., Inc.'s then-current Imaging Technologies and Communications Group Camera and Video Products Unilateral Minimum Advertised Price Policy (the "Policy") for the terms and conditions governing Minimum Advertised Pricing (MAP). Also, please see the terms and conditions of Canon U.S.A., Inc.'s Co-op Advertising Program which conditions reimbursement for co-op advertising in compliance with the Policy.

Ⓞ "Dealers do not earn any Co-op Advertising Allowance on purchases of these products."

FOCUSING SCREENS (CONT.)									SEMI HARD CASES	
ITEM DESCRIPTION	Focusing Screen Ec-C6	Focusing Screen Ec-B	Focusing Screen Ec-A	Focusing Screen Ee-S	Focusing Screen Ee-D	Focusing Screen EC-1Ds Crop Lines	Focusing Screen EC-1D Crop Lines	Focusing Screen EC-1D Black Mask	Semi Hard Case EH27-L	
										
ITEM CODE	1168C001 [Ⓢ]	4721A001 [Ⓢ]	4720A001 [Ⓢ]	0830B001 [Ⓢ]	0829B001 [Ⓢ]	0055T166 [Ⓢ]	0055T168 [Ⓢ]	0055T167 [Ⓢ]	0252C001 [Ⓢ]	
UPC CODE	013803 271645	082966 519987	082966 519970	013803 057256	013803 057249	013803 062700	013803 062724	013803 062717	013803 253085	
SUGGESTED LIST PRICE (\$)	45.00	45.00	45.00	45.00	45.00	170.00	170.00	170.00	80.00	
DEALER NET PRICE (\$)	28.00	28.00	28.00	28.00	28.00	104.00	104.00	104.00	50.00	
MAP* (\$)	—	—	—	—	—	—	—	—	—	
1D X Mark II	•	•	•							
1D X		•	•			•§	•§	•§		
1Ds Mark III		•	•			•				
1Ds Mark II/1Ds		•	•			•				
1D Mark IV/1D Mark III		•	•				•	•		
1D Mark II n/1D Mark II/1D		•	•				•	•		
D2000		•	•							
5DS/5DS R										
5D Mark IV										
5D Mark III										
5D Mark II										
5D				•	•					
6D Mark II										
6D										
7D Mark II										
7D										
80D										
77D									•	
70D										
60D										
50D/40D										
30D/20D/10D										
D60/D30										
Rebel T7i									•	
Rebel T6s/T6i									•	
Rebel T5i/T4i									•	
Rebel T3i/T2i										
Rebel T1i										
Rebel T6									•	
Rebel T5/T3										
Rebel SL2										
Rebel SL1										
Rebel XSi/Rebel XS										
Digital Rebel XTi/XT										
Digital Rebel										
EOS R										
EOS M5										
EOS M6										
EOS M50										
EOS M3										
EOS M100/M10										
EOS M										
REMARKS	Standard Precision Matte screen	New Split	Microprism	EOS 5D only. Super Precision Matte; for f/2.8 and faster lenses	EOS 5D only. Standard Matte with Grid Lines	For full-frame cameras. All metering works normally	For EOS-1D series. All metering works normally	For EOS-1D series. Partial or spot metering only		

§ For the EOS-1D X, by changing the Focusing Screen Custom Function setting, the camera can be compatible with the Laser Matte focusing screens: Ec-A, B, D, H, I, and L. The Ec-C IV and Ec-C, CII, CIII, S, N, and R focusing screens can also be installed, but since there is no Focusing Screen Custom Function setting for them, you must set exposure compensation as you shoot.

Note: **Bold products** are current, others shown for reference only.

* Please see Canon U.S.A., Inc.'s then-current Imaging Technologies and Communications Group Camera and Video Products Unilateral Minimum Advertised Price Policy (the "Policy") for the terms and conditions governing Minimum Advertised Pricing (MAP). Also, please see the terms and conditions of Canon U.S.A., Inc.'s Co-op Advertising Program which conditions reimbursement for co-op advertising in compliance with the Policy.










Ⓢ "Dealers do not earn any Co-op Advertising Allowance on purchases of these products."

ITEM DESCRIPTION	BODY JACKET		CAMERA STRAPS							
	Body Jacket EH29-CJ (Brown)	Body Jacket EH29-CJ (Black)	Pro Neck Strap 1	Hand Strap E2	Neck Strap L3	Wide Strap EW-100DB V	Neck Strap ER-100B	Neck Strap EM-200DB	Neck Strap EM-E2 (Brown)	Neck Strap EM-E2 (Black)
ITEM CODE	1663C001	1662C001	6255A003	4991B001	2342A001	0508C001	3222C001	9929B001	9930B001	1661C001
UPC CODE	013803 283488	013803 283471	750845 821086	013803 131932	082966 561214	013803 254921	013803 309072	013803 248036	013803 248029	013803 284072
SUGGESTED LIST PRICE (\$)	60.00	60.00	30.00	60.00	25.00	20.00	30.00	20.00	40.00	40.00
DEALER NET PRICE (\$)	42.00	42.00	19.00	36.00	16.00	14.00	19.00	14.00	26.00	26.00
MAP* (\$)	-	-	-	-	-	-	-	-	-	-
1D X Mark II			•	•	•	•				
1D X			•	•	•	•				
1Ds Mark III			•	•	•	•				
1Ds Mark II/1Ds			•	•	•	•				
1D Mark IV/1D Mark III			•	•	•	•				
1D Mark II n/1D Mark II/1D			•	•	•	•				
D2000			•	•	•	•				
5DS/5DS R			•	•	•	•				
5D Mark IV			•	•	•	•				
5D Mark III			•	•	•	•				
5D Mark II			•	•	•	•				
5D			•	•	•	•				
6D Mark II			•	•	•	•				
6D			•	•	•	•				
7D Mark II			•	•	•	•				
7D			•	•	•	•				
80D			•	•	•	•				
77D			•	•	•	•				
70D			•	•	•	•				
60D			•	•	•	•				
50D/40D			•	•	•	•				
30D/20D/10D			•	•	•	•				
D60/D30			•	•	•	•				
Rebel T7i			•	•	•	•				
Rebel T6s/T6i			•	•	•	•				
Rebel T5i/T4i			•	•	•	•				
Rebel T3i/T2i			•	•	•	•				
Rebel T1i			•	•	•	•				
Rebel T6			•	•	•	•				
Rebel T5/T3			•	•	•	•				
Rebel SL2			•	•	•	•				
Rebel SL1			•	•	•	•				
Rebel XSi/Rebel XS			•	•	•	•				
Digital Rebel XTi/XT			•	•	•	•				
Digital Rebel			•	•	•	•				
EOS R				•			•			
EOS M5	•	•							•	•
EOS M6									•	•
EOS M50								•	•	•
EOS M3								•	•	•
EOS M100/M10								•	•	•
EOS M										
REMARKS			w/ Quick release, anti-twist and non-slip backing							

Note: **Bold products** are current, others shown for reference only.
 * Please see Canon U.S.A., Inc.'s then-current Imaging Technologies and Communications Group Camera and Video Products Unilateral Minimum Advertised Price Policy (the "Policy") for the terms and conditions governing Minimum Advertised Pricing (MAP).
 Also, please see the terms and conditions of Canon U.S.A., Inc.'s Co-op Advertising Program which conditions reimbursement for co-op advertising in compliance with the Policy.
 • "Dealers do not earn any Co-op Advertising Allowance on purchases of these products."










ITEM DESCRIPTION	REMOTE CONTROLLERS					EYECUPS		
	Wireless Remote Controller RC-6	Wireless Controller LC-5	Timer Remote Control TC-80N3	Remote Switch RS-80N3	Remote Switch RS-60E3	Eyecup Ef	Eyecup Ec II	Eyecup Eb
								
ITEM CODE	4524B001 [Ⓞ]	0295B001 [Ⓞ]	2477A002 [Ⓞ]	2476A001 [Ⓞ]	2469A002 [Ⓞ]	8171A001 [Ⓞ]	2377A001 [Ⓞ]	2378A001 [Ⓞ]
UPC CODE	013803 123944	013803 054408	082966 581564	082966 581571	082966 581359	013803 020496	082966 509117	082966 509964
SUGGESTED LIST PRICE (\$)	30.00	680.00	210.00	70.00	30.00	12.00	17.00	12.00
DEALER NET PRICE (\$)	19.00	426.00	133.00	45.00	19.00	8.00	11.00	8.00
MAP* (\$)	—	—	—	—	—	—	—	—
EOS-1v HS/1v/1N RS/1N		● ^a	● ^a	● ^a			●	
EOS-3		●	●	●				
EOS A2E/A2								
EOS RT								●
EOS 850/750/700/650								●
EOS 630/620								●
EOS 10S								●
ELAN 7NE/7N/7E/7/II E/II	●				●			
ELAN	●							●
Rebel T2/Ti	● ^a				●	●		●
Rebel 2000					●			●
Rebel K2	●					●		●
Rebel GII/G/XSN/XS/X					●			●
EOS IX Lite/IX					●			
REMARKS	Infrared remote; operates as far as 16 ft. / 5m, from camera. a - For T2 only	Extended range wireless controller system; maximum transmitter to receiver distance 330 ft. / 100m a - For 1v HS/1v	2.6 ft. / 80cm remote switch w/ self-timer (includes CR2023 Lithium-ion Battery) a - For 1v HS/1v	2.6 ft. / 80cm electromagnetic cable release a - For 1v HS/1v	2 ft. / 60cm remote shutter release switch		Replacement eyecup for all EOS-1D series except Mark III	Replacement eyecup

[‡] Requires Remote Switch Adapter RA-N3.
^{††} These accessories are compatible with all Canon SLRs that feature T3 Remote Control terminals. T3 terminals are built in on the EOS-1, 1N RS, A2 / A2E and all T-Series Cameras except the T60. EOS 650, RT and 630 / 600 require optional Grip GR-20 for N3-type remote control socket and compatibility with remote control accessories. Grip GR-20 was supplied with EOS 620 camera.
^{*} Please see Canon U.S.A., Inc.'s then-current Imaging Technologies and Communications Group Camera and Video Products Unilateral Minimum Advertised Price Policy (the "Policy") for the terms and conditions governing Minimum Advertised Pricing (MAP). Also, please see the terms and conditions of Canon U.S.A., Inc.'s Co-op Advertising Program which conditions reimbursement for co-op advertising in compliance with the Policy.
[Ⓞ] *Dealers do not earn any Co-op Advertising Allowance on purchases of these products."








ITEM DESCRIPTION	RUBBER FRAMES		VIEWING ACCESORIES			DIOPTRIC ADJUSTMENT LENSES			
	Rubber Frame Ef	Rubber Frame Eb	Anti-Fog Eyepiece Ec	Eyepiece EP-EX15	Angle Finder C	Dioptic Adjustment Lens E (+2)	Dioptic Adjustment Lens E (+1.5)	Dioptic Adjustment Lens E (+1)	Dioptic Adjustment Lens E (+0.5)
									
ITEM CODE	8172A001 [⊕]	2858A001 [⊕]	2879A001 [⊕]	2444A001 [⊕]	2882A001 [⊕]	2839A001 [⊕]	2840A001 [⊕]	2841A001 [⊕]	2842A001 [⊕]
UPC CODE	013803 020595	082966 505539	082966 505906	082966 509100	082966 540097	082966 505423	082966 505430	082966 505447	082966 505454
SUGGESTED LIST PRICE (\$)	10.00	10.00	50.00	20.00	280.00	17.00	17.00	17.00	17.00
DEALER NET PRICE (\$)	7.00	7.00	32.00	13.00	174.00	11.00	11.00	11.00	11.00
MAP* (\$)	—	—	—	—	—	—	—	—	—
EOS-1v HS/1v/1N RS/1N			•	• ^a	•	•	•	•	•
EOS-3					•				
EOS A2E/A2					•				
EOS RT				•	•	•	•	•	•
EOS 850/750/700/650				•	•	•	•	•	•
EOS 630/620		•		•	•	•	•	•	•
EOS 10S		•		•	•	•	•	•	•
ELAN 7NE/7N/7E/7/IIE/II					•				
ELAN		•		•	•	•	•	•	•
Rebel T2/Ti	•			•	•	•	•	•	•
Rebel 2000		•		•	•	•	•	•	•
Rebel K2	•			•	•	•	•	•	•
Rebel GII/G/XSN/XS/X		•		•	•	•	•	•	•
EOS IX Lite/IX				•	•				
REMARKS	Used with Dioptic Adjustment Lens E	Used with Dioptic Adjustment Lens E	Prevents condensation or fogging	Extends eyepiece away from back of camera a - For 1v HS only	Requires Adapter (included)	Requires Rubber Frame Eb, Ec or Ef	Requires Rubber Frame Eb, Ec or Ef	Requires Rubber Frame Eb, Ec or Ef	Requires Rubber Frame Eb, Ec or Ef

* Please see Canon U.S.A., Inc.'s then-current Imaging Technologies and Communications Group Camera and Video Products Unilateral Minimum Advertised Price Policy (the "Policy") for the terms and conditions governing Minimum Advertised Pricing (MAP). Also, please see the terms and conditions of Canon U.S.A., Inc.'s Co-op Advertising Program which conditions reimbursement for co-op advertising in compliance with the Policy.

⊕ "Dealers do not earn any Co-op Advertising Allowance on purchases of these products."

ITEM DESCRIPTION	DIOPTRIC ADJUSTMENT LENSES (CONT.)				FOCUSING SCREENS				
	Dioptic Adjustment Lens E (0)	Dioptic Adjustment Lens E (-2)	Dioptic Adjustment Lens E (-3)	Dioptic Adjustment Lens E (-4)	Focusing Screen Ec-R	Focusing Screen Ec-N	Focusing Screen Ec-L	Focusing Screen Ec-I	Focusing Screen Ec-H
									
ITEM CODE	2843A001 [⊕]	2845A001 [⊕]	2846A001 [⊕]	2847A001 [⊕]	4728A001 [⊕]	4729A001 [⊕]	4726A001 [⊕]	4725A001 [⊕]	4724A001 [⊕]
UPC CODE	082966 505461	082966 505485	082966 505492	082966 505508	082966 520174	082966 581656	082966 520037	082966 052020	082966 520013
SUGGESTED LIST PRICE (\$)	17.00	17.00	17.00	17.00	45.00	45.00	45.00	45.00	45.00
DEALER NET PRICE (\$)	11.00	11.00	11.00	11.00	28.00	28.00	28.00	28.00	28.00
MAP* (\$)	-	-	-	-	-	-	-	-	-
EOS-1v HS/1v/1N RS/1N	•	•	•	•	•	•	•	•	•
EOS-3					•	•	•	•	•
EOS A2E/A2									
EOS RT	•	•	•	•					
EOS 850/750/700/650	•	•	•	•					
EOS 630/620	•	•	•	•					
EOS 10S	•	•	•	•					
ELAN 7NE/7N/7E/7/IIE/II									
ELAN	•	•	•	•					
Rebel T2/Ti	•	•	•	•					
Rebel 2000	•	•	•	•					
Rebel K2	•	•	•	•					
Rebel GII/G/XSN/XS/X	•	•	•	•					
EOS IX Lite/IX									
REMARKS	Requires Rubber Frame Eb, Ec or Ef	Requires Rubber Frame Eb, Ec or Ef	Requires Rubber Frame Eb, Ec or Ef	Requires Rubber Frame Eb, Ec or Ef	Overall Bright Laser Matte (Standard for EOS-1N RS)	Bright Laser Matte (Standard EOS-3)	Cross Split	Matte w/ Double Cross Hair Reticle	Matte w/ Scales

* Please see Canon U.S.A., Inc.'s then-current Imaging Technologies and Communications Group Camera and Video Products Unilateral Minimum Advertised Price Policy (the "Policy") for the terms and conditions governing Minimum Advertised Pricing (MAP). Also, please see the terms and conditions of Canon U.S.A., Inc.'s Co-op Advertising Program which conditions reimbursement for co-op advertising in compliance with the Policy.
[⊕] *Dealers do not earn any Co-op Advertising Allowance on purchases of these products."

ITEM DESCRIPTION	FOCUSING SCREENS (CONT.)				CAMERA STRAPS				
	Focusing Screen Ec-D	Focusing Screen Ec-B	Focusing Screen Ec-A	Focusing Screen EC-1Ds Crop Lines	Pro Neck Strap 1	Hand Strap E2	Neck Strap L3		
									
ITEM CODE	4723A001 [Ⓢ]	4721A001 [Ⓢ]	4720A001 [Ⓢ]	0055T166 [Ⓢ]	6255A003 [Ⓢ]	4991B001 [Ⓢ]	2342A001 [Ⓢ]		
UPC CODE	082966 520006	082966 519987	082966 519970	013803 062700	750845 821086	013803 131932	082966 561214		
SUGGESTED LIST PRICE (\$)	45.00	45.00	45.00	170.00	30.00	60.00	25.00		
DEALER NET PRICE (\$)	28.00	28.00	28.00	104.00	19.00	36.00	16.00		
MAP* (\$)	—	—	—	—	—	—	—		
EOS-1v HS/1v/1N RS/1N	•	•	•	•	•	•	•		
EOS-3	•	•	•	•	•	•	•		
EOS A2E/A2					•	•	•		
EOS RT					•	•	•		
EOS 850/750/700/650					•	•	•		
EOS 630/620					•	•	•		
EOS 10S					•	•	•		
ELAN 7NE/7N/7E/7/II E/II					•	•	•		
ELAN					•	•	•		
Rebel T2/Ti					•	•	•		
Rebel 2000					•	•	•		
Rebel K2					•	•	•		
Rebel GII/G/XSN/XS/X					•	•	•		
EOS IX Lite/IX					•	•	•		
REMARKS	Matte w/ Grid	New Split	Microprism	For full-frame cameras. All metering works normally	w/ Quick release, anti-twist and non-slip backing				

* Please see Canon U.S.A., Inc.'s then-current Imaging Technologies and Communications Group Camera and Video Products Unilateral Minimum Advertised Price Policy (the "Policy") for the terms and conditions governing Minimum Advertised Pricing (MAP). Also, please see the terms and conditions of Canon U.S.A., Inc.'s Co-op Advertising Program which conditions reimbursement for co-op advertising in compliance with the Policy.
[Ⓢ] "Dealers do not earn any Co-op Advertising Allowance on purchases of these products."

SEMI HARD CASE COMPATIBILITY CHART

LENS MODEL	REBEL T5i / T4i / SL1 / T3i / T2i / T5 / T3 / T1i / XSi / XS	DIGITAL REBEL XTi / XT	30D / 20D	DIGITAL REBEL	1v / 3			ELAN 7 SERIES	REBEL Ti / K2	REBEL 2000		REBEL XSN
	EH19-L [⊕]	EH18-L [⊕]	EH17-L [⊕]	EH16-L [⊕]	EH11-L [⊕]	EH11-LL [⊕]	EH111-LL [⊕]	EH14-L [⊕]	EH15-L [⊕]	EH13-L [⊕]	EH8N-L [⊕]	EH8H-L [⊕]
EF 8-15mm f/4L Fisheye USM												
EF 14mm f/2.8 II USM												
EF 14mm f/2.8L USM												
EF 15mm f/2.8 Fish-eye												
EF 20mm f/2.8 USM	△	▼	▼	▼	○				△	△	△	○
EF 24mm f/1.4L USM			△									
EF 24mm f/2.8				○				△	△	△		
EF 28mm f/1.8 USM								△	△	○	△	
EF 28mm f/2.8									△	△	△	
EF 35mm f/2									△	△	△	
EF 50mm f/1.0L USM					▼	△						
EF 50mm f/1.4 USM									▼	▼	○	△
EF 50mm f/1.8 II									△	△	△	
EF 50mm f/2.5 Compact Macro			○		●			△	○	○	○	○
EF 85mm f/1.2L USM					▼	△						
EF 85mm f/1.8 USM	△	○	○	○	○			○				
EF 100mm f/2 USM	△	○	○	○	○			○				
EF 100mm f/2.8 Macro												
EF 135mm f/2.8 w/ Sofffocus		○										
EF 16-35mm f/2.8L USM			△									
EF-S 18-55mm f/3.5-5.6 IS II	○	○	○	○								
EF-S 18-55mm f/3.5-5.6 IS	○	○	○	○								
EF-S 18-55mm f/3.5-5.6 II USM	○	○	○	○								
EF-S 18-55mm f/3.5-5.6	○	○	○	○								
EF 20-35mm f/2.8L			△			○						
EF 20-35mm f/3.5-4.5 USM					○			▼				▼
EF 22-55mm f/4-5.6 USM	○	○	○	○					△	△	○	
EF 24-70mm f/2.8L USM												
EF 24-85mm f/3.5-4.5 USM	○	○	○	○	○			○	▼	▼	▼	○
EF 28-70mm f/2.8L USM		○	○	○								
EF 28-70mm f/3.5-4.5 II		○	○	○	○			○	▼	▼		○
EF 28-80mm f/3.5-5.6 II USM	○	○	○	○	△			○	○	○	▼	○
EF 28-80mm f/3.5-5.6 III USM	○	○	○	○	△			○	○	○	▼	○
EF 28-80mm f/3.5-5.6 IV USM	○	○	○	○	△			○	○	○	▼	○
EF 28-80mm f/3.5-5.6 V USM	○	○	○	○	○			○	○	○		
EF 28-80mm f/3.5-5.6 USM	○	○	○	○	○			○	▼	▼		○
EF 28-80mm f/3.5-5.6	○	○	○	○	○			○	○	○		○
EF 28-90mm f/4-5.6 II USM	○	○	○	○	△			○	○	○	▼	○
EF 28-90mm f/4-5.6 USM	○	○	○	○				○				
EF 28-105mm f/4-5.6 USM	○	○	○	○	△			○	○	▼	▼	○
EF 28-105mm f/3.5-4.5 USM	○	○	○	○	○			○				
EF 28-135mm f/3.5-5.6 IS USM			○			○						
EF 35-80mm f/4-5.6 USM		○	○	○				△				
EF 35-80mm f/4-5.6 III	○	○	○	○				△	○	○	○	▼
EF 35-105mm f/4.5-5.6 USM	○	○	○	○	△				○	○	▼	○
EF 35-105mm f/4.5-5.6	○	○	○	○				○			○	
EF 35-135mm f/4-5.6 USM									△	△	○	○
EF 35-135mm f/3.5-4.5					○			○				▼
EF 55-200mm f/4.5-5.6 USM												
EF 55-200mm f/4.5-5.6 II USM			○									
EF 70-200mm f/2.8L USM												
EF 80-200mm f/4.5-5.6 USM		▼	▼	▼				▼				
EF 80-200mm f/4.5-5.6 II		▼	▼	▼				○	▼	▼	▼	○
EF 80-200mm f/4.5-5.6		▼	▼	▼				○	▼	▼	▼	

○ Fits ● EF 50mm f/2.5 Compact Macro + Life-size converter △ Large, but can be used ▼ Fits without filter or hood
 For information on other Semi-Hard case models please see your Canon EOS dealer. Some lenses discontinued. Shown for reference only.
 ⊕ "Dealers do not earn any Co-op Advertising Allowance on purchases of these products."

EF LENSES ACCESSORY CHART

LENS	HARD CASE & TRUNKS ^o	SOFT CASE ^o	LENS HOOD ^o	LENS FILTER ^o	LENS CAP ^o
• EF 8-15mm f/4L Fisheye USM	None	LP1219	EW-77	Gelatin	8-15
• EF-S 10-18mm f/4.5-5.6 IS STM ^{††}	None	LP1116	EW-73C	67mm	E-67II
• EF-S 10-22mm f/3.5-4.5 USM ^{††}	None	LP1319	EW-83E	77mm	E-77U
• EF 11-24mm f/4L USM	None	LP1424	Built-in	Gelatin	11-24
• EF 16-35mm f/2.8L III USM	None	LP1222	EW-88D	82mm	E-82II
• EF 16-35mm f/2.8L II USM	None	LP1319	EW-88	82mm	E-82U
• EF 16-35mm f/2.8L USM	None	LP1319	EW-83E	77mm	E-77U
• EF 16-35mm f/4L IS USM	None	LP1219	EW-82	77mm	E-77II
• EF 17-35mm f/2.8L USM*	LH-D14B*	LP1216	EW-83CII	77mm	E-77U
• EF 17-40mm f/4L USM	None	LP1319	EW-83E	77mm	E-77U
• EF 20-35mm f/2.8L*	LH-D13*	LP1214	EW-75II	72mm	E-72
• EF 20-35mm f/3.5-4.5 USM*	LH-D11*	LP1214	EW-83II	77mm	E-77U
• EF-S 15-85mm f/3.5-5.6 IS USM ^{††}	None	LP1116	EW-78E	72mm	E-72U
• EF-S 17-55mm f/2.8 IS USM ^{††}	None	LP1219	EW-83J	77mm	E-77U
• EF-S 17-85mm f/4-5.6 IS USM* ^{††}	None	LP1116	EW-73B	67mm	E-67U
• EF-S 18-55mm f/3.5-5.6 IS STM ^{††}	None	LP1016	EW-63C	58mm	E-58II
• EF-S 18-55mm f/3.5-5.6 IS II ^{††}	None	LP814	EW-60C	58mm	E-58
• EF-S 18-55mm f/3.5-5.6 IS ^{††}	None	LP814	EW-60C	58mm	E-58
• EF-S 18-55mm f/3.5-5.6 USM* ^{††}	None	LP814	EW-60C	58mm	E-58U
• EF-S 18-55mm f/3.5-5.6** ^{††}	None	LP814	EW-60C	58mm	E-58U
• EF-S 18-55mm f/4-5.6 IS STM ^{††}	None	LP1014	EW-63C	58mm	E-58II
• EF-S 18-135mm f/3.5-5.6 IS USM ^{††}	None	LP1116	EW-73D	67mm	E-67II
• EF-S 18-135mm f/3.5-5.6 IS STM ^{††}	None	LP1116	EW-73B	67mm	E-67
• EF-S 18-135mm f/3.5-5.6 IS* ^{††}	None	LP1116	EW-73B	67mm	E-67
• EF-S 18-200mm f/3.5-5.6 IS ^{††}	None	LP1116	EW-78D	72mm	E-72
• EF 22-55mm f/4-5.6 USM*	None	LP1014	EW-60D	58mm	E-58U
• EF 24-70mm f/2.8L II USM	None	LP1219	EW-88C	82mm	E-82U
• EF 24-70mm f/2.8L USM*	None	LP1219	EW-83F	77mm	E-77U
• EF 24-70mm f/4L IS USM	None	LP1219	EW-83L	77mm	E-77U
• EF 24-85mm f/3.5-4.5 USM*	LH-C13*	ES-C13*/LP1014	EW-73II	67mm	E-67U
• EF 24-105mm f/4L IS II USM	None	LP1219	EW-83M	77mm	E-77II
• EF 24-105mm f/4L IS USM	None	LP1219	EW-83H	77mm	E-77U
• EF 24-105mm f/3.5-5.6 IS STM	None	LP1219	EW-83M	77mm	E-77 II
• EF 28-70mm f/2.8L USM*	LH-D16II*	LP1219	EW-83BII	77mm	E-77U
• EF 28-70mm f/3.5-4.5*	LH-B12*	ES-C13*/LP1014	EW-68A	52mm	E-52
• EF 28-80mm f/3.5-5.6 IV USM*/III*	LH-C13*	ES-C9*/LP814	EW-60C	58mm	E-58U
• EF 28-80mm f/3.5-5.6 V USM*	None	LP814	EW-60C	58mm	E-58U
• EF 28-80mm f/3.5-5.6 II*	None	LP814	EW-60C	58mm	E-58
• EF 28-80mm f/3.5-5.6*	LH-C13*	ES-C9*/LP814	EW-60C	58mm	E-58
• EF 28-90mm f/4-5.6 III/II USM	None	LP814	EW-60C	58mm	E-58U / E-58
• EF 28-90mm f/4-5.6 USM*	None	LP814	EW-60C	58mm	E-58U
• EF 28-105mm f/3.5-4.5 II USM*	LH-C13*	ES-C13*/LP814	EW-63II	58mm	E-58U
• EF 28-105mm f/3.5-4.5 USM*	LH-C13*	ES-C13*/LP814	EW-63II	58mm	E-58U
• EF 28-105mm f/4-5.6 USM	None	LP814	EW-63B	58mm	E-58U
• EF 28-135mm f/3.5-5.6 IS USM*	None	LP1116	EW-78BII	72mm	E-72U
• EF 28-200mm f/3.5-5.6 USM*	None	LP116	EW-78D	72mm	E-72U
• EF 28-300mm f/3.5-5.6L IS USM	None	LZ1324	EW-83G	77mm	E-77U
• EF 35-80mm f/4-5.6 III/II*	LH-C13*	ES-C9*/LP814	EW-54II	52mm	E-52
• EF 35-80mm f/4-5.6 USM*	LH-C13*	ES-C9*/LP814	EW-54II	52mm	E-52U
• EF 35-135mm f/4-5.6 USM*	LH-C13*	ES-C13*/LP1014	EW-62*	58mm	E-58U
• EF 35-350mm f/3.5-5.6L USM*	LH-D22*	LZ1324	EW-78II	72mm	E-72U
• EF-S 55-250mm f/4-5.6 IS STM ^{††}	—	LP1019	ET-63	58mm	E-58 II
• EF-S 55-250mm f/4-5.6 IS II* ^{††}	—	LP1019	ET-60	58mm	E-58
• EF-S 55-250mm f/4-5.6 IS ^{††}	—	LP1019	ET-60	58mm	E-58
NEW • EF 70-200mm f/2.8L IS III USM	None	LZ1326	ET-87	77mm	E-77 II
• EF 70-200mm f/2.8L IS II USM	None	LZ1326	ET-87	77mm	E-77U
• EF 70-200mm f/2.8L IS USM*	None	LZ1324	ET-86	77mm	E-77U
• EF 70-200mm f/2.8L USM	LH-D24B*	LZ1324	ET-83II	77mm	E-77U
NEW • EF 70-200mm f/4L IS II USM	None	LP1224	ET-78B	72mm	E-72 II
• EF 70-200mm f/4L IS USM/USM	None	LP1224	ET-74	67mm	E-67U
• EF 70-300mm f/4.5-5.6 DO IS USM	None	LP1116	ET-65B	58mm	E-58U
• EF 70-300mm f/4-5.6L IS USM ^a	None	LP1424	ET-73B	67mm	E-67U
• EF 70-300mm f/4-5.6 IS II USM	None	LP1222	ET-74B	67mm	E-67 II
• EF 70-300mm f/4-5.6 IS USM	None	LP1222	ET-65B	58mm	E-58U
• EF 75-300mm f/4-5.6 IS USM*	LH-D18B*	LP1022	ET-64II	58mm	E-58U
• EF 75-300mm f/4-5.6 III USM/III	None	LP1019	ET-60	58mm	E-58 / E-58U
• EF 75-300mm f/4-5.6 II USM*/USM*	None	ES-C17*/LP1019	ET-60	58mm	E-58U

^a Not compatible with tele-extenders.

^o Discontinued; [†] for reference only. ^{††} Limited Inventory. Rear Cap for EF Lenses = Lens Dust Cap E. Body Cap for EOS Cameras = Camera Cover R-F-3. DI = Drop-in. ^{**} Available only with EOS 30D, 20D, Digital Rebel XT and Digital Rebel Lens Kits.

^{*} Incorporates distance information with E-TTL II

^{††} Can be mounted only on select EOS Digital Cameras (EOS 7D Mark II, 7D, 80D, 77D, 70D, 60D, 50D, 40D, 30D, 20D, Rebel T6s / T7i / T6i / T5i / T4i / T3i / T2i / T1i, Rebel T6 / T5 / T3, Rebel SL2 / SL1, Rebel XSi / XS, Digital Rebel XTi, XT and Digital Rebel).

^o *Dealers do not earn any Co-op Advertising Allowance on purchases of these products.*

EF LENSES ACCESSORY CHART (CONT.)

LENS	HARD CASE & TRUNKS [Ⓞ]	SOFT CASE [Ⓞ]	LENS HOOD [Ⓞ]	LENS FILTER [Ⓞ]	LENS CAP [Ⓞ]
EF 75-300mm f/4-5.6 II*	None	ES-C17*/ LP1019	ET-60	58mm	E-58
EF 80-200mm f/2.8L*	LH-D23*	LZ1324	ES-79II	72mm	E-72
EF 80-200mm f/4.5-5.6 II*	LH-B12*	ES-C13*/ LP1014	ET-54	52mm	E-52
EF 80-200mm f/4.5-5.6 USM*	LH-B12*	ES-C13*/ LP1014	ET-54	52mm	E-52U
• EF 100-300mm f/4.5-5.6 USM*	None	ES-C17*/ LP1019	ET-65III	58mm	E-58U
EF 100-300mm f/5.6L*	None	ES-C20*	ET-62II*	58mm	E-58
• EF 100-400mm f/4.5-5.6L IS II USM*	None	LZ1326	ET-83D	77mm	E-77II
• EF 100-400mm f/4.5-5.6L IS USM	None	LZ1324	ET-83C	77mm	E-77U
• EF 200-400mm f/4L IS USM Extender 1.4x	Lens Case 200-400	None	ET-120WII	52mm DI	E-145C
• EF 14mm f/2.8L II USM	LH-C13*	ES-C13*/ LP1016	Built-in	Gelatin	Exclusive
• EF 14mm f/2.8L USM*	LH-C13*	ES-C13*/ LP1016	Built-in	Gelatin	Exclusive
EF 15mm f/2.8 Fisheye*	LHP-C10*	ES-C9*/ LP814	Built-in	Gelatin	E-73
• EF 20mm f/2.8 USM	LH-D13*	LP1214	EW-75II	72mm	E-72U
EF 24mm f/1.4L II USM	None	LP1319	EW-83K	77mm	E-77U
• EF 24mm f/1.4L USM	None	LP1214	EW-83DII	77mm	E-77U
EF 24mm f/2.8 IS USM	None	LP1014	EW-65B	58mm	E-58U
EF-S 24mm f/2.8 STM ^{††}	None	LP811	ES-52	52mm	E-52 II
EF 24mm f/2.8*	LHP-B9*	ES-C9*/ LP811	EW-60II	58mm	E-58
• EF 28mm f/1.8 USM	LHP-C10*	ES-C9*/ LP814	EW-63II	58mm	E-58U
EF 28mm f/2.8 IS USM	None	LP1014	EW-65B	58mm	E-58U
EF 28mm f/2.8*	LHP-B9*	ES-C9*/ LP1011	EW-65II	52mm	E-52
• EF 35mm f/1.4L II USM	None	LP1219	EW-77B	72mm	E-72 II
• EF 35mm f/1.4L USM*	None	LP1214	EW-78C	72mm	E-72U
EF 35mm f/2*	LH-B9*	ES-C9*/ LP1011	EW-65II	52mm	E-52
EF 35mm f/2 IS USM	None	LP1116	EW-72	67mm	E-52
EF-S 35mm f/2.8 Macro IS STM ^{††}	None	LP1014	ES-27	49mm [#]	EF-S35
EF 40mm f/2.8 STM	None	LP-811	ES-52	52mm	E-52 II
EF 50mm f/1.0L USM*	LH-D12*	LP1219	ES-79II	72mm	E-72U
• EF 50mm f/1.2L USM	None	LP1214	ES-78	72mm	E-72U
EF 50mm f/1.4 USM	LHP-C10*	ES-C9*/ LP1014	ES-71II	58mm	E-58U
EF 50mm f/1.8 STM	None	LP1014	ES-68	49mm	E-49
EF 50mm f/1.8 II*	LH-B9*	ES-C9*/ LP1014	ES-62 ^{##}	52mm	E-52
EF 50mm f/1.8*	LH-B9*	ES-C13*/ LP1014	ES-65*	52mm	E-52
• EF 85mm f/1.2L II USM	None	LP1219	ES-79II	72mm	E-7U
EF 85mm f/1.2L USM*	LH-D12*	LP1219	ES-79II	72mm	E-72U
• EF 85mm f/1.4L IS USM	None	LP1219	ET-83E	77mm	E-77 II
• EF 85mm f/1.8 USM	LH-B12*	ES-C13*/ LP1014	ET-65III	58mm	E-58U
• EF 100mm f/2 USM	LH-B12*	ES-C13*/ LP1014	ET-65III	58mm	E-58U
• EF 135mm f/2L USM	LH-D16 II*	LP1219	ET-78II	72mm	E-72U
EF 135mm f/2.8 w/Softfocus	LH-C13*	ES-C13*/ LP1016	ET-65III	52mm	E-52
EF 200mm f/1.8L USM*	Exclusive	None	ET-123	48mm DI	E-162
• EF 200mm f/2L IS USM	Lens Case 200	None	ET-120B	52mm DI	E-145B
• EF 200mm f/2.8L II USM	LH-D18II*	LP1222	ET-83BII	72mm	E-72U
EF 200mm f/2.8L USM*	LH-D18II*	LP1222	Built-in	72mm	E-72U
• EF 300mm f/2.8L IS II USM	Lens Case 300B	None	ET-120WII	52mm DI	E-145C
• EF 300mm f/2.8L IS USM	Lens Case 300	None	ET-120	52mm DI	E-145
• EF 300mm f/2.8L USM*	None	Lens Case 300	ET-118II*	48mm DI	E-137*
EF 300mm f/4L IS USM	LH-D27*	LZ1128	Built-in	77mm	E-77U
EF 300mm f/4L USM*	LH-D26*	LZ1128	Built-in	77mm	E-77U
NEW • EF 400mm f/2.8L IS III USM	Lens Case 400E	LS400	ET-155WIII	52mm DI	E-180E
• EF 400mm f/2.8L IS II USM	Lens Case 400C	None	ET-155WII	52mm DI	E-180D
• EF 400mm f/2.8L IS USM	Lens Case 400	None	ET-155	52mm DI	E-180C
• EF 400mm f/2.8L II USM*/USM*	Exclusive	None	ET-161BII*	48mm DI	E-180B II*
• EF 400mm f/4 DO IS II USM	Lens Case 400D	None	ET-120WII	52mm DI	E-145C
• EF 400mm f/4 DO IS USM*	Lens Case 400B	None	ET-120	52mm DI	E-145 II
• EF 400mm f/5.6L USM	LH-D29*	LZ1132	Built-in	77mm	E-77U
NEW • EF 600mm f/4L IS III USM	Lens Case 600C	LS600	ET-160WIII	52mm DI	E-185C
• EF 500mm f/4L IS II USM	Lens Case 500B	None	ET-138WII	52mm DI	E-163B
• EF 500mm f/4L IS USM*	Lens Case 500	None	ET-138	52mm DI	E-163
EF 500mm f/4.5L USM*	Exclusive	None	ET-123BII [†]	48mm DI	E-130*
• EF 600mm f/4L IS II USM	Lens Case 600B	None	ET-160WII	52mm DI	E-185B
• EF 600mm f/4L IS USM*	Lens Case 600	None	ET-160	52mm DI	E-185
EF 600mm f/4L USM*	Exclusive	None	ET-161II [†]	48mm DI	E-180*/ 180II*
• EF 800mm f/5.6L IS USM	Lens Case 800	None	ET-155	52mm DI	E-180C
• EF 1200mm f/5.6L USM	Exclusive	None	Built-in	48mm DI	Exclusive

b Extenders EF 1.4x II/III and 2x II/III are for exclusive use with EF 70-200mm f/2.8L, 70-200mm f/2.8L IS, 70-200mm f/2.8L IS II, 70-200mm f/4L, 100-400mm f/4.5-5.6L, 200-400mm f/4L IS USM Extender 1.4x, 135mm f/2L, 180mm f/3.5L Macro, 200mm f/1.8L, 300mm f/2.8L, 300mm f/2.8L IS II, 300mm f/4L, 300mm f/4L IS, 400mm f/2.8L IS, 400mm f/2.8L IS II, 400mm f/4 DO, 400mm f/5.6L, 500mm f/4L IS, 500mm f/4L IS II, 600mm f/4L IS, 600mm f/4L IS II, and 1200mm f/5.6L. (Manual focus only when EF 1.4x II/III are used with EF 100-400mm f/4.5-5.6L, 200-400mm f/4L IS USM Extender 1.4x, 400mm f/5.6L, 500mm f/4.5L, 1200mm f/5.6L, and with 180mm f/3.5 Macro when focused closer than 2.6 feet or with Extender EF 2x II/III when used with EF 70-200mm f/4L, 100-400mm f/4.5-5.6L, 200-400mm f/4L IS USM Extender 1.4x, 180mm f/3.5L Macro, 300mm f/4L IS, 300 f/4L, 400mm f/4 DO, 400mm f/5.6L, 500mm f/4L, 500mm f/4.5L, 600mm f/4L, and 1200mm f/5.6L.)

* Discontinued; for reference only. † Limited Inventory. ‡ Rear Cap for EF Lenses - Lens Dust Cap E. Body Cap for EOS Cameras - Camera Cover R-F-3. DI = Drop-in. # Compatible only when hood attached. ## With Adapter Ring

†† Can be mounted only on select EOS Digital Cameras (EOS 7D Mark II, 7D, 80D, 77D, 70D, 60D, 50D, 40D, 30D, 20D, Rebel T6s / T7i / T6i / T5i / T4i / T3i / T2i / T1i, Rebel T6 / T5 / T3, Rebel SL2 / SL1, Rebel XSi / XS, Digital Rebel XTi, XT and Digital Rebel).

Ⓞ *Dealers do not earn any Co-op Advertising Allowance on purchases of these products.

EF LENSES ACCESSORY CHART (CONT.)

LENS	HARD CASE & TRUNKS [Ⓞ]	SOFT CASE [Ⓞ]	LENS HOOD [Ⓞ]	LENS FILTER [Ⓞ]	LENS CAP [Ⓞ]
EF 50mm f/2.5 Compact Macro*	LHP-C10*	ES-C9*/ LP814	Built-in	52mm	E-52
• EF-S 60mm f/2.8 Macro USM ^{††}	None	LP1016	ET-67B	52mm	E-52U
• MP-E 65mm f/2.8 1-5x Macro Photo	None	LP1216	None	58mm	E-58
• EF 100mm f/2.8L Macro IS USM	None	LP1219	ET-73	67mm	E-67U
• EF 100mm f/2.8 Macro USM	None	LP1219	ET-67	58mm	E-58U
EF 100mm f/2.8 Macro*	None	ES-C13*/ LP816	None	52mm	E-52
• EF 180mm f/3.5L Macro USM	LH-D24C*	LZ1324	ET-78II	72mm	E-72U
Life Size Converter EF	LHP-C10*	ES-C9*/ LP811	None	None	R-F-3
TS-E 17mm f/4L Tilt-Shift	None	LP1219	None	None	Lens Cap 17
TS-E 24mm f/3.5L II Tilt-Shift	None	LP1319	EW-88B	82mm	E-82
TS-E 45mm f/2.8 Tilt-Shift	LH-D14*	LP1216	EW-79BII	72mm	E-72
TS-E 50mm f/2.8L Macro	None	LP1219	ES-84	77mm	E-77 II
TS-E 90mm f/2.8L Macro	None	LP1219	ES-84	77mm	E-77 II
TS-E 90mm f/2.8 Tilt-Shift	LH-D14*	LP1016	ES-65III	58mm	E-58
TS-E 135mm f/4L Macro	None	LP1424	ET-88	82mm	E-82 II
Extender EF 1.4x III [Ⓟ]	LH-B8*	ES-C9*/ LP811	None	None	Extender Cap EII
Extender EF 1.4x II [Ⓟ] *	LH-B8*	ES-C9*/ LP811	None	None	Extender Cap EII
Extender EF 2x III [Ⓟ]	LH-B9*	ES-C9*/ LP811	None	None	Extender Cap EII
Extender EF 2x II [Ⓟ] *	LH-B9*	ES-C9*/ LP811	None	None	Extender Cap EII

* Discontinued; for reference only.

• Incorporates distance information with E-TTL II

†† Can be mounted only on select EOS Digital Cameras (EOS 7D Mark II, 7D, 80D, 77D, 70D, 60D, 50D, 40D, 30D, 20D, Rebel T6s / T7i / T6i / T5i / T4i / T3i / T2i / T1i, Rebel T6 / T5 / T3, Rebel SL2 / SL1, Rebel XSi / XS, Digital Rebel XTi, XT and Digital Rebel).

Ⓞ *Dealers do not earn any Co-op Advertising Allowance on purchases of these products."

RF LENSES ACCESSORY CHART

<i>LENS</i>	<i>HARD CASE & TRUNKS</i> [Ⓞ]	<i>SOFT CASE</i> [Ⓞ]	<i>LENS HOOD</i> [Ⓞ]	<i>LENS FILTER</i> [Ⓞ]	<i>LENS CAP</i> [Ⓞ]
NEW • RF 24-105mm F4 L IS USM	None	LP1319	EW-83N	77mm	E-77 II
NEW • RF 28-70mm F2 L USM	None	LP1424	EW-103	95mm	E-95
NEW • RF 50mm F1.2 L USM	None	LP1319	ES-83	77mm	E-77 II
NEW • RF 35mm F1.8 Macro IS STM	None	LP1016	EW-52	52mm	E-52 II

• Incorporates distance information with E-TTL II

Ⓞ "Dealers do not earn any Co-op Advertising Allowance on purchases of these products."

EF-M LENSES ACCESSORY CHART

LENS	HARD CASE & TRUNKS [Ⓞ]	SOFT CASE [Ⓞ]	LENS HOOD [Ⓞ]	LENS FILTER [Ⓞ]	LENS CAP [Ⓞ]
• EF-M 11-22mm f/4-5.6 IS STM	None	LP814	EW-60E	55mm	E-55
• EF-M 15-45mm f/3.5-6.3 IS STM (Graphite)	None	LP811	EW-53	49mm	E-49
• EF-M 15-45mm f/3.5-6.3 IS STM (Silver)	None	LP811	EW-53	49mm	E-49
• EF-M 18-55mm f/3.5-5.6 IS STM	None	LP814	EW-54	52mm	E-52 II
• EF-M 18-150mm f/3.5-6.3 IS STM (Graphite)	None	LP816	EW-60F	55mm	E-55
• EF-M 18-150mm f/3.5-6.3 IS STM (Silver)	None	LP816	EW-60F	55mm	E-55
• EF-M 55-200mm f/4.5-6.3 IS STM (Graphite)	None	LP816	ET-54B	52mm	E-52 II
• EF-M 55-200mm f/4.5-6.3 IS STM (Silver)	None	LP816	ET-54B	52mm	E-52 II
• EF-M 22mm f/2 STM (Graphite)	None	LP811	EW-43	43mm	E-43
• EF-M 22mm f/2 STM (Silver)	None	LP811	EW-43	43mm	E-43
NEW • EF-M 32mm f/1.4 STM	None	LP1014	ES-60	43mm	E-43
• EF-M 28mm f/3.5 Macro IS STM	None	LP811	ES-22	43mm	EF-M28

• Incorporates distance information with E-TTL II

Ⓞ "Dealers do not earn any Co-op Advertising Allowance on purchases of these products."

EOS SYSTEM ACCESSORIES CHART (Part 1-1/4)

ITEM CODE	PRODUCT DESCRIPTION	1D X Mark II	1D X	1Ds Mark III/ 1D Mark IV/ 1D Mark III	1Ds Mark II/ 1D Mark II	1Ds Mark II N	1Ds / 1D	5DS/5DS R	5D Mark IV	5D Mark III	5D Mark II	5D	6D Mark II	6D	7D Mark II
POWER DRIVE BOOSTERS / CHARGERS AND BATTERY PACKS															
2254A002	Power Drive Booster PB-E2*														
3354B001	Battery Magazine BGM-E6*										•				
9833A001	Battery Magazine BGM-E2														
2446A001	Battery Magazine BM-E2*														
7084A002	Ni-MH Pack NP-E3				•	•									
2418A001	Ni-MH Pack NP-E2*														
2419A005	Ni-MH Charger NC-E2*				•	•									
7875A002	Compact Power Adapter CA-PS700														
5737A008	Compact Power Adapter CA-PS400*											•			
8466A001	Car Battery Cable CB-570		•	•								•			
3350B001	Car Battery Charger CBC-E6							•	•	•	•		•	•	•
3051B001	Car Battery Charger CBC-E5*														
1170C002	Battery Charger LC-E19	•	•	•											
9968B001	Battery Charger LC-E17														
6781B001	Battery Charger LC-E12														
5113B002	Battery Charger LC-E10														
4520B003	Battery Charger LC-E8E														
3348B001	Battery Charger LC-E6							•	•	•	•		•	•	•
3047B001	Battery Charger LC-E5*														
5752B002	Battery Charger LC-E4N*†	•	•	•											
1895B002	Battery Charger LC-E4†	•	•	•											
8478A002	Battery Charger CB-5L*											•			
0763B001	Battery Charger CB-2LW														
7303A001	Battery Charger CB-2LT*														
NEW 3250C002	USB Power Adapter PD-E1														
0073C002	AC Adapter Kit ACK-E18*														
9927B001	AC Adapter Kit ACK-E17*														
8624B002	AC Adapter Kit ACK-E15*														
6784B002	AC Adapter Kit ACK-E12*														
4517B002	AC Adapter Kit ACK-E8*														
3351B002	AC Adapter Kit ACK-E6*							•	•	•	•		•	•	•
3071B002	AC Adapter Kit ACK-E5*														
1896B002	AC Adapter Kit ACK-E4*††	•	•	•											
0766B001	AC Adapter Kit ACK-DC20*														
5113B002	AC Adapter Kit ACK-E10*														
8364A002	AC Adapter Kit ACK-E2*											•			
7097A002	DC Coupler Kit DCK-E1*				•	•									
1171C002	AC Adapter AC-E19	•	•												
1425C002	AC Adapter AC-E6N							•	•	•			•	•	•
1172C001	DC Coupler Kit DR-E19	•	•	•											
0250C001	DC Coupler Kit DR-E18														
1431C001	DC Coupler Kit DR-E17														
8623B001	DC Coupler Kit DR-E15														
6785B001	DC Coupler Kit DR-E12														
5112B001	DC Coupler Kit DR-E10														
4518B001	DC Coupler Kit DR-E8														
3352B001	DC Coupler Kit DR-E6							•	•		•		•		•
3072B001	DC Coupler Kit DR-E5*														
5738A001	DC Coupler Kit DR-400*											•			
NEW 3086C002	Battery Grip BG-E22														
2130C001	Battery Grip BG-E21												•		
1485C001	Battery Grip BG-E20								•						
0050C001	Battery Grip BG-E18														
9130B001	Battery Grip BG-E16														•
8471B001	Battery Grip BG-E14														
8038B001	Battery Grip BG-E13														
5261B001	Battery Grip BG-E11							•		•				•	
4740B001	Battery Grip BG-E9*														
4516B001	Battery Grip BG-E8*														
3815B001	Battery Grip BG-E7*														
3353B001	Battery Grip BG-E6*										•				
3052B001	Battery Grip BG-E5														
0297B001	Battery Grip BG-E4*											•			
0211B001	Battery Grip BG-E3*														

* Discontinued *Dealers do not earn any Co-op Advertising Allowance on purchases of these products.*

a May require exposure compensation. b Requires RA-N3 Adapter. c Requires Adapter Ed-c (included w/ Angle Finder C). d Requires Adapter Ec-c (included w/ Angle Finder C). e Not for use w/ EOS-1N RS. f EOS-1v only; not for use with a Power Drive Booster. g No TTL flash possible. h 30D only. i T5i/T4i only. j Not for use w/ K2. k For Power Drive Booster PB-E2 only. l Rebel XT only. m Rebel only. n Requires Remote Controller Adapter RA-E3. o No TTL flash possible for IX Lite only. p T5 only. q IX only. r 30D/20D only. s XSi/T1i only. t 1Ds Mark III/1D Mark III require firmware upgrade. u 1D Mark IV only. v XSi/XS only. w XT1/XT only. x Firmware update required. y Requires a firmware update and Interface Cables IFC-40AB II or IFC-150AB II. z The digital compass function is not supported.

† Although Battery Charger LC-E19 can be used to charge Battery Pack LP-E4/E4N, Battery Charger LC-E4/E4N cannot be used to charge Battery Pack LP-E19.

†† When using ACK-E4 with the EOS-1D X Mark II camera the continuous shooting speed and maximum burst rate will be lowered when compared to using AC-E19 + DR-E19.

EOS SYSTEM ACCESSORIES CHART (Part 1-2/4)

ITEM CODE	PRODUCT DESCRIPTION	1D X Mark II	1D X	1Ds Mark III/ 1D Mark IV/ 1D Mark III	1Ds Mark II/ 1D Mark II N	1Ds / 1D	5DS/5DS R	5D Mark IV	5D Mark III	5D Mark II	5D	6D Mark II	6D	7D Mark II
☛ POWER DRIVE BOOSTERS / CHARGERS AND BATTERY PACKS (CONT.)														
2313B001	Battery Grip BG-E2N*													
9444A001	Battery Grip BG-E2*													
8865A001	Battery Grip BG-E1*													
1169C002	Battery Pack LP-E19	●	●	●										
9967B002	Battery Pack LP-E17													
6760B002	Battery Pack LP-E12													
5108B002	Battery Pack LP-E10													
4515B002	Battery Pack LP-E8													
9486B002	Battery Pack LP-E6N						●	●	●	●		●	●	●
3347B001	Battery Pack LP-E6* †						●	●	●	●		●	●	●
3039B001	Battery Pack LP-E5 †											●	●	●
5751B002	Battery Pack LP-E4N	●	●	●										
1891B002	Battery Pack LP-E4*	●	●	●										
9200A001	Battery Pack BP-511A										●			
2413A002	Battery Pack BP-E1*													
4594A002	Battery Pack BP-300*													
8093A001	Battery Pack BP-220*													
2415A001	Battery Pack BP-50*													
9612A001	Battery Pack NB-2LH*													
☛ REMOTE CONTROLLERS AND ACCESSORIES														
2140C001	Wireless Remote Control BR-E1												●	
4524B001	Wireless Controller RC-6						●	●	●			●	●	●
2467A001	Wireless Controller RC-5*						●	●	●				●	
2465A001	Wireless Controller RC-1*							●	●				●	
0295B001	Wireless Controller LC-5	●	●	●	●	●		●	●			●	●	●
2474A002	Wireless Controller LC-4*		●	● <i>b</i>	● <i>b</i>	● <i>b</i>					● <i>b</i>			
2471A002	Wireless Controller LC-3 Set*			● <i>b</i>	● <i>b</i>	● <i>b</i>					● <i>b</i>			
2477A002	Timer Remote Controller TC-80N3	●	●	●	●	●	●	●	●	●	●	●	●	●
1157C001	Remote Controller Adapter RA-E3													
2476A001	Remote Switch RS-80N3	●	●	●	●	●	●	●	●		●	●		●
2469A002	Remote Switch RS-60E3													
2393A001	Remote Switch 60T3*			● <i>b</i>	● <i>b</i>	● <i>b</i>					● <i>b</i>			
2449A001	Remote Switch Adapter T3*			● <i>b</i>	● <i>b</i>	● <i>b</i>					● <i>b</i>			
2441A001	Remote Switch Adapter RA-N3*	●	●	●	●	●					●			
2450A001	Cable Release Adapter T3*		●	● <i>b</i>	● <i>b</i>	● <i>b</i>					● <i>b</i>			
2440A001	Extension Cord ET-1000N3*		●	●	●	●			●	●	●			
2455A001	Extension Cord 1000T3			● <i>b</i>	● <i>b</i>	● <i>b</i>			● <i>b</i>	● <i>b</i>	● <i>b</i>			
☛ VIEWING ACCESSORIES														
0047C001	Magnifier MG-Eb	Please note that the magnifier will reduce the field of view visible through the camera's viewfinder and display. This effect on the image through the viewfinder will be more pronounced while wearing glasses. The magnifier may blur the image visible through the viewfinder and may make it more difficult to focus the camera manually. Please note, the image taken with the camera will not be affected by any of the above.												
0048C001	Magnifier MG-Ef													
1889B001	Eyecup Eg	●	●	●			●	●	●					●
8171A001	Eyecup Ef													
2377A001	Eyecup Ec II				●	●								
2378A001	Eyecup Eb									●	●	●	●	
8172A001	Rubber Frame Ef													
2858A001	Rubber Frame Eb*									●	●	●	●	
2200B001	Anti-Fog Eyepiece Eg	●	●	●			●	●	●					●
2880A001	Anti-Fog Eyepiece Ed*													
2879A001	Anti-Fog Eyepiece Ec				●	●								
3069B001	Eyepiece Extender EP-EX15 II*									●	●		●	
2444A001	Eyepiece Extender EP-EX15*									●	●	●		
2882A001	Angle Finder C	● <i>d</i>	● <i>d</i>	● <i>d</i>	● <i>d</i>	● <i>d</i>	● <i>d</i>	● <i>d</i>	● <i>d</i>	● <i>d</i>	● <i>d</i>	● <i>d</i>	● <i>d</i>	● <i>d</i>
1727C001	Electronic Viewfinder EVF-DC2 (BK)													
1882C001	Electronic Viewfinder EVF-DC2 (SL)													
9555B001	Electronic Viewfinder EVF-DC1													
☛ EXTENSION TUBES AND CLOSE UP ACCESSORIES														
9198A001/9199A001	Extension Tube EF12 II / EF25 II			● <i>a</i>	● <i>a</i>	● <i>a</i>				● <i>a</i>	● <i>a</i>	● <i>a</i>		● <i>a</i>
2819A001	52mm Close up Lens 250D													
2821A001	52mm Close up Lens 500D													
2820A001	58mm Close up Lens 250D													
2822A001	58mm Close up Lens 500D													
2823A001	72mm Close up Lens 500D													
2824A001	77mm Close up Lens 500D													

* Discontinued ☛ Dealers do not earn any Co-op Advertising Allowance on purchases of these products.†

a May require exposure compensation. *b* Requires RA-N3 Adapter. *c* Requires Adapter Ed-c (included w/ Angle Finder C). *d* Requires Adapter Ec-c (included w/ Angle Finder C). *e* Not for use w/ EOS-1n RS. *f* EOS-1v only; not for use with a Power Drive Booster. *g* No TTL flash possible. *h* 30D only. *i* T5i/T4i only. *j* Not for use w/ K2. *k* For Power Drive Booster PB-E2 only. *l* Rebel XT only. *m* Rebel only. *n* Requires Remote Controller Adapter RA-E3. *o* No TTL flash possible for IX Lite only. *p* T5 only. *q* IX only. *r* 30D/20D only. *s* XSi/T1i only. *t* 1Ds Mark III/1D Mark III require firmware upgrade. *u* 1D Mark IV only. *v* XSi/XS only. *w* XTi/XT only. *x* Firmware update required. *y* Requires a firmware update and Interface Cables IFC-40AB II or IFC-150AB II. *z* The digital compass function is not supported.

† When using Battery Pack LP-E4/E4N with the EOS-1D X Mark II camera the continuous shooting speed and maximum burst rate will be lowered when compared to using the Battery Pack LP-E19.

EOS SYSTEM ACCESSORIES CHART (Part 1-3/4)

ITEM CODE	PRODUCT DESCRIPTION	1D X Mark II	1D X	1Ds Mark III/ 1D Mark IV/ 1D Mark III	1Ds Mark II/ 1D Mark II N	1Ds / 1D	5DS/5DS R	5D Mark IV	5D Mark III	5D Mark II	5D	6D Mark II	6D	7D Mark II	
SPEEDLITE AND ACCESSORIES (CONT.)															
2398C002	Macro Twin Lite MT-26EX-RT	●	●	●	●	●	●	●	●	●	●	●	●	●	
2357A002	Macro Twin Lite MT-24EX	●	●	●	●	●	●	●	●	●	●	●	●	●	
9389B002	Macro Ring Lite MR-14EX II	●	●	●	●	●	●	●	●	●	●	●	●	●	
2356A002	Macro Ring Lite MR-14EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
1177C002	Speedlite 600EX II-RT	●	●	●	●	●	●	●	●	●	●	●	●	●	
5296B002	Speedlite 600EX-RT*	●	●	●	●	●	●	●	●	●	●	●	●	●	
1946B002	Speedlite 580EX II*	●	●	●	●	●	●	●	●	●	●	●	●	●	
9445A002	Speedlite 580EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
2261A003	Speedlite 550EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
4580A001	Speedlite 540EZ	●g	●g	●g	●g	●g	●g	●g	●g	●g	●g	●g	●g	●g	
2258A003	Speedlite 480EG Set*	●g	●g	●g	●g	●g	●g	●g	●g	●g	●g	●g	●g	●g	
1957C002	Speedlite 470EX-AI	●	●	●	●	●	●	●	●	●	●	●	●	●	
0585C006	Speedlite 430EX III-RT	●	●	●	●	●	●	●	●	●	●	●	●	●	
2805B002	Speedlite 430EX II*	●	●	●	●	●	●	●	●	●	●	●	●	●	
0298B002	Speedlite 430EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
4590A009	Speedlite 420EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
	Speedlite 380EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
5246B002	Speedlite 320EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
5247B002	Speedlite 270EX II	●	●	●	●	●	●	●	●	●	●	●	●	●	
3806B002	Speedlite 270EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
2262A006	Speedlite 220EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
6825B002	Speedlite 90EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
2257A001	Speedlite 200E*			●g	●g	●g									
	Macro Ring Lite ML-3 Set*														
	Slave Unit E*	For exclusive use w/ Speedlite 480EG													
● 1180C001	Compact Battery Pack CP-E4N	For exclusive use w/ Speedlite 600EX II-RT, 600EX-RT, 600EX, 580EX II, 580EX, 550EX, 540EZ, 430EZ, Macro Ring Lite MR-14EX II, MR-14EX, Macro Twin Lite MT-26EX-RT, MT-24EX													
● 1947B001	Compact Battery Pack CP-E4*	For exclusive use w/ Speedlite 580EX II, 580EX, 550EX, 540EZ, 480EG, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX													
● 9836A001	Compact Battery Pack CP-E3*	For exclusive use w/ Speedlite 580EX, 550EX, 540EZ, 480EG, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX													
● 2448A001	Compact Battery Pack CP-E2*	For exclusive use w/ Speedlite 580EX, 550EX, 540EZ, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX													
● 5743B002	Speedlite Transmitter ST-E3-RT	For exclusive use w/ Speedlite 600EX II-RT, 600EX-RT, 430EX III-RT													
● 2478A002	Speedlite Transmitter ST-E2	For exclusive use w/ Speedlite 600EX II-RT, 600EX-RT, 580EX II, 580EX, 550EX, 470EX-AI, 430EX III-RT, 430EX, 420EX													
● 2402A005	Transistor Pack E Ni-Cd Set*	For exclusive use w/ Speedlite 550EX, 540EZ, 480EG, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX													
● 2402A006	Transistor Pack E*	For exclusive use w/ Speedlite 580EX, 550EX, 540EZ, 480EG, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX													
● 2429A001	Battery Magazine TP	For exclusive use w/ Transistor Pack E*													
● 1948B001	Battery Magazine CPM-E4*	For exclusive use w/ Speedlite Speedlite 600EX-RT, 580EX II													
● 2403A007	Ni-Cd Pack TP*	For exclusive use w/ Transistor Pack E*													
● 2401A003	Ni-Cd Charger TP*	For exclusive use w/ Transistor Pack E*													
● 2438A001	TTL Hot Shoe Adapter 3*	For exclusive use w/Connecting Cords 60 & 300 (Not compatible with any EOS Digital SLR cameras)													
	Off-Camera Shoe Adapter*														
● 2447A001	Off-Camera Shoe Adapter OA-2*	For exclusive use w/TTL Hot Shoe Adapter 3, TTL Distributor & Off-Camera Shoe Adapter (Not compatible with any EOS digital SLR cameras)													
● 2431A001	TTL Distributor														
● 2387A001	Connecting Cord 60	For exclusive use w/TTL Hot Shoe Adapter 3, TTL Distributor & Off-Camera Shoe Adapter (Not compatible with any EOS digital SLR cameras)													
● 2388A001	Connecting Cord 300														
● 2391A001	Off-Camera Shoe Cord 2*		●	●	●							●			
● 1950B00	Off-Camera Shoe Cord OC-E3	Dust/Water-resistant for use w/Speedlite 600EX II-RT, 600EX-RT, 580EX II, for exclusive use w/ Speedlite 580EX, 470EX-AI, 430EX III-RT, 430EX													
● 5744B001	Speedlite Release Cable SR-N3	For exclusive use w/ Speedlite 600EX-RT													
● 2364A001	MacroLite Adapter 52C	For exclusive use w/ Macro Ring Lite ML-3 / M6.5													
● 2365A001	MacroLite Adapter 58C	R-14EX / Macro Twin Lite MT-24EX													
● 3563B001	MacroLite Adapter 67	For exclusive use w/ Macro Ring Lite MR-14EX, ML-3, Macro Twin Lite MT-26EX-RT, MT-24EX													
● 2829A001	MacroLite Adapter 72C	For exclusive use w/ Macro Ring Lite MR-14EX, ML-3, Macro Twin Lite MT-26EX-RT, MT-24EX													
	Wide Adapter 200E*	For exclusive use w/ Speedlite 200E													
● 1179C001	Bounce Adapter SBA-E3	For exclusive use w/ Speedlite 600EX II-RT													
● 0588C001	Bounce Adapter SBA-E2	For exclusive use w/ Speedlite 430EX III-RT													
● 1178C001	Color Filter Set SCF-E3	For exclusive use w/ Speedlite 600EX II-RT													
● 0587C001	Color Filter Set SCF-E2	For exclusive use w/ Speedlite 430EX III-RT													
● 5746B001	Color Filter Set SCF-E1	For exclusive use w/ Speedlite 600EX-RT													
● 5745B001	Color Filter Holder SCH-E1	For exclusive use w/ Speedlite 600EX-RT													
● GPS, WIRELESS TRANSMITTERS & ADAPTERS															
6363B001	GPS Receiver GP-E2		●				●		●x					●	
6364B001	GPS Receiver GP-E1		●												
1173C001	Wireless File Transmitter WFT-E8A	●													
5754B009	Wireless File Transmitter WFT-E7A (Ver. 2)						●	●	●					●	
5754B001	Wireless File Transmitter WFT-E7A*†						●y	●y	●					●y	
5756B001	Wireless File Transmitter WFT-E6A*	●	●												

* Discontinued ● Dealers do not earn any Co-op Advertising Allowance on purchases of these products.
 a May require exposure compensation. b Requires RA-N3 Adapter. c Requires Adapter Ed-c (included w/ Angle Finder C). d Requires Adapter Ec-c (included w/ Angle Finder C). e Not for use w/ EOS-1n RS.
 f EOS-1v only; not for use with a Power Drive Booster. g No TTL flash possible. h 30D only. i TS1/T4i only. j Not for use w/ K2. k For Power Drive Booster PB-E2 only. l Rebel XT only. m Rebel only.
 n Requires Remote Controller Adapter RA-E3. o No TTL flash possible for IX Lite only. p T5 only. q IX only. r 30D/20D only. s XSi/T1i only. t 1Ds Mark III/1D Mark III require firmware upgrade. u 1D Mark IV only.
 v XSi/XS only. w XT/XT only. x Firmware update required. y Requires a firmware update and Interface Cables IFC-40AB II or IFC-150AB II. z The digital compass function is not supported.
 † The WFT-E7A requires a firmware update and Interface Cables IFC-40AB II or IFC-150AB II to work with the EOS 5DS, EOS 5DS R, EOS 5D Mark IV and 7D Mark II.

EOS SYSTEM ACCESSORIES CHART (Part 1-4/4)

ITEM CODE	PRODUCT DESCRIPTION	1D X Mark II	1D X	1Ds Mark III/ 1D Mark IV/ 1D Mark III	1Ds Mark II/ 1D Mark II 1D Mark II N	1Ds / 1D	5DS/5DS R	5D Mark IV	5D Mark III	5D Mark II	5D	6D Mark II	6D	7D Mark II
GPS, WIRELESS TRANSMITTERS & ADAPTERS (CONT.)														
3829B001	Wireless File Transmitter WFT-E5A													
4263B001	Wireless File Transmitter WFT-E4 II A*									•				
2806B002	Wireless File Transmitter WFT-E4A*									•				
2375B002	Wireless File Transmitter WFT-E3A*													
4262B001	Wireless File Transmitter WFT-E2 II A*			• <i>t</i>										
1906B002	Wireless File Transmitter WFT-E2A*			•										
0032B002	Wireless File Transmitter WFT-E1A				•						•			
0127B001	Wireless Range Antenna ERA-E1*				•						•			
1716C001	Wi-Fi Adapter W-E1						•							•
STORAGE														
9899B002	Connect Station CS100*	•	•				•	•	•			•	•	•
MICROPHONE														
1429C001	Directional Microphone DM-E1	•	•	• <i>u</i>			•	•	•			•	•	•

* Discontinued • *Dealers do not earn any Co-op Advertising Allowance on purchases of these products.
a May require exposure compensation. *b* Requires RA-N3 Adapter. *c* Requires Adapter Ed-c (included w/ Angle Finder C). *d* Requires Adapter Ec-c (included w/ Angle Finder C). *e* Not for use w/ EOS-1n RS.
f EOS-1v only; not for use with a Power Drive Booster. *g* No TTL flash possible. *h* 30D only. *i* T5i/T4i only. *j* Not for use w/ K2. *k* For Power Drive Booster PB-E2 only. *l* Rebel XT only. *m* Rebel only.
n Requires Remote Controller Adapter RA-E3. *o* No TTL flash possible for IX Lite only. *p* T5 only. *q* IX only. *r* 30D/20D only. *s* XSi/T1i only. *t* 1Ds Mark III/1D Mark III require firmware upgrade. *u* 1D Mark IV only.
v XSi/XS only. *w* XT/XT only. *x* Firmware update required. *y* Requires a firmware update and Interface Cables IFC-40AB II or IFC-150AB II. *z* The digital compass function is not supported.



EOS SYSTEM ACCESSORIES CHART (Part 2-1/4)

ITEM CODE	PRODUCT DESCRIPTION	7D	80D	77D	70D	60D	50D / 40D	Rebel T7i	Rebel T6s / T6i	Rebel T5i / T4i / T3i / T2i	Rebel T6	Rebel T5 / T3	Rebel SL2	Rebel SL1	
POWER DRIVE BOOSTERS / CHARGERS AND BATTERY PACKS															
2254A002	Power Drive Booster PB-E2*														
3354B001	Battery Magazine BGM-E6*	•													
9833A001	Battery Magazine BGM-E2						•								
2446A001	Battery Magazine BM-E2*														
7084A002	Ni-MH Pack NP-E3														
2418A001	Ni-MH Pack NP-E2*														
2419A005	Ni-MH Charger NC-E2*														
7875A002	Compact Power Adapter CA-PS700									•	•	•			
5737A008	Compact Power Adapter CA-PS400*						•								
8466A001	Car Battery Cable CB-570	•	•		•	•	•								
3350B001	Car Battery Charger CBC-E6	•	•		•	•									
3051B001	Car Battery Charger CBC-E5*														
1170C002	Battery Charger LC-E19														
9968B001	Battery Charger LC-E17				•			•	•				•		
6781B001	Battery Charger LC-E12														•
5113B002	Battery Charger LC-E10										•	•			
4520B003	Battery Charger LC-E8E									•					
3348B001	Battery Charger LC-E6	•	•		•	•									
3047B001	Battery Charger LC-E5*														
5752B002	Battery Charger LC-E4N*														
1895B002	Battery Charger LC-E4														
8478A002	Battery Charger CB-5L*						•								
0763B001	Battery Charger CB-2LW														
7303A001	Battery Charger CB-2LT*														
NEW 3250C002	USB Power Adapter PD-E1														
0073C002	AC Adapter Kit ACK-E18*			•				•	•				•		
9927B001	AC Adapter Kit ACK-E17*														
8624B002	AC Adapter Kit ACK-E15*														•
6784B002	AC Adapter Kit ACK-E12*														
4517B002	AC Adapter Kit ACK-E8*									•					
3351B002	AC Adapter Kit ACK-E6*	•	•		•	•									
3071B002	AC Adapter Kit ACK-E5*														
1896B002	AC Adapter Kit ACK-E4*														
0766B001	AC Adapter Kit ACK-DC20*														
5113B002	AC Adapter Kit ACK-E10*										•				
8364A002	AC Adapter Kit ACK-E2*						•								
7097A002	DC Coupler Kit DCK-E1*														
1171C002	AC Adapter AC-E19														
1425C002	AC Adapter AC-E6N	•	•	•	•	•		•	•				•		
1172C001	DC Coupler Kit DR-E19														
0250C001	DC Coupler Kit DR-E18								•				•		
1431C001	DC Coupler Kit DR-E17														
8623B001	DC Coupler Kit DR-E15														•
6785B001	DC Coupler Kit DR-E12														
5112B001	DC Coupler Kit DR-E10										•	•			
4518B001	DC Coupler Kit DR-E8									•					
3352B001	DC Coupler Kit DR-E6	•	•		•	•									
3072B001	DC Coupler Kit DR-E5*						•								
5738A001	DC Coupler Kit DR-400*														
NEW 3086C002	Battery Grip BG-E22														
2130C001	Battery Grip BG-E21														
1485C001	Battery Grip BG-E20														
0050C001	Battery Grip BG-E18								•						
9130B001	Battery Grip BG-E16														
8471B001	Battery Grip BG-E14		•		•										
8038B001	Battery Grip BG-E13														
5261B001	Battery Grip BG-E11														
4740B001	Battery Grip BG-E9*					•									
4516B001	Battery Grip BG-E8*									•					
3815B001	Battery Grip BG-E7*	•													
3353B001	Battery Grip BG-E6*														
3052B001	Battery Grip BG-E5											•			
0297B001	Battery Grip BG-E4*														
0211B001	Battery Grip BG-E3*														

* Discontinued *Dealers do not earn any Co-op Advertising Allowance on purchases of these products.
a May require exposure compensation. b Requires RA-N3 Adapter. c Requires Adapter Ed-c (included w/ Angle Finder C). d Requires Adapter Ec-c (included w/ Angle Finder C). e Not for use w/ EOS-1N RS.
f EOS-1v only; not for use with a Power Drive Booster. g No TTL flash possible. h 30D only. i T5i/T4i only. j Not for use w/ K2. k For Power Drive Booster PB-E2 only. l Rebel XT only. m Rebel only.
n Requires Remote Controller Adapter RA-E3. o No TTL flash possible for IX Lite only. p T5 only. q IX only. r 30D/20D only. s XSi/T1i only. t 1Ds Mark III/1D Mark III require firmware upgrade. u 1D Mark IV only.
v XSi/XS only. w XTi/XT only. x Firmware update required y Requires a firmware update and Interface Cables IFC-40AB II or IFC-150AB II. z The digital compass function is not supported.

EOS SYSTEM ACCESSORIES CHART (Part 2-2/4)

ITEM CODE	PRODUCT DESCRIPTION	7D	80D	77D	70D	60D	50D / 40D	Rebel T7i	Rebel T6s / T6i	Rebel T5i / T4i / T3i / T2i	Rebel T6	Rebel T5 / T3	Rebel SL2	Rebel SL1	
◊ POWER DRIVE BOOSTERS / CHARGERS AND BATTERY PACKS (CONT.)															
2313B001	Battery Grip BG-E2N*						•								
9444A001	Battery Grip BG-E2*						•								
8865A001	Battery Grip BG-E1*														
1169C002	Battery Pack LP-E19														
9967B002	Battery Pack LP-E17			•				•	•				•		
6760B002	Battery Pack LP-E12														•
5108B002	Battery Pack LP-E10										•	•			
4515B002	Battery Pack LP-E8									•					
9486B002	Battery Pack LP-E6N	•	•		•	•									
3347B001	Battery Pack LP-E6*	•	•		•	•									
3039B001	Battery Pack LP-E5														
5751B002	Battery Pack LP-E4N														
1891B002	Battery Pack LP-E4*						•								
9200A001	Battery Pack BP-511A														
2413A002	Battery Pack BP-E1*														
4594A002	Battery Pack BP-300*														
8093A001	Battery Pack BP-220*														
2415A001	Battery Pack BP-50*														
9612A001	Battery Pack NB-2LH*														
◊ REMOTE CONTROLLERS AND ACCESSORIES															
2140C001	Wireless Remote Control BR-E1				•				•					•	
4524B001	Wireless Controller RC-6	•	•	•	•	•		•	•	•					•
2467A001	Wireless Controller RC-5*	•								•					
2465A001	Wireless Controller RC-1*	•								•					
0295B001	Wireless Controller LC-5	•													
2474A002	Wireless Controller LC-4*									• b					
2471A002	Wireless Controller LC-3 Set*									• b					
2477A002	Timer Remote Controller TC-80N3	•	• n	• n	• n	• n	• n	• n	• n	• n	• n	• n	• n	• n	• n
1157C001	Remote Controller Adapter RA-E3		•	•	•	•		•	•	•	•	•	•	•	•
2476A001	Remote Switch RS-80N3	•						•							
2469A002	Remote Switch RS-60E3		•	•	•	•		•	•	•	•	•	•	•	•
2393A001	Remote Switch 60T3*									• b					
2449A001	Remote Switch Adapter T3*									• b					
2441A001	Remote Switch Adapter RA-N3*									•					
2450A001	Cable Release Adapter T3*									• b					
2440A001	Extension Cord ET-1000N3*		•							•					
2455A001	Extension Cord 1000T3	• b								• b					
◊ VIEWING ACCESSORIES															
0047C001	Magnifier MG-Eb		•		•	•	•								
0048C001	Magnifier MG-Ef			•				•	•	•	•	•	•	•	•
1889B001	Eyecup Eg	•													
8171A001	Eyecup Ef			•				•	•	•	•	•	•	•	•
2377A001	Eyecup Ec II														
2378A001	Eyecup Eb		•		•	•	•								
8172A001	Rubber Frame Ef			•				•	•	•	•	•	•	•	•
2858A001	Rubber Frame Eb*		•		•	•	•								
2200B001	Anti-Fog Eyepiece Eg	•													
2880A001	Anti-Fog Eyepiece Ed*														
2879A001	Anti-Fog Eyepiece Ec														
3069B001	Eyepiece Extender EP-EX15 II*			•		•	•	•	•	•	•	•	•	•	•
2444A001	Eyepiece Extender EP-EX15*		•		•	•	•								
2882A001	Angle Finder C	• d	• d	• d	• d	• d	• d	• d	• d	• d	• d	• d	• d	• d	• d
1727C001	Electronic Viewfinder EVF-DC2 (BK)														
1882C001	Electronic Viewfinder EVF-DC2 (SL)														
9555B001	Electronic Viewfinder EVF-DC1														
◊ EXTENSION TUBES AND CLOSE UP ACCESSORIES															
9198A001/9199A001	Extension Tube EF12 II / EF25 II	• a					• a	• a		• a			• a		
2819A001	52mm Close up Lens 250D														
2821A001	52mm Close up Lens 500D														
2820A001	58mm Close up Lens 250D														
2822A001	58mm Close up Lens 500D														
2823A001	72mm Close up Lens 500D														
2824A001	77mm Close up Lens 500D														

* Discontinued ◊ Dealers do not earn any Co-op Advertising Allowance on purchases of these products.†

a May require exposure compensation. b Requires RA-N3 Adapter. c Requires Adapter Ed-c (included w/ Angle Finder C). d Requires Adapter Ec-c (included w/ Angle Finder C). e Not for use w/ EOS-1n RS. f EOS-1v only; not for use with a Power Drive Booster. g No TTL flash possible. h 30D only. i T5i/T4i only. j Not for use w/ K2. k For Power Drive Booster PB-E2 only. l Rebel XT only. m Rebel only. n Requires Remote Controller Adapter RA-E3. o No TTL flash possible for IX Lite only. p T5 only. q IX only. r 30D/20D only. s XSi/T1i only. t 1Ds Mark III/1D Mark III require firmware upgrade. u 1D Mark IV only. v XSi/XS only. w XT/XT only. x Firmware update required. y Requires a firmware update and Interface Cables IFC-40AB II or IFC-150AB II. z The digital compass function is not supported.

◊ Please note that the magnifier will reduce the field of view visible through the camera's viewfinder and display. This effect on the image through the viewfinder will be more pronounced while wearing glasses. The magnifier may blur the image visible through the viewfinder and may make it more difficult to focus the camera manually. Please note, the image taken with the camera will not be affected by any of the above.

EOS SYSTEM ACCESSORIES CHART (Part 2-3/4)

ITEM CODE	PRODUCT DESCRIPTION	7D	80D	77D	70D	60D	50D / 40D	Rebel T7i	Rebel T6s / T6i	Rebel T5i / T4i / T3i / T2i	Rebel T6	Rebel T5 / T3	Rebel SL2	Rebel SL1	
SPEEDLITE AND ACCESSORIES (CONT.)															
2398C002	Macro Twin Lite MT-26EX-RT	●	●	●	●	●	●	●	●	●	●	●	●	●	
2357A002	Macro Twin Lite MT-24EX	●	●	●	●	●	●	●	●	●	●	●	●	●	
9389B002	Macro Ring Lite MR-14EX II	●	●	●	●	●	●	●	●	●	●	●	●	●	
2356A002	Macro Ring Lite MR-14EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
1177C002	Speedlite 600EX II-RT	●	●	●	●	●	●	●	●	●	●	●	●	●	
5296B002	Speedlite 600EX-RT*	●	●	●	●	●	●	●	●	●	●	●	●	●	
1946B002	Speedlite 580EX II*	●	●	●	●	●	●	●	●	●	●	●	●	●	
9445A002	Speedlite 580EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
2261A003	Speedlite 550EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
4580A001	Speedlite 540EZ	●g	●g	●g	●g	●g	●g	●g	●g	●g	●g	●g	●g	●g	
2258A003	Speedlite 480EG Set*	●g	●g	●g	●g	●g	●g	●g	●g	●g	●g	●g	●g	●g	
1957C002	Speedlite 470EX-AI	●	●	●	●	●	●	●	●	●	●	●	●	●	
0585C006	Speedlite 430EX III-RT	●	●	●	●	●	●	●	●	●	●	●	●	●	
2805B002	Speedlite 430EX II*	●	●	●	●	●	●	●	●	●	●	●	●	●	
0298B002	Speedlite 430EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
4590A009	Speedlite 420EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
	Speedlite 380EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
5246B002	Speedlite 320EX*	●	●	●	●	●	●	●	●	●	●	●	●g	●g	
5247B002	Speedlite 270EX II	●	●	●	●	●	●	●	●	●	●	●	●g	●g	
3806B002	Speedlite 270EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
2262A006	Speedlite 220EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
6825B002	Speedlite 90EX*	●	●	●	●	●	●	●	●	●	●	●	●	●	
2257A001	Speedlite 200E*														
	Macro Ring Lite ML-3 Set*														
	Slave Unit E*	For exclusive use w/ Speedlite 480EG													
Ⓢ1180C001	Compact Battery Pack CP-E4N	For exclusive use w/ Speedlite 600EX II-RT, 600EX-RT, 600EX, 580EX II, 580EX, 550EX, 540EZ, 430EZ, Macro Ring Lite MR-14EX II, MR-14EX, Macro Twin Lite MT-26EX-RT, MT-24EX													
Ⓢ1947B001	Compact Battery Pack CP-E4*	For exclusive use w/ Speedlite 580EX II, 580EX, 550EX, 540EZ, 480EG, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX													
Ⓢ9836A001	Compact Battery Pack CP-E3*	For exclusive use w/ Speedlite 580EX, 550EX, 540EZ, 480EG, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX													
Ⓢ2448A001	Compact Battery Pack CP-E2*	For exclusive use w/ Speedlite 580EX, 550EX, 540EZ, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX													
Ⓢ5743B002	Speedlite Transmitter ST-E3-RT	For exclusive use w/ Speedlite 600EX II-RT, 600EX-RT, 430EX III-RT													
Ⓢ2478A002	Speedlite Transmitter ST-E2	For exclusive use w/ Speedlite 600EX II-RT, 600EX-RT, 580EX II, 580EX, 550EX, 470EX-AI, 430EX III-RT, 430EX, 420EX													
Ⓢ2402A005	Transistor Pack E Ni-Cd Set*	For exclusive use w/ Speedlite 550EX, 540EZ, 480EG, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX													
Ⓢ2402A006	Transistor Pack E*	For exclusive use w/ Speedlite 580EX, 550EX, 540EZ, 480EG, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX													
Ⓢ2429A001	Battery Magazine TP	For exclusive use w/ Transistor Pack E*													
Ⓢ1948B001	Battery Magazine CPM-E4*	For exclusive use w/ Speedlite Speedlite 600EX-RT, 580EX II													
Ⓢ2403A007	Ni-Cd Pack TP*	For exclusive use w/ Transistor Pack E*													
Ⓢ2401A003	Ni-Cd Charger TP*	For exclusive use w/ Transistor Pack E*													
Ⓢ2438A001	TTL Hot Shoe Adapter 3*	For exclusive use w/Connecting Cords 60 & 300 (Not compatible with any EOS digital SLR cameras)													
	Off-Camera Shoe Adapter*														
Ⓢ2447A001	Off-Camera Shoe Adapter OA-2*														
Ⓢ2431A001	TTL Distributor	For exclusive use w/TTL Hot Shoe Adapter 3, TTL Distributor & Off-Camera Shoe Adapter (Not compatible with any EOS digital SLR cameras)													
Ⓢ2387A001	Connecting Cord 60														
Ⓢ2388A001	Connecting Cord 300														
Ⓢ2391A001	Off-Camera Shoe Cord 2*				●	●									
Ⓢ1950B00	Off-Camera Shoe Cord OC-E3	Dust/Water-resistant for use w/Speedlite 600EX II-RT, 600EX-RT, 580EX II, for exclusive use w/ Speedlite 580EX, 470EX-AI, 430EX III-RT, 430EX													
Ⓢ5744B001	Speedlite Release Cable SR-N3	For exclusive use w/ Speedlite 600EX-RT													
Ⓢ2364A001	Macrolite Adapter 52C	For exclusive use w/ Macro Ring Lite ML-3 / MR-14EX / Macro Twin Lite MT-24EX													
Ⓢ2365A001	Macrolite Adapter 58C														
Ⓢ3563B001	Macrolite Adapter 67														
Ⓢ2829A001	Macrolite Adapter 72C	For exclusive use w/ Macro Ring Lite MR-14EX, ML-3, Macro Twin Lite MT-26EX-RT, MT-24EX													
	Wide Adapter 200E*	For exclusive use w/ Speedlite 200E													
Ⓢ1179C001	Bounce Adapter SBA-E3	For exclusive use w/ Speedlite 600EX II-RT													
Ⓢ0588C001	Bounce Adapter SBA-E2	For exclusive use w/ Speedlite 430EX III-RT													
Ⓢ1178C001	Color Filter Set SCF-E3	For exclusive use w/ Speedlite 600EX II-RT													
Ⓢ0587C001	Color Filter Set SCF-E2	For exclusive use w/ Speedlite 430EX III-RT													
Ⓢ5746B001	Color Filter Set SCF-E1	For exclusive use w/ Speedlite 600EX-RT													
Ⓢ5745B001	Color Filter Holder SCH-E1	For exclusive use w/ Speedlite 600EX-RT													
ⓈGPS, WIRELESS TRANSMITTERS & ADAPTERS															
6363B001	GPS Receiver GP-E2	●x	●	●	●				●z	●	●j	●	●p	●z	●
6364B001	GPS Receiver GP-E1														
1173C001	Wireless File Transmitter WFT-E8A														
5754B009	Wireless File Transmitter WFT-E7A (Ver. 2)														
5754B001	Wireless File Transmitter WFT-E7A*														
5756B001	Wireless File Transmitter WFT-E6A*														

* Discontinued ⓈDealers do not earn any Co-op Advertising Allowance on purchases of these products.
a May require exposure compensation. b Requires RA-N3 Adapter. c Requires Adapter Ed-c (included w/ Angle Finder C). d Requires Adapter Ec-c (included w/ Angle Finder C). e Not for use w/ EOS-1n RS.
f EOS-1v only; not for use with a Power Drive Booster. g No TTL flash possible. h 30D only. i T5i/T4i only. j Not for use w/ K2. k For Power Drive Booster PB-E2 only. l Rebel XT only. m Rebel only.
n Requires Remote Controller Adapter RA-E3. o No TTL flash possible for IX Lite only. p T5 only. q IX only. r 30D/20D only. s XSi/T1i only. t 1Ds Mark III/1D Mark III require firmware upgrade. u 1D Mark IV only.
v XSi/XS only. w XT/XT only. x Firmware update required. y Requires a firmware update and Interface Cables IFC-40AB II or IFC-150AB II. z The digital compass function is not supported.

EOS SYSTEM ACCESSORIES CHART (Part 2-4/4)

ITEM CODE	PRODUCT DESCRIPTION	7D	80D	77D	70D	60D	50D / 40D	Rebel T7i	Rebel T6s / T6i	Rebel T5i / T4i / T3i / T2i	Rebel T6	Rebel T5 / T3	Rebel SL2	Rebel SL1	
GPS, WIRELESS TRANSMITTERS & ADAPTERS (CONT.)															
3829B001	Wireless File Transmitter WFT-E5A	•													
4263B001	Wireless File Transmitter WFT-E4 II A*														
2806B002	Wireless File Transmitter WFT-E4A*														
2375B002	Wireless File Transmitter WFT-E3A*						•								
4262B001	Wireless File Transmitter WFT-E2 II A*														
1906B002	Wireless File Transmitter WFT-E2A*														
0032B002	Wireless File Transmitter WFT-E1A														
0127B001	Wireless Range Antenna ERA-E1*														
1716C001	Wi-Fi Adapter W-E1														
STORAGE															
9899B002	Connect Station CS100*		•	•	•	•		•	•	•	•	•	•	•	•
MICROPHONE															
1429C001	Directional Microphone DM-E1	•	•	•		•		•	•	•			•	•	

* Discontinued • Dealers do not earn any Co-op Advertising Allowance on purchases of these products.
 a May require exposure compensation. b Requires RA-N3 Adapter. c Requires Adapter Ed-c (included w/ Angle Finder C). d Requires Adapter Ec-c (included w/ Angle Finder C). e Not for use w/ EOS-1n RS.
 f EOS-1v only; not for use with a Power Drive Booster. g No TTL flash possible. h 30D only. i T5i/T4i only. j Not for use w/ K2. k For Power Drive Booster PB-E2 only. l Rebel XT only. m Rebel only.
 n Requires Remote Controller Adapter RA-E3. o No TTL flash possible for IX Lite only. p T5 only. q IX only. r 30D/20D only. s XSi/T1i only. t 1Ds Mark III/1D Mark III require firmware upgrade. u 1D Mark IV only.
 v XSi/XS only. w XT/XT only. x Firmware update required. y Requires a firmware update and Interface Cables IFC-40AB II or IFC-150AB II. z The digital compass function is not supported.



EOS SYSTEM ACCESSORIES CHART (Part 3-1/4)

ITEM CODE	PRODUCT DESCRIPTION	Rebel T1i / XSi / XS	30D / 20D / 10D	D60 / D30	DIGITAL REBEL XTi / XT / DIGITAL REBEL	EOS R	EOS M5	EOS M6	EOS M50	EOS M3	EOS M100/ EOS M10	EOS M		
*POWER DRIVE BOOSTERS / CHARGERS AND BATTERY PACKS														
2254A002	Power Drive Booster PB-E2*													
3354B001	Battery Magazine BGM-E6*													
9833A001	Battery Magazine BGM-E2		• r											
2446A001	Battery Magazine BM-E2*													
7084A002	Ni-MH Pack NP-E3													
2418A001	Ni-MH Pack NP-E2*													
2419A005	Ni-MH Charger NC-E2*													
7875A002	Compact Power Adapter CA-PS700	•			• /		•	•	•	•	•	•		
5737A008	Compact Power Adapter CA-PS400*		•	•	• m									
8466A001	Car Battery Cable CB-570		• h											
3350B001	Car Battery Charger CBC-E6					•								
3051B001	Car Battery Charger CBC-E5*	•												
1170C002	Battery Charger LC-E19													
9968B001	Battery Charger LC-E17						•	•		•				
6781B001	Battery Charger LC-E12								•		•	•		
5113B002	Battery Charger LC-E10										•	•		
4520B003	Battery Charger LC-E8E													
3348B001	Battery Charger LC-E6					•								
3047B001	Battery Charger LC-E5*	•												
5752B002	Battery Charger LC-E4N*													
1895B002	Battery Charger LC-E4													
8478A002	Battery Charger CB-5L*		•	•	• m									
0763B001	Battery Charger CB-2LW				• /									
7303A001	Battery Charger CB-2LT*				• /									
NEW 3250C002	USB Power Adapter PD-E1					•								
0073C002	AC Adapter Kit ACK-E18*													
9927B001	AC Adapter Kit ACK-E17*						•	•		•				
8624B002	AC Adapter Kit ACK-E15*													
6784B002	AC Adapter Kit ACK-E12*								•		•	•		
4517B002	AC Adapter Kit ACK-E8*													
3351B002	AC Adapter Kit ACK-E6*					•								
3071B002	AC Adapter Kit ACK-E5*	•												
1896B002	AC Adapter Kit ACK-E4*													
0766B001	AC Adapter Kit ACK-DC20*													
5113B002	AC Adapter Kit ACK-E10*													
8364A002	AC Adapter Kit ACK-E2*		•	•	• m									
7097A002	DC Coupler Kit DCK-E1*													
1171C002	AC Adapter AC-E19													
1425C002	AC Adapter AC-E6N					•								
1172C001	DC Coupler Kit DR-E19													
0250C001	DC Coupler Kit DR-E18													
1431C001	DC Coupler Kit DR-E17						•	•		•				
8623B001	DC Coupler Kit DR-E15													
6785B001	DC Coupler Kit DR-E12								•		•	•		
5112B001	DC Coupler Kit DR-E10													
4518B001	DC Coupler Kit DR-E8													
3352B001	DC Coupler Kit DR-E6					•								
3072B001	DC Coupler Kit DR-E5*	•	•	•										
5738A001	DC Coupler Kit DR-400*				• m									
NEW 3086C002	Battery Grip BG-E22					•								
2130C001	Battery Grip BG-E21													
1485C001	Battery Grip BG-E20													
0050C001	Battery Grip BG-E18													
9130B001	Battery Grip BG-E16													
8471B001	Battery Grip BG-E14													
8038B001	Battery Grip BG-E13													
5261B001	Battery Grip BG-E11													
4740B001	Battery Grip BG-E9*													
4516B001	Battery Grip BG-E8*													
3815B001	Battery Grip BG-E7*													
3353B001	Battery Grip BG-E6*													
3052B001	Battery Grip BG-E5	•												
0297B001	Battery Grip BG-E4*													
0211B001	Battery Grip BG-E3*				• /									

* Discontinued *Dealers do not earn any Co-op Advertising Allowance on purchases of these products.
a May require exposure compensation. b Requires RA-N3 Adapter. c Requires Adapter Ed-c (included w/ Angle Finder C). d Requires Adapter Ec-c (included w/ Angle Finder C). e Not for use w/ EOS-1N RS.
f EOS-1v only; not for use with a Power Drive Booster. g No TTL flash possible. h 30D only. i TSi/T4i only. j Not for use w/ K2. k For Power Drive Booster PB-E2 only. l Rebel XT only. m Rebel only.
n Requires Remote Controller Adapter RA-E3. o No TTL flash possible for IX Lite only. p T5 only. q IX only. r 30D/20D only. s XSi/T1i only. t 1Ds Mark III/1D Mark III require firmware upgrade. u 1D Mark IV only.
v XSi/XS only. w XTi/XT only. x Firmware update required y Requires a firmware update and Interface Cables IFC-40AB II or IFC-150AB II. z The digital compass function is not supported.

EOS SYSTEM ACCESSORIES CHART (Part 3-2/4)

ITEM CODE	PRODUCT DESCRIPTION	Rebel T1i/ XS1/XS	30D/ 20D/10D	D60/D30	DIGITAL REBEL XT1/XT/ DIGITAL REBEL	EOS R	EOS M5	EOS M6	EOS M50	EOS M3	EOS M100/ EOS M10	EOS M		
☉ POWER DRIVE BOOSTERS / CHARGERS AND BATTERY PACKS (CONT.)														
2313B001	Battery Grip BG-E2N*		● r											
9444A001	Battery Grip BG-E2*		● r											
8865A001	Battery Grip BG-E1*				● m									
1169C002	Battery Pack LP-E19													
9967B002	Battery Pack LP-E17						●	●		●				
6760B002	Battery Pack LP-E12								●		●	●		
5108B002	Battery Pack LP-E10													
4515B002	Battery Pack LP-E8													
9486B002	Battery Pack LP-E6N					●								
3347B001	Battery Pack LP-E6*					●								
3039B001	Battery Pack LP-E5	●												
5751B002	Battery Pack LP-E4N													
1891B002	Battery Pack LP-E4*		●	●										
9200A001	Battery Pack BP-511A				● m									
2413A002	Battery Pack BP-E1*													
4594A002	Battery Pack BP-300*													
8093A001	Battery Pack BP-220*													
2415A001	Battery Pack BP-50*													
9612A001	Battery Pack NB-2LH*				● j									
☉ REMOTE CONTROLLERS AND ACCESSORIES														
2140C001	Wireless Remote Control BR-E1					●			●					
4524B001	Wireless Controller RC-6	● s			●		●	●		●			●	
2467A001	Wireless Controller RC-5*	● s			●									
2465A001	Wireless Controller RC-1*	● s			●									
0295B001	Wireless Controller LC-5		●	●										
2474A002	Wireless Controller LC-4*		● b	● b										
2471A002	Wireless Controller LC-3 Set*		● b	● b										
2477A002	Timer Remote Controller TC-80N3	● n, v	● n	●	● n, w	●		●						
1157C001	Remote Controller Adapter RA-E3					●		●						
2476A001	Remote Switch RS-80N3		●	●				●						
2469A002	Remote Switch RS-60E3	●			●	●	●	●						
2393A001	Remote Switch 60T3*		● b	● b										
2449A001	Remote Switch Adapter T3*		● b	● b										
2441A001	Remote Switch Adapter RA-N3*		●	●										
2450A001	Cable Release Adapter T3*		● b	● b										
2440A001	Extension Cord ET-1000N3*		●	●										
2455A001	Extension Cord 1000T3		● b	● b										
☉ VIEWING ACCESSORIES														
0047C001	Magnifier MG-Eb		●	●										
0048C001	Magnifier MG-Ef	●												
1889B001	Eyecup Eg													
8171A001	Eyecup Ef	●			●									
2377A001	Eyecup Ec II													
2378A001	Eyecup Eb		●	●										
8172A001	Rubber Frame Ef	●			●									
2858A001	Rubber Frame Eb*		●	●										
2200B001	Anti-Fog Eyepiece Eg													
2880A001	Anti-Fog Eyepiece Ed*													
2879A001	Anti-Fog Eyepiece Ec													
3069B001	Eyepiece Extender EP-EX15 II*	●			●									
2444A001	Eyepiece Extender EP-EX15*		●	●	●									
2882A001	Angle Finder C	● d	● d	● d	● d									
1727C001	Electronic Viewfinder EVF-DC2 (BK)							●		●				
1882C001	Electronic Viewfinder EVF-DC2 (SL)							●		●				
9555B001	Electronic Viewfinder EVF-DC1							●		●				
☉ EXTENSION TUBES AND CLOSE UP ACCESSORIES														
9198A001/9199A001	Extension Tube EF12 II / EF25 II	● a	● a	● a	● a									
2819A001	52mm Close up Lens 250D													
2821A001	52mm Close up Lens 500D													
2820A001	58mm Close up Lens 250D													
2822A001	58mm Close up Lens 500D													
2823A001	72mm Close up Lens 500D													
2824A001	77mm Close up Lens 500D													

* Discontinued ☉ Dealers do not earn any Co-op Advertising Allowance on purchases of these products.™

a May require exposure compensation. b Requires RA-N3 Adapter. c Requires Adapter Ed-c (included w/ Angle Finder C). d Requires Adapter Ec-c (included w/ Angle Finder C). e Not for use w/ EOS-1n RS. f EOS-1v only; not for use with a Power Drive Booster. g No TTL flash possible. h 30D only. i T5i/T4i only. j Not for use w/ K2. k For Power Drive Booster PB-E2 only. l Rebel XT only. m Rebel only. n Requires Remote Controller Adapter RA-E3. o No TTL flash possible for IX Lite only. p T5 only. q IX only. r 30D/20D only. s XS1/T1i only. t 1Ds Mark III/1D Mark III require firmware upgrade. u 1D Mark IV only. v XS1/XS only. w XT1/XT only. x Firmware update required. y Requires a firmware update and Interface Cables IFC-40AB II or IFC-150AB II. z The digital compass function is not supported.

EOS SYSTEM ACCESSORIES CHART (Part 3-3/4)

ITEM CODE	PRODUCT DESCRIPTION	Rebel T1i / XS1 / XS	30D / 20D / 10D	D60 / D30	DIGITAL REBEL XT1 / XT2 / DIGITAL REBEL	EOS R	EOS M5	EOS M6	EOS M50	EOS M3	EOS M100/ EOS M10	EOS M			
SPEEDLITE AND ACCESSORIES (CONT.)															
2398C002	Macro Twin Lite MT-26EX-RT	●	●	●	●	●	●	●	●	●	●	●			
2357A002	Macro Twin Lite MT-24EX	●	●	●	●	●	●	●	●	●	●	●			
9389B002	Macro Ring Lite MR-14EX II	●	●	●	●	●	●	●	●	●	●	●			
2356A002	Macro Ring Lite MR-14EX*	●	●	●	●	●	●	●	●	●	●	●			
1177C002	Speedlite 600EX II-RT	●	●	●	●	●	●	●	●	●	●	●			
5296B002	Speedlite 600EX-RT*	●	●	●	●	●	●	●	●	●	●	●			
1946B002	Speedlite 580EX II*	●	●	●	●	●	●	●	●	●	●	●			
9445A002	Speedlite 580EX*	●	●	●	●	●	●	●	●	●	●	●			
2261A003	Speedlite 550EX*	●	●	●	●	●	●	●	●	●	●	●			
4580A001	Speedlite 540EZ	●g	●g	●g	●g	●	●	●	●	●	●	●			
2258A003	Speedlite 480EG Set*	●g	●g	●g	●g	●	●	●	●	●	●	●			
1957C002	Speedlite 470EX-AI	●	●	●	●	●	●	●	●	●	●	●			
0585C006	Speedlite 430EX III-RT	●	●	●	●	●	●	●	●	●	●	●			
2805B002	Speedlite 430EX II*	●	●	●	●	●	●	●	●	●	●	●			
0298B002	Speedlite 430EX*	●	●	●	●	●	●	●	●	●	●	●			
4590A009	Speedlite 420EX*	●	●	●	●	●	●	●	●	●	●	●			
	Speedlite 380EX*	●	●	●	●	●	●	●	●	●	●	●			
5246B002	Speedlite 320EX*	●g	●g	●g	●g	●	●	●	●	●	●	●			
5247B002	Speedlite 270EX II	●g	●g	●g	●g	●	●	●	●	●	●	●			
3806B002	Speedlite 270EX*	●	●	●	●	●	●	●	●	●	●	●			
2262A006	Speedlite 220EX*	●	●	●	●	●	●	●	●	●	●	●			
6825B002	Speedlite 90EX*	●	●	●	●	●	●	●	●	●	●	●			
2257A001	Speedlite 200E*					●									
	Macro Ring Lite ML-3 Set*					●									
	Slave Unit E*	For exclusive use w/ Speedlite 480EG													
◆1180C001	Compact Battery Pack CP-E4N	For exclusive use w/ Speedlite 600EX II-RT, 600EX-RT, 600EX, 580EX II, 580EX, 550EX, 540EZ, 430EZ, Macro Ring Lite MR-14EX II, MR-14EX, Macro Twin Lite MT-26EX-RT, MT-24EX													
◆1947B001	Compact Battery Pack CP-E4*	For exclusive use w/ Speedlite 580EX II, 580EX, 550EX, 540EZ, 480EG, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX													
◆9836A001	Compact Battery Pack CP-E3*	For exclusive use w/ Speedlite 580EX, 550EX, 540EZ, 480EG, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX													
◆2448A001	Compact Battery Pack CP-E2*	For exclusive use w/ Speedlite 580EX, 550EX, 540EZ, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX													
◆5743B002	Speedlite Transmitter ST-E3-RT	For exclusive use w/ Speedlite 600EX II-RT, 600EX-RT, 430EX III-RT													
◆2478A002	Speedlite Transmitter ST-E2	For exclusive use w/ Speedlite 600EX II-RT, 600EX-RT, 580EX II, 580EX, 550EX, 470EX-AI, 430EX III-RT, 430EX, 420EX													
◆2402A005	Transistor Pack E Ni-Cd Set*	For exclusive use w/ Speedlite 550EX, 540EZ, 480EG, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX													
◆2402A006	Transistor Pack E*	For exclusive use w/ Speedlite 580EX, 550EX, 540EZ, 480EG, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX													
◆2429A001	Battery Magazine TP	For exclusive use w/ Transistor Pack E*													
◆1948B001	Battery Magazine CPM-E4*	For exclusive use w/ Speedlite Speedlite 600EX-RT, 580EX II													
◆2403A007	Ni-Cd Pack TP*	For exclusive use w/ Transistor Pack E*													
◆2401A003	Ni-Cd Charger TP*	For exclusive use w/ Transistor Pack E*													
◆2438A001	TTL Hot Shoe Adapter 3*	For exclusive use w/Connecting Cords 60 & 300 (Not compatible with any EOS digital SLR cameras)													
	Off-Camera Shoe Adapter*														
◆2447A001	Off-Camera Shoe Adapter OA-2*	For exclusive use w/TTL Hot Shoe Adapter 3, TTL Distributor & Off-Camera Shoe Adapter (Not compatible with any EOS digital SLR cameras)													
◆2431A001	TTL Distributor														
◆2387A001	Connecting Cord 60	For exclusive use w/TTL Hot Shoe Adapter 3, TTL Distributor & Off-Camera Shoe Adapter (Not compatible with any EOS digital SLR cameras)													
◆2388A001	Connecting Cord 300														
◆2391A001	Off-Camera Shoe Cord 2*	●		●	●										
◆1950B00	Off-Camera Shoe Cord OC-E3	Dust/Water-resistant for use w/Speedlite 600EX II-RT, 600EX-RT, 580EX II, for exclusive use w/ Speedlite 580EX, 470EX-AI, 430EX III-RT, 430EX													
◆5744B001	Speedlite Release Cable SR-N3	For exclusive use w/ Speedlite 600EX-RT													
◆2364A001	Macrolite Adapter 52C	For exclusive use w/ Macro Ring Lite ML-3 / MR-14EX / Macro Twin Lite MT-24EX													
◆2365A001	Macrolite Adapter 58C														
◆3563B001	Macrolite Adapter 67	For exclusive use w/ Macro Ring Lite MR-14EX, ML-3, Macro Twin Lite MT-26EX-RT, MT-24EX													
◆2829A001	Macrolite Adapter 72C	For exclusive use w/ Macro Ring Lite MR-14EX, ML-3, Macro Twin Lite MT-26EX-RT, MT-24EX													
	Wide Adapter 200E*	For exclusive use w/ Speedlite 200E													
◆1179C001	Bounce Adapter SBA-E3	For exclusive use w/ Speedlite 600EX II-RT													
◆0588C001	Bounce Adapter SBA-E2	For exclusive use w/ Speedlite 430EX III-RT													
◆1178C001	Color Filter Set SCF-E3	For exclusive use w/ Speedlite 600EX II-RT													
◆0587C001	Color Filter Set SCF-E2	For exclusive use w/ Speedlite 430EX III-RT													
◆5746B001	Color Filter Set SCF-E1	For exclusive use w/ Speedlite 600EX-RT													
◆5745B001	Color Filter Holder SCH-E1	For exclusive use w/ Speedlite 600EX-RT													
◆GPS, WIRELESS TRANSMITTERS & ADAPTERS															
6363B001	GPS Receiver GP-E2					●									
6364B001	GPS Receiver GP-E1														
1173C001	Wireless File Transmitter WFT-E8A														
5754B009	Wireless File Transmitter WFT-E7A (Ver. 2)					●									
5754B001	Wireless File Transmitter WFT-E7A*														
5756B001	Wireless File Transmitter WFT-E6A*														

* Discontinued ◆Dealers do not earn any Co-op Advertising Allowance on purchases of these products.
a May require exposure compensation. b Requires RA-N3 Adapter. c Requires Adapter Ed-c (included w/ Angle Finder C). d Requires Adapter Ec-c (included w/ Angle Finder C). e Not for use w/ EOS-1n RS.
f EOS-1v only; not for use with a Power Drive Booster. g No TTL flash possible. h 30D only. i TS1/4i only. j Not for use w/ K2. k For Power Drive Booster PB-E2 only. l Rebel XT only. m Rebel only.
n Requires Remote Controller Adapter RA-E3. o No TTL flash possible for IX Lite only. p TS only. q IX only. r 30D/20D only. s XS1/T1i only. t 1Ds Mark III/1D Mark III require firmware upgrade. u 1D Mark IV only.
v XS1/XS only. w XT1/XT only. x Firmware update required y Requires a firmware update and Interface Cables IFC-40AB II or IFC-150AB II. z The digital compass function is not supported.

EOS SYSTEM ACCESSORIES CHART (Part 3-4/4)

ITEM CODE	PRODUCT DESCRIPTION	Rebel T1i / XSi / XS	30D / 20D / 10D	D60 / D30	DIGITAL REBEL XTi / XT / DIGITAL REBEL	EOS R	EOS M5	EOS M6	EOS M50	EOS M3	EOS M100/ EOS M10	EOS M		
GPS, WIRELESS TRANSMITTERS & ADAPTERS (CONT.)														
3829B001	Wireless File Transmitter WFT-E5A													
4263B001	Wireless File Transmitter WFT-E4 II A*													
2806B002	Wireless File Transmitter WFT-E4A*													
2375B002	Wireless File Transmitter WFT-E3A*													
4262B001	Wireless File Transmitter WFT-E2 II A*													
1906B002	Wireless File Transmitter WFT-E2A*													
0032B002	Wireless File Transmitter WFT-E1A		• r											
0127B001	Wireless Range Antenna ERA-E1*		• r											
1716C001	Wi-Fi Adapter W-E1													
STORAGE														
9899B002	Connect Station CS100*					•	•	•		•	•	•		
MICROPHONE														
1429C001	Directional Microphone DM-E1					•	•	•		•		•		

* Discontinued. • Dealers do not earn any Co-op Advertising Allowance on purchases of these products.
a May require exposure compensation. b Requires RA-N3 Adapter. c Requires Adapter Ed-c (included w/ Angle Finder C). d Requires Adapter Ec-c (included w/ Angle Finder C). e Not for use w/ EOS-1n RS.
f EOS-1v only; not for use with a Power Drive Booster. g No TTL flash possible. h 30D only. i T5i/T4i only. j Not for use w/ K2. k For Power Drive Booster PB-E2 only. l Rebel XT only. m Rebel only.
n Requires Remote Controller Adapter RA-E3. o No TTL flash possible for IX Lite only. p T5 only. q IX only. r 30D/20D only. s XSi/T1i only. t 1Ds Mark III/1D Mark III require firmware upgrade. u 1D Mark IV only.
v XSi/XS only. w XT/XT only. x Firmware update required. y Requires a firmware update and Interface Cables IFC-40AB II or IFC-150AB II. z The digital compass function is not supported.

EOS SYSTEM ACCESSORIES CHART (Part 4-1/3)

ITEM CODE	PRODUCT DESCRIPTION	1V HS / 1V	1N RS / 1N / 1	3	ELAN 7 Series	ELAN IIe / II	REBEL T2 / Ti / K2	REBEL 2000	REBEL GII / G	REBEL XSN / XS / X	IX Lite / IX			
POWER DRIVE BOOSTERS / CHARGERS AND BATTERY PACKS														
2254A002	Power Drive Booster PB-E2*	•	• e	•										
3354B001	Battery Magazine BGM-E6*													
9833A001	Battery Magazine BGM-E2													
2446A001	Battery Magazine BM-E2*	•	• e	•										
7084A002	Ni-MH Pack NP-E3													
2418A001	Ni-MH Pack NP-E2*	• k	• k	• k										
2419A005	Ni-MH Charger NC-E2*	• k	• k	• k										
7875A002	Compact Power Adapter CA-PS700													
5737A008	Compact Power Adapter CA-PS400*													
5113B002	Battery Charger LC-E10													
4520B003	Battery Charger LC-E8E													
3348B001	Battery Charger LC-E6													
3047B001	Battery Charger LC-E5*													
5752B002	Battery Charger LC-E4N*													
1895B002	Battery Charger LC-E4													
8478A002	Battery Charger CB-5L*													
0763B001	Battery Charger CB-2LW													
7303A001	Battery Charger CB-2LT*													
4517B002	AC Adapter Kit ACK-E8*													
3351B002	AC Adapter Kit ACK-E6*													
3071B002	AC Adapter Kit ACK-E5*													
1896B002	AC Adapter Kit ACK-E4*													
0766B001	AC Adapter Kit ACK-DC20*													
5113B002	AC Adapter Kit ACK-E10*													
8364A002	AC Adapter Kit ACK-E2*													
7097A002	DC Coupler Kit DCK-E1*													
5112B001	DC Coupler Kit DR-E10													
4518B001	DC Coupler Kit DR-E8													
3352B001	DC Coupler Kit DR-E6													
3072B001	DC Coupler Kit DR-E5*													
5738A001	DC Coupler Kit DR-400*													
8471B001	Battery Grip BG-E14													
8038B001	Battery Grip BG-E13													
5261B001	Battery Grip BG-E11													
4740B001	Battery Grip BG-E9*													
4516B001	Battery Grip BG-E8*													
3815B001	Battery Grip BG-E7*													
3353B001	Battery Grip BG-E6*													
3052B001	Battery Grip BG-E5													
0297B001	Battery Grip BG-E4*													
0211B001	Battery Grip BG-E3*													
2313B001	Battery Grip BG-E2N*													
9444A001	Battery Grip BG-E2*													
8865A001	Battery Grip BG-E1*													
5108B002	Battery Pack LP-E10													
4515B002	Battery Pack LP-E8													
3347B001	Battery Pack LP-E6*													
3039B001	Battery Pack LP-E5													
5751B002	Battery Pack LP-E4N													
1891B002	Battery Pack LP-E4*													
9200A001	Battery Pack BP-511A													
2413A002	Battery Pack BP-E1*	•	• e	•										
4594A002	Battery Pack BP-300*				•									
8093A001	Battery Pack BP-220*						•							
2415A001	Battery Pack BP-50*					•								
9612A001	Battery Pack NB-2LH*													
GRIPS AND BACKS														
2369A002	Standard Grip GR-E2*	• c	• e	•										
2285A002	Date Back DB-E2*							•						
2368A003	Grip GR-100TP*								•	•				
REMOTE CONTROLLERS AND ACCESSORIES														
4524B001	Wireless Controller RC-6				•	•	•							
2467A001	Wireless Controller RC-5*			•	•	•	• j				• q			
2465A001	Wireless Controller RC-1*				•	•	• j				• q			

* Discontinued *Dealers do not earn any Co-op Advertising Allowance on purchases of these products.*

a May require exposure compensation. b Requires RA-N3 Adapter. c Requires Adapter Ed-c (included w/ Angle Finder C). d Requires Adapter Ec-c (included w/ Angle Finder C). e Not for use w/ EOS-1N RS. f EOS-1v only; not for use with a Power Drive Booster. g No TTL flash possible. h 30D only. i T5i/T4i only. j Not for use w/ K2. k For Power Drive Booster PB-E2 only. l Rebel XT only. m Rebel only. n Requires Remote Controller Adapter RA-E3. o No TTL flash possible for IX Lite only. p T5 only. q IX only. r 30D/20D only. s XSi/T1i only. t 1Ds Mark III/1D Mark III require firmware upgrade. u 1D Mark IV only. v XSi/XS only. w XTi/XT only. x Firmware update required. y Requires a firmware update and Interface Cables IFC-40AB II or IFC-150AB II. z The digital compass function is not supported.

EOS SYSTEM ACCESSORIES CHART (Part 4-2/3)

ITEM CODE	PRODUCT DESCRIPTION	1V HS / 1V	1N RS / 1N / 1	3	ELAN 7 Series	ELAN IIe / II	REBEL T2 / Ti / K2	REBEL 2000	REBEL GII / G	REBEL XSN / XS / X	IX Lite / IX			
REMOTE CONTROLLERS AND ACCESSORIES (CONT.)														
0295B001	Wireless Controller LC-5													
2474A002	Wireless Controller LC-4*	● b	●	● b										
2471A002	Wireless Controller LC-3 Set*	●	●	●										
2477A002	Time Remote Controller TC-80N3	●		●										
2476A001	Remote Switch RS-80N3	●		●							● g			
2469A002	Remote Switch RS-60E3	●			●	●	●	●	●		● g			
2393A001	Remote Switch 60T3*	● b		● b										
2449A001	Remote Switch Adapter T3*	● b		● b										
2441A001	Remote Switch Adapter RA-N3*	●		●										
2450A001	Cable Release Adapter T3*	● b	●	● b										
2440A001	Extension Cord ET-1000N3*	●		●										
2455A001	Extension Cord 1000T3	● b	●	● b										
VIEWING ACCESSORIES														
8171A001	Eyecup Ef						●							
2377A001	Eyecup Ec II	●	●											
2378A001	Eyecup Eb							●	●	●				
8172A001	Rubber Frame Ef						●							
2858A001	Rubber Frame Eb*							●	●	●				
2200B001	Anti-Fog Eyepiece Eg													
2880A001	Anti-Fog Eyepiece Ed*			●	●									
2879A001	Anti-Fog Eyepiece Ec	●	●											
3069B001	Eyepiece Extender EP-EX15 II*													
2444A001	Eyepiece Extender EP-EX15*	●	●				●	●	●	●	●			
2882A001	Angle Finder C	● d	● d	● c	● c	● c	● d	● d	● d	● d	● d			
EXTENSION TUBES AND CLOSE UP ACCESSORIES														
9198A001/9199A001	Extension Tube EF12 II / EF25 II	● a	● a	● a	● a	● a	● a	● a	● a	● a	● a			
2819A001	52mm Close up Lens 250D													
2821A001	52mm Close up Lens 500D													
2820A001	58mm Close up Lens 250D													
2822A001	58mm Close up Lens 500D													
2823A001	72mm Close up Lens 500D													
2824A001	77mm Close up Lens 500D													
<i>For exclusive use w/ EF and FD Lenses</i>														
<i>Close-up lens 250D is recommended for use with lenses from 50mm to 135mm focal length; 500 & 500D for lenses from 70mm to 300mm</i>														
SPEEDLITE AND ACCESSORIES														
2398C002	Macro Twin Lite MT-26EX-RT	●	●	●	●	●	●	●	●	●	●			
2357A002	Macro Twin Lite MR-24EX	●	●	●	●	●	●	●	●	●	●			
9389B002	Macro Ring Lite MR-14EX II	●	●	●	●	●	●	●	●	●	●			
2356A002	Macro Ring Lite MR-14EX*	●	●	●	●	●	●	●	●	●	●			
1177C002	Speedlite 600EX II-RT	●	●	●	●	●	●	●	●	●	●			
5296B002	Speedlite 600EX-RT*	●	●	●	●	●	●	●	●	●	●			
1946B002	Speedlite 580EX II*	●	●	●	●	●	●	●	●	●	●			
9445A002	Speedlite 580EX*	●	●	●	●	●	●	●	●	●	●			
2261A003	Speedlite 550EX*	●	●	●	●	●	●	●	●	●	●			
4580A001	Speedlite 540EZ	● g	●	●	●	●	●	●	●	●	● o			
2258A003	Speedlite 480EG Set*	● g	●	●	●	●	●	●	●	●	● o			
NEW 1957C002	Speedlite 470EX-AI	● g	●	●	●	●	●	●	●	●	● o			
0585C006	Speedlite 430EX III-RT	●	●	●	●	●	●	●	●	●	●			
2805B002	Speedlite 430EX II*	●	●	●	●	●	●	●	●	●	●			
0298B002	Speedlite 430EX*	●	●	●	●	●	●	●	●	●	●			
4590A009	Speedlite 420EX*	●	●	●	●	●	●	●	●	●	●			
	Speedlite 380EX*	●	●	●	●	●	●	●	●	●	●			
5246B002	Speedlite 320EX*	●	●	●	●	●	●	●	●	●	●			
5247B002	Speedlite 270EX II	●	●	●	●	●	●	●	●	●	●			
3806B002	Speedlite 270EX*	●	●	●	●	●	●	●	●	●	●			
2262A006	Speedlite 220EX*	●	●	●	●	●	●	●	●	●	●			
2257A001	Speedlite 200E*	●	●	●	●	●	● g	●	●	●	● o			
	Macro Ring Lite ML-3 Set*	●	●	●	●	●	● g	●	●	●	●			
	Slave Unit E*	<i>For exclusive use w/ Speedlite 480EG</i>												
1180C001	Compact Battery Pack CP-E4N	<i>For exclusive use w/ Speedlite 600EX II-RT, 600EX-RT, 600EX, 580EX II, 580EX, 550EX, 540EZ, 430EZ, Macro Ring Lite MR-14EX II, MR-14EX, Macro Twin Lite MT-26EX-RT, MT-24EX</i>												
1947B001	Compact Battery Pack CP-E4*	<i>For exclusive use w/ Speedlite 580EX II, 580EX, 550EX, 540EZ, 480EG, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX</i>												
9836A001	Compact Battery Pack CP-E3*	<i>For exclusive use w/ Speedlite 580EX, 550EX, 540EZ, 480EG, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX</i>												
2448A001	Compact Battery Pack CP-E2*	<i>For exclusive use w/ Speedlite 580EX, 550EX, 540EZ, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX</i>												
5743B002	Speedlite Transmitter ST-E3-RT	<i>For exclusive use w/ Speedlite 600EX II-RT, 600EX-RT, 430EX III-RT</i>												
2478A002	Speedlite Transmitter ST-E2	<i>For exclusive use w/ Speedlite 600EX II-RT, 600EX-RT, 580EX II, 580EX, 550EX, 470EX-AI, 430EX III-RT, 430EX, 420EX</i>												
2402A005	Transistor Pack E Ni-Cd Set*	<i>For exclusive use w/ Speedlite 550EX, 540EZ, 480EG, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX</i>												
2402A006	Transistor Pack E*	<i>For exclusive use w/ Speedlite 580EX, 550EX, 540EZ, 480EG, 430EZ, Macro Ring Lite MR-14EX, Macro Twin Lite MT-24EX</i>												

* Discontinued *Dealers do not earn any Co-op Advertising Allowance on purchases of these products.*

a May require exposure compensation. b Requires RA-N3 Adapter. c Requires Adapter Ed-c (included w/ Angle Finder C). d Requires Adapter Ec-c (included w/ Angle Finder C). e Not for use w/ EOS-1N RS. f EOS-1v only; not for use with a Power Drive Booster. g No TTL flash possible. h 30D only. i T5i/T4i only. j Not for use w/ K2. k For Power Drive Booster PB-E2 only. l Rebel Ti only. m Rebel only. n Requires Remote Controller Adapter RA-E3. o No TTL flash possible for IX Lite only. p T5 only. q IX only. r 30D/20D only. s XSi/Ti only. t 1Ds Mark III/1D Mark III require firmware upgrade. u 1D Mark IV only. v XSi/XS only. w XTi/XT only. x Firmware update required. y Requires a firmware update and Interface Cables IFC-40AB II or IFC-150AB II. z The digital compass function is not supported.

EOS SYSTEM ACCESSORIES CHART (Part 4-3/3)

ITEM CODE	PRODUCT DESCRIPTION	1V HS / 1V	1N RS / 1N / 1	3	ELAN 7 Series	ELAN IIe / II	REBEL T2 / Ti / K2	REBEL 2000	REBEL GII / G	REBEL XSN / XS / X	IX Lite / IX			
SPEEDLITE AND ACCESSORIES (CONT.)														
2429A001	Battery Magazine TP	For exclusive use w/ Transistor Pack E*												
1948B001	Battery Magazine CPM-E4*	For exclusive use w/ Speedlite Speedlite 600EX-RT, 580EX II												
2403A007	Ni-Cd Pack TP*	For exclusive use w/ Transistor Pack E*												
2401A003	Ni-Cd Charger TP*	For exclusive use w/ Transistor Pack E*												
2438A001	TTL Hot Shoe Adapter 3*	For exclusive use w/Connecting Cords 60 & 300 (Not compatible with any EOS Digital SLR cameras)												
	Off-Camera Shoe Adapter*													
2447A001	Off-Camera Shoe Adapter OA-2*													
2431A001	TTL Distributor	For exclusive use w/TTL Hot Shoe Adapter 3, TTL Distributor & Off-Camera Shoe Adapter (Not compatible with any EOS digital SLR cameras)												
2387A001	Connecting Cord 60													
2388A001	Connecting Cord 300													
2391A001	Off-Camera Shoe Cord 2*	•	•	•	•	•	•	•	•	•	•			
1950B001	Off-Camera Shoe Cord OC-E3	Dust/Water-resistant for use w/Speedlite 600EX II-RT, 600EX-RT, 580EX II, for exclusive use w/ Speedlite 580EX, 470EX-AI, 430EX III-RT, 430EX												
5744B001	Speedlite Release Cable SR-N3	For exclusive use w/ Speedlite Speedlite 600EX-RT												
2364A001	MacroLite Adapter 52C	For exclusive use w/ Macro Ring Lite ML-3 / MR-14EX / Macro Twin Lite MT-24EX												
2365A001	MacroLite Adapter 58C													
3563B001	MacroLite Adapter 67	For exclusive use w/ Macro Ring Lite MR-14EX, ML-3, Macro Twin Lite MT-26EX-RT, MT-24EX												
2829A001	MacroLite Adapter 72C	For exclusive use w/ Macro Ring Lite MR-14EX, ML-3, Macro Twin Lite MT-26EX-RT, MT-24EX												
	Wide Adapter 200E*	For exclusive use w/ Speedlite 200E												
1179C001	Bounce Adapter SBA-E3	For exclusive use w/ Speedlite 600EX II-RT												
0588C001	Bounce Adapter SBA-E2	For exclusive use w/ Speedlite 430EX III-RT												
1178C001	Color Filter Set SCF-E3	For exclusive use w/ Speedlite 600EX II-RT												
0587C001	Color Filter Set SCF-E2	For exclusive use w/ Speedlite 430EX III-RT												
5746B001	Color Filter Set SCF-E1	For exclusive use w/ Speedlite 600EX-RT												
5745B001	Color Filter Holder SCH-E1	For exclusive use w/ Speedlite 600EX-RT												
WIRELESS TRANSMITTER														
5754B001	Wireless File Transmitter WFT-E7A*													
5756B001	Wireless File Transmitter WFT-E6A*													
3829B001	Wireless File Transmitter WFT-E5A													
4263B001	Wireless File Transmitter WFT-E4 II A*													
2806B002	Wireless File Transmitter WFT-E4A*													
2375B002	Wireless File Transmitter WFT-E3A*													
4262B001	Wireless File Transmitter WFT-E2 II A*													
1906B002	Wireless File Transmitter WFT-E2A*													
0032B002	Wireless File Transmitter WFT-E1A													
0127B001	Wireless Range Antenna ERA-E1*													

* Discontinued • Dealers do not earn any Co-op Advertising Allowance on purchases of these products.
a May require exposure compensation. b Requires RA-N3 Adapter. c Requires Adapter Ed-c (included w/ Angle Finder C). d Requires Adapter Ec-c (included w/ Angle Finder C). e Not for use w/ EOS-1n RS.
f EOS-1v only; not for use with a Power Drive Booster. g No TTL flash possible. h 30D only. i T5i/T4i only. j Not for use w/ K2. k For Power Drive Booster PB-E2 only. l Rebel XT only. m Rebel only.
n Requires Remote Controller Adapter RA-E3. o No TTL flash possible for IX Lite only. p T5 only. q IX only. r 30D/20D only. s XSi/T1i only. t 1Ds Mark III/1D Mark III require firmware upgrade. u 1D Mark IV only.
v XSi/XS only. w XT/XT only. x Firmware update required y Requires a firmware update and Interface Cables IFC-40AB II or IFC-150AB II. z The digital compass function is not supported.