



**SS150 SHUTTER STARZ
PROFESSIONAL PHOTOGRAPHY
STUDIO LIGHTING UMBRELLA KIT**



SS150 SHUTTER STARZ PROFESSIONAL PHOTOGRAPHY STUDIO LIGHTING UMBRELLA KIT

- A** Qty. 2 Premium Light Stands (extend from 33" to 81")
- B** Qty. 2 32" White Umbrellas
- C** Qty. 2 Premium Grade Bulbs (45 Watts each)
- D** Qty. 2 Light Brackets with Umbrella Holders
- E** Qty. 1 Premium Carrying Case

Total weight of kit 8lbs.

SS150 SHUTTER STARZ PROFESSIONAL PHOTOGRAPHY STUDIO LIGHTING UMBRELLA KIT

Thank you for your purchase of the Shutter Starz Photo Studio Lighting Umbrella Kit. This manual has been written to help you with the assembly, operating procedures and accessories. This Shutter Starz kit offers exceptional quality at a price you can afford. Qualities such as the thick nylon durable construction of our umbrellas and the extra large footprint offered by our light stands, plus the incredible convenience and portability of this package are standard on our lighting kits. The beauty about this set

is the ease and simplicity of use. It is not only one of our most cost effective flash set-ups, the quality is unmatched in the industry. With 2 45W Continuous Light Bulbs, you will be taking professional photos in minutes. Please read this manual carefully before use, and keep it handy for use during break down of equipment. For ordering spare bulbs or replacement parts, contact us at sales@squareperfect.com. Also check out our extended line of photo equipment now available.



Nylon Carrying Case



(2) Light Brackets with Umbrella Holders



(2) Premium Grade Bulbs (45 Watts each)



(2) White Studio Umbrellas



(2) Premium Light Stands

ASSEMBLY INSTRUCTIONS:



Insert bulb into light holder as shown and screw bulb until it fits snug into the socket.



Attach light holder to tripod/light stand as shown. Be sure to tighten screw on back of light holder for stability.



Insert umbrella pole into hole in light holder and tighten screw on side of light holder to keep umbrella stable.

SAFETY PRECAUTIONS:

- Become thoroughly familiar with this product before use. Run through at least one practice assembly and breakdown before you schedule a shoot.
- Never leave the lighting unsupervised when in use. Keep children or incompetent person away from lighting equipment.
- If the power cords show signs of wear or damage, they should be replaced or repaired by a qualified electrician before use.
- Wait until bulbs are completely cool before touching or removing them.
- Never use in a wet environment.
- Never move the appliance by pulling the cord. Make sure the cords do not come in contact with bulbs. Do not wind the cord around the appliance.
- Place stands/tripods on flat surface to prevent toppling.
- Do not touch the metal parts near the bulbs while in use, these parts may become very hot.
- Do not let umbrella touch light bulb when in use. Light bulb will get hot and can ruin the umbrella or start a fire.



SS150 SHUTTER STARZ PROFESSIONAL PHOTOGRAPHY STUDIO LIGHTING UMBRELLA KIT



One Year Limited Warranty

Shutter Starz products are warranted to be free from defects in materials or workmanship for one year from the date of purchase. Within this period, Shutter Starz will, at its sole discretion, repair or replace any components that fail during normal use. This warranty does not apply to damage caused by abnormal or unreasonable use, including any repair or attempted repair by anyone other than a certified Shutter Starz authorized service technician, use of replacement parts that are not OEM parts, in addition to incidental or consequential damages. Using this product for anything other than its original intended purpose or altering this product in any way will void this warranty. There is a 30 day limited warranty on all consumable parts including fuses and/or light bulbs.

If your Shutter Starz product has a manufacturer's defect covered by our warranty, we will either repair or replace it, at our option, without charge or refund. Such repairs, or items deemed to be eligible for replacement, will be made at no charge to the customer for parts or labor, provided that the customer shall be responsible for all shipping costs. This warranty does not apply to: A. cosmetic damage, such as scratches, nicks and dents; B. consumable parts, such as fuses and light bulbs, unless product damage has occurred due to a defect in materials or workmanship; C. damage caused by accident, abuse, misuse, water, flood, fire, or other acts of nature or external causes; D. damage caused by service performed by anyone who is not an authorized service provider of Shutter Starz; or E. damage to a product that has been modified or altered without the written permission of Shutter Starz. In addition, The original purchaser who has provided proper proof of the original retail purchase and all other requested information is the holder of this warranty.

Please note that repair costs and handling charges may apply if any issue was found to be the fault of the end user. Please be prepared to provide the units serial number, if applicable, your return shipping address and a daytime phone number and proof of purchase.

Shutter Starz retains the exclusive right to repair or replace, with a new or newly-refurbished replacement machine or part, the product or offer a full refund of the purchase price at its sole discretion. SUCH REMEDY SHALL BE THE SOLE AND EXCLUSIVE REMEDY FOR ANY BREACH OF WARRANTY.